Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-RC802N YAI2-TL001

Azwok RC802N YAI2 Replacement Remote Control User Manual

Model: AU-RC802N YAI2-TL001

Brand: Azwok

1. Introduction and Overview

This manual provides instructions for the Azwok RC802N YAI2 Replacement Remote Control. This remote is designed to function as a direct replacement for the original TCL RC802N YAI2 remote, offering all major buttons and functions. It is an ideal solution for replacing lost or defective remote controls.

The remote control is compatible with various TCL TV models, including but not limited to: 65P4USM, 50E18US, 55E18US, 55S6000FS, 49C2US, 55C2US, 65C2US, 75C2US, 32S6000S, 40S6000FS, 43S6000FS, and 49S6000FS.





Figure 1.1: Front view of the Azwok RC802N YAI2 Replacement Remote Control, showing all buttons and layout.

2. Product Features

- **Direct Replacement:** Functions identically to the original TCL RC802N YAI2 remote control.
- **No Programming Required:** Ready to use immediately after battery installation.
- **High Quality:** Constructed for durability and reliable performance.
- **Simple Operation:** Intuitive button layout for ease of use.
- **Wide Compatibility:** Supports a range of specified TCL TV models.

3. Setup

The Azwok RC802N YAI2 Replacement Remote Control requires no programming. Simply install the batteries, and it will be ready for immediate use with your compatible TCL TV.

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with the remote control. Always use new batteries for optimal performance.





Figure 3.1: Back view of the remote control, illustrating the battery compartment and proper battery orientation.

4. Operating Instructions

Once batteries are installed, point the remote control directly at your TCL TV. Ensure there are no obstructions between the remote and the TV's infrared receiver.

4.1 Key Functions

Button	Function
Power (Red)	Turns the TV On or Off.
Mute	Mutes or unmutes the TV sound.
0-9 (Number Buttons)	Direct channel selection.
Volume (+/-)	Adjusts the volume level.
Channel (Up/Down)	Changes TV channels.
Navigation (Arrows & OK)	Navigates through menus and confirms selections.
Home	Accesses the TV's home screen or smart TV interface.
Back/Exit	Returns to the previous screen or exits a menu.
Netflix	Direct access to the Netflix application.
Media Playback Controls	Includes Play/Pause, Stop, Fast Forward, Rewind, and Record buttons for media control.

5. Maintenance

5.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these may damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

6. Troubleshooting

6.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh AAA batteries if necessary.
- **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor.
- **Remote Sensor:** Ensure the TV's infrared sensor is clean and not blocked.
- **Compatibility:** Verify that your TV model is listed as compatible. If your model is not listed or your original remote differs significantly, please contact Azwok customer support for assistance.

6.2 Specific Buttons Not Working

- This may indicate low battery power. Try replacing the batteries.
- Ensure the remote is pointed directly at the TV.

7. Specifications

Attribute	Detail
Model Number	AU-RC802N YAI2-TL001
Product Dimensions	9.06 x 1.46 x 0.59 inches
Item Weight	2.79 ounces
Batteries Required	2 x AAA batteries (not included)
Color	Black
Compatible Devices	Television (Specific TCL models)
Special Feature	No Programming Required

8. Warranty and Support

8.1 Warranty Information

This Azwok RC802N YAI2 Replacement Remote Control comes with a 12-month warranty. Returns are accepted for refund or exchange if the product does not function with your specified devices.

8.2 Customer Support

If you cannot find your specific TV model listed, or if your original remote control appears different from this replacement, please contact Azwok customer support. We are available to assist you in confirming suitability and selecting the correct remote control for your needs.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BV29LJ3L

More documents and user manuals: **https://manuals.plus/**