Aigostar Bonnie

Aigostar Bonnie Drip Coffee Maker User Manual

Brand: Aigostar

Model: Bonnie (ASIN: B0BV8XLJ37)

Product Overview

The Aigostar Bonnie Drip Coffee Maker combines timeless design with modern technology to deliver a convenient and enjoyable coffee brewing experience. Featuring an 800W heating element, a 1.2-liter capacity thermal carafe, and a programmable LCD screen, this coffee maker is designed for ease of use and to keep your coffee warm for longer.



Image: Aigostar Coffee Maker with key features highlighted: 10-cup Carafe, Delay Brew Timer, Lasting Insulation.

Key features include a permanent filter, an intuitive LCD display, a durable thermal carafe, and a clear water gauge for precise filling. Its 24-hour programmable timer allows you to wake up to freshly brewed coffee, and the anti-drip design ensures a clean brewing process.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials from the coffee maker and its accessories. Ensure all components are present: main unit, thermal carafe with lid, and permanent filter.
2. **Initial Cleaning:** Before first use, wash the thermal carafe, its lid, and the permanent filter in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the coffee maker with a damp cloth.
3. **Placement:** Place the coffee maker on a flat, stable, heat-resistant surface, away from the edge of the countertop and out of reach of children. Ensure there is adequate ventilation around the unit.
4. **First Brew Cycle (Cleaning):** Fill the water reservoir to the MAX level with cold water. Do not add coffee grounds. Place the thermal carafe with its lid on the warming plate. Plug in the coffee maker and press the ON/OFF button to run a full brewing cycle. Discard the water after the cycle is complete. Repeat this process 1-2 times to thoroughly clean the internal components.



Image: The Aigostar Bonnie Drip Coffee Maker, showing its sleek black and stainless steel design.

Operating Instructions

Brewing Coffee

1. **Fill Water Reservoir:** Open the top lid and fill the water reservoir with fresh, cold water using the thermal carafe. Refer to the water gauge on the side of the coffee maker for desired cup markings (up to 1.2 liters or 10 cups). Do not exceed the MAX level.



Image: A hand pouring water into the coffee maker's reservoir, demonstrating its 10-cup large capacity.

2. **Add Coffee Grounds:** Place the permanent filter into the filter basket. Add the desired amount of ground coffee into the filter. A general guideline is one level tablespoon of coffee grounds per cup (150ml). Adjust to your taste. Close the top lid securely.



Image: A four-panel view showing the permanent filter with coffee grounds, the LCD display, the thermal carafe, and the water gauge.

3. **Place Carafe:** Ensure the thermal carafe with its lid is correctly positioned on the warming plate.
4. **Start Brewing:** Plug the coffee maker into a power outlet. Press the**ON/OFF** button on the control panel. The indicator light will illuminate, and the brewing process will begin.
5. **Pause & Serve Function:** The coffee maker features an anti-drip system. You can temporarily remove the carafe during the brewing cycle to pour a cup of coffee. The flow of coffee will stop for approximately 30 seconds. Return the carafe to the warming plate within this time to prevent overflow.



Image: Diagram illustrating the 30-second anti-drip design, showing coffee flow stopping when the carafe is removed.

6. **Brewing Complete:** Once the brewing cycle is complete, the coffee maker will automatically turn off. The thermal carafe is designed with double-layer insulation to keep your coffee warm for an extended period.



Image: Cross-section diagram of the thermal carafe highlighting its double-layer stainless steel construction for long-time insulation.

Using the 24-Hour Programmable Timer

The programmable timer allows you to set the coffee maker to start brewing automatically at a desired time within a 24-hour period.

1. **Set Current Time:** When the coffee maker is plugged in but not brewing, the LCD display will show "12:00". Press the **HOUR** button to set the hour and the **MIN** button to set the minutes. The clock operates in a 24-hour format.
2. **Set Programmed Time:** Press the **PRO** button. The display will flash "PRO". Use the **HOUR** and **MIN** buttons to set your desired brewing start time.
3. **Activate Program:** After setting the program time, press the **PRO** button again to confirm. The "PRO" indicator will remain lit, indicating that the timer is active.
4. **Prepare for Brewing:** Ensure the water reservoir is filled and coffee grounds are in the filter basket, and the carafe is in place. The coffee maker will automatically start brewing at the set time.



Image: Graphic illustrating the 24-hour timer function, with coffee beans arranged in a clock-like pattern around a cup of coffee.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your coffee maker.

- **Daily Cleaning:**
  - Always unplug the coffee maker before cleaning.
  - Remove the permanent filter and discard used coffee grounds. Rinse the filter and filter basket under running water.
  - Wash the thermal carafe and its lid with warm, soapy water. Use a soft brush for thorough cleaning if needed. Rinse well and dry.
  - Wipe the exterior of the coffee maker with a soft, damp cloth. Do not immerse the main unit in water or other liquids.
- **Descaling (Monthly or as needed):**

  Mineral deposits from water can build up over time, affecting performance. Descale your coffee maker regularly, especially in areas with hard water.

  a. Prepare a descaling solution: Mix white vinegar and water in a 1:2 ratio (e.g., 1 part vinegar to 2 parts water). Fill the water reservoir with this solution up to the MAX level.
  b. Place the empty thermal carafe on the warming plate.
  c. Run a full brewing cycle with the descaling solution.

d. After the cycle, turn off the coffee maker and let the solution sit in the carafe for 15-30 minutes.

e. Discard the solution. Fill the reservoir with fresh, cold water and run 2-3 full brewing cycles to rinse thoroughly.

Troubleshooting

Problem	Possible Cause	Solution
Coffee does not brew.	Not plugged in. Power outage. Water reservoir empty. Programmable timer not set correctly.	Ensure the coffee maker is securely plugged into a working outlet. Check your household's power supply. Fill the water reservoir with water. Verify the timer settings or press the ON/OFF button for immediate brewing.
Coffee tastes weak or too strong.	Incorrect coffee-to-water ratio. Coffee grounds too coarse/fine.	Adjust the amount of coffee grounds to water. Use medium-ground coffee for optimal results.
Coffee overflows from filter basket.	Too much coffee grounds. Filter basket clogged. Carafe not properly placed.	Reduce the amount of coffee grounds. Clean the permanent filter and filter basket thoroughly. Ensure the carafe is fully seated on the warming plate.
Carafe leaks when pouring.	Lid not properly secured. Pouring too quickly.	Ensure the carafe lid is securely twisted or snapped into place. Pour coffee slowly and steadily.

Specifications

Feature	Detail
Brand	Aigostar
Model	Bonnie
ASIN	B0BV8XLJ37
Capacity	1.2 Liters (approx. 10 cups)
Power	800 Watts
Dimensions (L x W x H)	Approx. 25.4 x 19.7 x 36.6 cm (from package dimensions)
Weight	2.31 Kilograms
Interface	LCD Touch Screen
Timer	24-hour programmable
Carafe Type	Thermal (Double-layer Stainless Steel)
Filter Type	Permanent, removable stainless steel



Image: Diagram showing the approximate dimensions of the Aigostar Bonnie coffee maker.

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official Aigostar website. Keep your purchase receipt as proof of purchase for any warranty claims.

If you encounter any issues not covered in this manual or require further assistance, please contact Aigostar customer support. Contact details can typically be found on the manufacturer's website or on the product packaging.

© 2023 Aigostar. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question