LA SOMMELIERE LS512ZBLACK

LA SOMMELIERE LS51.2ZBLACK Dual Zone Wine Cooler Instruction Manual

Model: LS51.2ZBLACK

Important Safety Information

- Read all instructions before using the appliance.
- This appliance is intended for household use only.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Ensure proper grounding.
- Keep ventilation openings clear of obstruction.
- Do not damage the refrigerant circuit.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not use electrical appliances inside the storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the appliance before cleaning or performing maintenance.
- Keep children away from packaging materials.
- Do not allow children to play with the appliance.

Setup and Installation

Unpacking

Carefully remove all packaging materials. Inspect the wine cooler for any damage. Keep packaging materials for future transport if needed.

Placement

Place the wine cooler on a flat, stable surface. Ensure there is adequate ventilation around the unit. Maintain a minimum clearance of 10 cm (4 inches) from walls and other appliances to allow for proper air circulation.

The unit is equipped with two adjustable feet at the front and two wheels at the rear for easy positioning and leveling.

Adjust the front feet to ensure the appliance is perfectly level.



Image: The wine cooler positioned in a living room, demonstrating suitable placement with surrounding furniture.

Initial Cleaning

Before first use, clean the interior and exterior of the wine cooler with a soft cloth and mild detergent. Rinse with clean water and dry thoroughly.

Power Connection

Connect the appliance to a properly grounded electrical outlet (Type E – 2 pins, France). Ensure the voltage matches the appliance's requirements (240 Volts). Avoid using extension cords.

Initial Startup

After plugging in, allow the wine cooler to stand for at least 2-4 hours before loading bottles. This allows the refrigerant to settle. The unit will then begin to cool to the default temperature settings.

Operating Instructions

Control Panel

The digital control panel is integrated into the door, allowing temperature adjustments without opening the door. This helps maintain stable internal temperatures.



Image: Detail of the digital control panel located on the top of the wine cooler door.

Temperature Zones

This wine cooler features two independent temperature zones:

- **Upper Zone:** Adjustable from 5°C to 12°C (capacity for 26 bottles). Ideal for white wines and rosés.
- **Lower Zone:** Adjustable from 12°C to 18°C (capacity for 24 bottles). Ideal for red wines.

Use the up/down arrows on the control panel to set the desired temperature for each zone.



Image: Interior of the wine cooler displaying the separation between the upper (5-12°C) and lower (12-18°C) temperature zones, with bottles stored on wooden shelves.

LED Interior Lighting

The white LED interior lighting enhances the presentation of your bottles. It can be switched on or off via the control panel.

Child Safety Lock

The control panel includes a child safety lock feature to prevent accidental changes to settings. Refer to the specific instructions in the full manual for activation and deactivation.

Shelving

The wine cooler comes with 4 wooden shelves (3 fixed, 1 half-shelf) for flexible and aesthetic storage of your wine bottles. The anti-vibration system ensures stable and respectful wine preservation.



Image: The wine cooler interior with its wooden shelves, demonstrating the storage configuration.

Humidity Regulation

The appliance maintains regulated humidity levels (50-80%) to replicate natural cellar conditions, protecting corks and preserving wine quality.

Maintenance and Care

Cleaning the Interior

Regularly clean the interior with a solution of mild detergent and warm water. Avoid abrasive cleaners or solvents. Remove shelves and clean them separately. Ensure the interior is dry before replacing bottles.

Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. For the glass door, use a glass cleaner. Do not spray water directly onto the control panel or electrical components.

Automatic Defrosting

The wine cooler features an automatic defrosting system. Frost buildup will melt and drain into an evaporation tray at the back of the unit. Ensure the drain hole is not blocked.

Power Outage

In case of a power outage, keep the door closed to maintain the internal temperature for as long as possible. The unit will resume operation with previous settings once power is restored.

Long-Term Storage / Moving

If the appliance will not be used for an extended period, unplug it, empty all bottles, clean the interior, and leave the door slightly ajar to prevent odors and mold growth. When moving, secure the door and shelves, and transport the unit in an upright position.

Troubleshooting Guide

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate.	No power supply; power cord not plugged in; circuit breaker tripped.	Check power connection, wall outlet, and circuit breaker.
Temperature is not cold enough.	Temperature setting is too high; door not closed properly; excessive door opening; poor ventilation; too many bottles loaded.	Adjust temperature setting; ensure door is sealed; reduce door openings; ensure adequate clearance around the unit; do not overload.
Appliance is noisy.	Unit is not level; contact with wall or other objects; normal compressor operation.	Adjust leveling feet; move unit away from obstructions; some noise from the compressor is normal.
Temperature display error or fluctuating temperatures.	Electronic board malfunction; sensor issue.	Unplug the unit for 15 minutes and plug back in to reset. If the problem persists, contact customer support.
Water on the floor.	Drain hole blocked; evaporation tray overflowing.	Clear the drain hole. Check if the evaporation tray is correctly positioned and not damaged.

Product Specifications

Feature	Detail
Model Name	Cave de mise à température double zone LS51.2ZBLACK 50 Bouteilles
Model Number	LS512ZBLACK
Brand	LA SOMMELIERE
Capacity	50 Bottles / 118 Liters
Dimensions (D x W x H)	57P x 48l x 84H centimeters
Weight	32.9 Kilograms
Upper Zone Temperature Range	5°C - 12°C
Lower Zone Temperature Range	12°C - 18°C
Cooling Method	Compressor
Shelves	4 (3 fixed, 1 half-shelf, wood)
Door Type	Glass door with anti-UV treatment
Defrost System	Automatic
Voltage	240 Volts
Annual Energy Consumption	141 kWh/year
Special Features	Digital control panel, LED lighting, anti-vibration system, humidity regulation (50-80%), child safety lock.

Warranty and Customer Support

Warranty Information

This LA SOMMELIERE wine cooler comes with a **2-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims.

Spare parts are available for a period of **10 years** from the date of purchase.

Customer Support

For technical assistance, warranty claims, or spare parts inquiries, please contact your retailer or the manufacturer's authorized service center. Refer to your purchase documentation for specific contact details.

The seller, Frio Entreprise (Climadiff-Sommelière-FrigeluX), offers specialized customer support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question