Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AK59-00070D

ZdalaMit AK59-00070D Replacement Remote Control User Manual

1. Introduction

This manual provides instructions for the ZdalaMit AK59-00070D replacement remote control, designed for use with specific Samsung Blu-ray Disc Player models. Please read this manual thoroughly before use to ensure proper operation and longevity of your device.

2. Product Overview

The ZdalaMit AK59-00070D is a direct replacement remote control. It requires no programming and is ready for use once batteries are installed. This remote provides full functionality for compatible Samsung Blu-ray Disc Players.





Image 2.1: Front view of the ZdalaMit AK59-00070D replacement remote control, displaying all buttons and their labels. The remote is black with red, white, and colored function buttons.



Image 2.2: Angled view of the ZdalaMit AK59-00070D remote control, showing its ergonomic design and button layout from a side perspective.

3. Setup: Battery Installation

3.1 Required Batteries:

- 2 x 1.5V AAA Alkaline Batteries (not included)

3.2 Installation Steps:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA alkaline batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

Note: Ensure batteries are inserted correctly. Incorrect polarity can prevent the remote from functioning. Always use new, high-quality alkaline batteries for optimal performance.

4. Operating Instructions

4.1 Compatibility:

This remote control is compatible with the following Samsung Blu-ray Disc Player models:

- BD-P2550
- BD-P2500
- BD-P1500
- BDP2550
- BDP2500
- BDP1500
- BD-P2550/XAA
- BD-P2500/XAA
- BD-P1500/XAA

4.2 Basic Operation:

No programming is required for this remote. Once batteries are installed, it is ready for immediate use with your compatible Samsung Blu-ray Disc Player.

Point the remote control directly at the Blu-ray Disc Player's infrared sensor. Ensure there are no obstructions between the remote and the player.

4.3 Key Functions:

- **POWER (Red Button):** Turns the Blu-ray Disc Player on or off.
- **OPEN/CLOSE:** Opens or closes the disc tray.
- **TV POWER (Red Button):** Controls the power of a compatible television (if supported by the remote's universal functions).
- **Number Buttons (0-9):** For direct track selection or inputting numbers.
- **CANCEL:** Cancels current selection or operation.
- **TV INPUT SEL:** Selects input source on a compatible television.
- **Playback Controls (SLOW, PAUSE, STOP, PLAY, Fast Forward, Rewind, Skip Forward, Skip Back):** Controls disc playback.
- **TV VOL (+/-), TV MUTE, TV CH (+/-):** Controls volume, mute, and channel on a compatible television.
- **MENU:** Accesses the main menu of the Blu-ray Disc Player.
- **RETURN:** Returns to the previous screen or menu.
- **Navigation Pad (Up, Down, Left, Right, ENTER):** Navigates through menus and confirms selections.
- **DISC MENU:** Accesses the disc menu.
- **INFO:** Displays information about the current content.
- **EXIT:** Exits the current menu or function.
- **POPUP MENU/TITLE MENU:** Accesses the popup or title menu of the disc.
- **Color Buttons (A, B, C, D):** Used for specific functions as indicated on the disc or player menu.
- **AUDIO:** Selects audio tracks.
- **SUBTITLE:** Selects subtitle options.

- **REPEAT:** Repeats playback.
- **A-B:** Repeats a specific section.
- **MARKER:** Sets markers during playback.
- **BONUSVIEW:** Activates BonusView features (if available on disc).

5. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, solvents, or abrasive materials, as these can damage the surface or internal components.
- **Battery Care:** Remove batteries if the remote will not be used for an extended period (e.g., more than one month) to prevent potential battery leakage, which can damage the remote. Replace old batteries promptly when the remote's performance declines.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, high humidity, and extreme temperatures. Avoid dropping the remote or exposing it to strong impacts.

6. Troubleshooting

- **Remote not responding:**
  - Check battery installation. Ensure batteries are inserted with correct polarity (+ and -).
  - Replace old batteries with new AAA alkaline batteries. Low battery power is a common cause of unresponsiveness.
  - Ensure there are no obstructions between the remote and the Blu-ray Disc Player's infrared sensor.
  - Verify the remote is pointed directly at the player's infrared sensor.
- **Specific buttons not working:**
  - This may indicate a faulty button or a need for battery replacement. Try replacing batteries first.
  - Ensure the function you are trying to use is supported by your specific Blu-ray Disc Player model.
- **Remote works intermittently:**
  - This often indicates low battery power. Replace batteries.
  - Ensure a clear line of sight to the Blu-ray Disc Player and that you are within the effective range of the remote.

7. Specifications

- **Model:** AK59-00070D
- **Compatibility:** Samsung Blu-ray Disc Player models BD-P2550, BD-P2500, BD-P1500, BDP2550, BDP2500, BDP1500, BD-P2550/XAA, BD-P2500/XAA, BD-P1500/XAA
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries
- **Dimensions:** Approximately 5 x 1.5 x 0.5 inches (12.7 x 3.8 x 1.3 cm)
- **Weight:** Approximately 2 ounces (56.7 grams) (without batteries)
- **Color:** Black
- **Special Feature:** Ergonomic design

8. Warranty and Support

For warranty information or technical support regarding your ZdalaMit AK59-00070D replacement remote control, please refer to the documentation provided with your original purchase or contact the retailer from whom the product was acquired. This manual does not include specific warranty details or direct support contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BVMN5F6G

More documents and user manuals: **https://manuals.plus/**