Ariete 4626

Ariete 4626 Airy Fryer 6L Air Fryer Instruction Manual

Model: 4626 | Brand: Ariete

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Ariete 4626 Airy Fryer 6L. Please read these instructions carefully before first use and retain them for future reference.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.

- Do not block any ventilation openings.

Product Overview

The Ariete 4626 Airy Fryer 6L is designed for healthy cooking with minimal oil. It features a 6-liter capacity, digital touchscreen, and 8 preset programs.



Image 1: Front view of the Ariete 4626 Airy Fryer 6L, showcasing the digital display and transparent basket window.



Image 2: Angled view of the Ariete 4626 Airy Fryer 6L, highlighting its compact design and digital control panel.

Components:

- Main Unit with Digital Touchscreen
- Removable Frying Basket (6-liter capacity)

- Crisper Plate/Grill
- Power Cord

Setup

Unpacking:

1. Carefully remove all packaging materials from the appliance.
2. Check for any damage during transit. If damaged, do not use and contact customer support.
3. Remove any stickers or labels from the appliance.

First Use Cleaning:

1. Wash the frying basket and crisper plate with hot water, dish soap, and a non-abrasive sponge.
2. Wipe the inside and outside of the appliance with a damp cloth.
3. Ensure all parts are completely dry before use.

Placement:

- Place the air fryer on a stable, horizontal, and heat-resistant surface.
- Ensure there is at least 10 cm (4 inches) of free space at the back and sides of the appliance, and above it, to allow for proper air circulation.
- Do not place the appliance against a wall or other appliances.

Operating Instructions

General Operation:

1. Plug the appliance into a grounded wall outlet.
2. Carefully pull the frying basket out of the air fryer.
3. Place the crisper plate into the basket.
4. Place the ingredients into the frying basket. Do not exceed the MAX fill line.
5. Slide the frying basket back into the air fryer.
6. Press the power button to turn on the appliance.
7. Select a preset program or manually set the temperature and time using the touchscreen controls.
8. Press the start button to begin cooking.



Image 3: The frying basket partially removed, illustrating the hot air circulation system within the appliance for even cooking.

Using Preset Programs:

The Ariete 4626 features 8 preset programs for common dishes. Simply select the desired program from the touchscreen, and the appliance will automatically set the optimal temperature and time.

Manual Settings:

- **Temperature:** Adjust temperature up to 200°C (392°F) using the temperature control buttons.
- **Time:** Set the cooking time up to 60 minutes using the timer control buttons.

Shaking Ingredients:

Some ingredients require shaking halfway through the preparation time to ensure even cooking. The appliance may emit a beep to remind you to shake the basket. To shake, pull the basket out, shake it gently, and then slide it back in. The cooking process will resume automatically.



Image 4: A hand adding a small amount of oil to fries in the air fryer basket, demonstrating the minimal oil requirement.

Monitoring Cooking:

The transparent basket allows for visual monitoring of the cooking process without opening the basket, preserving heat and cooking efficiency.



Image 5: Cooked fries visible through the transparent window of the air fryer basket, illustrating the monitoring feature.

Finishing Cooking:

When the cooking time is complete, the appliance will beep. Carefully pull out the basket and transfer the cooked food to a plate. Use heat-resistant tongs.

Maintenance and Cleaning

Cleaning After Each Use:

1. Unplug the appliance and allow it to cool down completely before cleaning.
2. Wipe the exterior of the appliance with a damp cloth.
3. Clean the frying basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. These parts are also dishwasher safe.
4. Clean the inside of the appliance with a damp cloth.
5. Ensure all parts are thoroughly dry before storing or next use.

Storage:

Store the appliance in a cool, dry place, away from direct sunlight and moisture. Ensure the power cord is neatly wrapped.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance not plugged in. Power outlet not functioning. Basket not inserted correctly.	Ensure the power plug is securely inserted into a grounded wall outlet. Check the power outlet by plugging in another appliance. Push the frying basket completely into the appliance.
Food is not cooked evenly.	Too much food in the basket. Food not shaken during cooking.	Reduce the amount of food per batch. Shake the basket halfway through cooking for even results.
White smoke comes from the appliance.	Fat residues from previous use. Fatty ingredients being cooked.	Clean the basket and crisper plate thoroughly after each use. Remove excess oil from ingredients before air frying.
Appliance smells like plastic.	New appliance odor.	This is normal for first few uses. Ensure good ventilation. The smell will dissipate.

Specifications

- **Model:** Ariete 4626
- **Power:** 1300 W
- **Voltage:** 230 V
- **Capacity:** 6 Liters (Frying capacity: up to 2.5 kg)
- **Temperature Range:** Up to 200°C
- **Dimensions:** 35 x 23 x 33 cm (L x W x H)
- **Weight:** 4 kg
- **Material:** Plastic
- **Features:** 8 Preset Programs, Digital Touchscreen, Transparent Basket, Automatic Shut-off, Programmable

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Ariete website. Keep your proof of purchase for any warranty claims.
Manufacturer: Ariete
Website: www.ariete.net (Example link, actual link may vary by region)

© 2025 Ariete. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question