Xiaomi L55M7-Q2EU

Xiaomi Q2 55-inch 4K LED TV User Manual

Model: L55M7-Q2EU

Introduction

This user manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your Xiaomi Q2 55-inch 4K LED TV (Model L55M7-Q2EU). Please read this manual thoroughly before using your television to ensure proper functionality and safety. Keep this manual for future reference.

Important Safety Information

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and injury. This includes, but is not limited to:

- Do not expose the TV to rain or moisture.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the TV.
- Use only the power cord supplied with the TV.
- Keep the TV away from direct sunlight and heat sources.
- Position the TV on a stable, level surface or mount it securely.

Setup Guide

1. Unpacking

Carefully remove the TV and all accessories from the packaging. Retain the packaging materials for potential future transport or servicing.



Figure 1: Front view of the Xiaomi Q2 55-inch 4K LED TV. This image shows the front of the Xiaomi Q2 55-inch 4K LED TV, featuring a slim bezel design and two metallic stand feet. The screen displays a colorful, high-resolution abstract image.

2. Stand Installation (Optional)

If you are not wall-mounting the TV, attach the included stand feet. Place the TV face down on a soft, clean surface to prevent screen damage. Align each stand foot with the corresponding screw holes on the bottom of the TV and secure them using the provided screws. Ensure the stands are firmly attached before placing the TV upright.

3. Wall Mounting (Optional)

For wall mounting, use a VESA-compatible wall mount kit (sold separately) that matches the TV's VESA pattern. Refer to the wall mount kit's instructions for installation. It is highly recommended to seek professional assistance for wall mounting to ensure safety and proper installation.

4. Connecting Peripherals

Connect your external devices (e.g., cable box, Blu-ray player, gaming console) to the appropriate ports on the TV. Common connection types include HDMI, USB, and optical audio. Refer to the port labels on the back of your TV.

5. Initial Power On and Setup

1. Connect the power cord to the TV and then to a power outlet.
2. Press the power button on the TV or the remote control to turn on the TV.
3. Follow the on-screen instructions to complete the initial setup, which typically includes language selection, network connection (Wi-Fi), Google account sign-in, and channel scanning.

Operating Instructions

Remote Control Overview

The remote control allows you to navigate the TV's features. Common buttons include:

- **Power Button:** Turns the TV on or off.
- **Input/Source:** Selects the input source (HDMI 1, HDMI 2, TV, etc.).
- **Navigation Buttons (Up/Down/Left/Right) and OK:** Used to navigate menus and confirm selections.

- **Back/Return:** Returns to the previous screen or menu.
- **Home:** Accesses the Google TV home screen.
- **Volume Up/Down:** Adjusts the volume level.
- **Channel Up/Down:** Changes TV channels.
- **Mute:** Mutes or unmutes the sound.
- **Google Assistant:** Activates voice control.

Basic TV Functions

- **Power On/Off:** Press the Power button on the remote or TV.
- **Selecting Input Source:** Press the Input/Source button on the remote and select the desired input (e.g., HDMI 1 for a game console).
- **Navigating Google TV:** Use the navigation buttons to browse apps, content, and settings on the Google TV home screen.
- **Adjusting Picture Settings:** Go to Settings > Display & Sound > Picture to adjust brightness, contrast, color, and other display options.
- **Adjusting Sound Settings:** Go to Settings > Display & Sound > Sound to adjust volume, sound mode, and other audio options.
- **Connecting to Wi-Fi:** Go to Settings > Network & Internet and select your Wi-Fi network to connect.

Maintenance

Cleaning the Screen

Before cleaning, unplug the TV from the power outlet. Use a soft, lint-free cloth, slightly dampened with water or a specialized screen cleaner. Do not spray cleaner directly onto the screen. Wipe gently to avoid scratching.

Cleaning the TV Body

Use a soft, dry cloth to wipe dust from the TV's frame and back. Avoid using abrasive cleaners or solvents that could damage the finish.

Software Updates

Ensure your TV is connected to the internet to receive automatic software updates. You can also manually check for updates via Settings > System > About > System update.

Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions before contacting support.

- **No Power:**
  - Check if the power cord is securely plugged into both the TV and the power outlet.
  - Ensure the power outlet is working by testing it with another device.
  - Try pressing the power button on the TV itself, not just the remote.
- **No Picture, But Sound is Present:**
  - Verify the correct input source is selected (e.g., HDMI 1).
  - Check the cable connections between the TV and the external device.
  - Try restarting the external device.
- **No Sound, But Picture is Present:**
  - Check the volume level and ensure the TV is not muted.
  - Verify audio cable connections if using external speakers.

- Check sound settings in the TV menu.

- **Remote Control Not Working:**
  - Replace the batteries in the remote control.
  - Ensure there are no obstructions between the remote and the TV's IR sensor.
  - If it's a Bluetooth remote, try re-pairing it (refer to TV settings for pairing instructions).
- **Network Connection Issues:**
  - Restart your Wi-Fi router.
  - Check if other devices can connect to the same network.
  - Go to TV Settings > Network & Internet and try reconnecting or forgetting and re-adding the network.

Specifications

Feature	Detail
Brand	Xiaomi
Model Number	L55M7-Q2EU
Screen Size	55 Inches
Display Technology	4K LED (UHD)
Operating System	Google TV
Connectivity	Wi-Fi, HDMI, USB (specific port count not provided)
ASIN	B0BVZWJ1DD
Release Date on Amazon.com.be	February 16, 2023

Note: Specifications are subject to change without notice. For the most up-to-date information, please refer to the official Xiaomi website.

Warranty and Support

Your Xiaomi Q2 55-inch 4K LED TV is covered by a limited warranty. The terms and conditions of the warranty may vary by region and retailer. Please refer to the warranty card included with your product or visit the official Xiaomi website for detailed warranty information specific to your purchase location.
For technical support, service requests, or further assistance, please visit the official Xiaomi support website or contact their customer service hotline. Have your model number (L55M7-Q2EU) and purchase information ready when seeking support.
Official Xiaomi Website: www.mi.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question