BCXY CS-WKC210SL

BCXY CS-WKC210SL Lithium-ion Battery Pack Instruction Manual

1. Introduction

This instruction manual provides essential information for the safe and effective use, installation, and maintenance of your BCXY CS-WKC210SL Lithium-ion Battery Pack. Please read this manual thoroughly before using the product and retain it for future reference.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in fire, electric shock, injury, or damage to the product or property.

- **WARRANTY VOID IF LABEL IS REMOVED.**
- **DO NOT ATTEMPT TO DISASSEMBLE, OPEN, OR SERVICE THE BATTERY PACK.**
- Replace only with the battery pack designated for this product (C210AEBATT).
- Do not crush, puncture, short external contacts, or dispose of in fire or water.
- Do not store above 60°C (140°F).
- Keep the battery away from children and pets.
- If the battery shows signs of damage, swelling, or leakage, discontinue use immediately and dispose of it properly.
- **TO REDUCE RISK OF FIRE OR BURNS, READ INSTRUCTIONS IN OPERATING GUIDE BEFORE USING THE BATTERY.**

3. Product Overview

The BCXY CS-WKC210SL is a high-quality Lithium-ion battery pack designed as a replacement for compatible devices. It offers reliable power and is manufactured to meet exact specifications for safe and durable use.

Key Features:

- Exact specifications as the original battery.

- Strict detection and testing for safety and durability.
- Protection against overcharge, over discharge, over voltage, and short circuit.
- Certifications: ISO9001, RoHS, CE, UN38.3, and MSDS.

Compatible Models:

- C210 Life



Figure 1: BCXY CS-WKC210SL Lithium-ion Battery Pack. An image of the BCXY CS-WKC210SL Lithium-ion Battery Pack, showing its compact rectangular shape and the label with model number, part number, rating, and safety warnings.

4. Setup and Initial Use

Upon receiving your new battery pack, it is crucial to perform an initial full charge.

Initial Charging:

1. **NEW BATTERY PACK MUST BE FULLY CHARGED BEFORE USE.**
2. Insert the battery pack into your compatible device or a dedicated charger, ensuring correct orientation (refer to 'Insert this direction' marking on the battery, if present, and your device's manual).
3. Connect the device or charger to a suitable power source.
4. Allow the battery to charge completely until the charging indicator on your device or charger signals a full charge.
5. For optimal performance, it is recommended to fully discharge and recharge the battery 2-3 times after the initial charge.

5. Operating Instructions

Once fully charged, the battery pack is ready for use in your compatible device.

General Usage:

- Ensure the battery is securely installed in your device. The battery has a directional arrow indicating 'Insert this direction'.
- Use the device as per its original operating instructions.
- Monitor the device's battery indicator to avoid complete discharge, which can reduce battery lifespan.
- Recharge the battery when the device indicates low power.

6. Maintenance

Proper maintenance extends the life and performance of your battery pack.

Charging Practices:

- Always use the charger specified by your device manufacturer.
- Avoid overcharging; disconnect the charger once the battery is full.
- Do not leave the battery on charge for extended periods if not in use.

Storage:

- If storing the battery for an extended period, charge it to approximately 50-70% capacity.
- Store in a cool, dry place, away from direct sunlight and extreme temperatures.
- Do not store above 60°C (140°F).
- Periodically check the battery during long-term storage and recharge to 50-70% if necessary.

Cleaning:

- Clean the battery contacts with a dry, clean cloth if they appear dirty.
- Do not use liquid cleaners or solvents.

7. Troubleshooting

If you encounter issues with your battery pack, consider the following common solutions:

- **Battery not charging:** Ensure the battery is correctly inserted and the charger is properly connected to a power source. Check for any visible damage to the battery or charger.
- **Short operating time:** The battery may not be fully charged, or its capacity might be reduced due to age or improper charging cycles. Ensure full charges and consider replacing if performance significantly degrades.
- **Device not powering on:** Verify the battery is correctly installed and charged. If the issue persists, the problem might be with the device itself.

If these steps do not resolve the issue, please refer to the Warranty and Support section for further assistance.

8. Specifications

Model Number	CS-WKC210SL
Part Number	C210AEBATT
Battery Type	Lithium-ion Battery Pack
Voltage	3.8V
Capacity	2300mAh
Watt-hours (Wh)	8.74Wh
Limited Charge Voltage	4.35V ± 0.05V
Standard	GB 31241-2014

Dimensions	77.0 x 59.9 x 4.1mm (3.03 x 2.36 x 0.16 inches)
Weight	94.0g (3.32 ounces)
Certifications	ISO9001, RoHS, CE, UN38.3, MSDS
Manufacturer	ShenZhen HENZENS Technology Co., Limited (Brand: BCXY)

9. Warranty and Support

The BCXY CS-WKC210SL battery pack is manufactured with quality assurance certifications including CE and ISO9001. Please note that the **WARRANTY IS VOID IF THE LABEL IS REMOVED**from the battery pack.
For any questions, concerns, or support regarding your BCXY battery pack, please contact your original point of purchase or the BCXY customer service. When contacting support, please provide your product model number (CS-WKC210SL) and any relevant purchase details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question