Bajaj ICX 190TS

Bajaj ICX 190TS Induction Cooktop User Manual

Model: ICX 190TS | Power: 1900W

1. Introduction

Thank you for choosing the Bajaj ICX 190TS Induction Cooktop. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before use and retain them for future reference.
The Bajaj ICX 190TS is designed for modern kitchens, offering efficient and precise cooking with its 1900W power, digital display, and feather-touch control panel. It features auto pan detection and a range of preset cooking functions to simplify your culinary tasks.

2. Important Safety Instructions

To prevent injury or damage, always observe basic safety precautions when using electrical appliances. This includes, but is not limited to, the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs. The glass surface remains hot after cooking.
- To protect against electrical shock, do not immerse the cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- Ensure proper ventilation around the cooktop during operation.
- Use only induction-compatible cookware.



Image: Top view of the Bajaj ICX 190TS Induction Cooktop, showing the glass surface and control panel. A warning notice about the hot glass surface after cooking is visible.

3. Product Overview

3.1 Components

The Bajaj ICX 190TS Induction Cooktop consists of the following main components:

- **Glass Cooking Surface:** The primary cooking area where induction-compatible cookware is placed.
- **Control Panel:** Located at the front, featuring feather-touch buttons and a digital display for operation.
- **Ventilation Openings:** Located on the sides and bottom to ensure proper airflow for cooling.
- **Power Cord:** For connecting the cooktop to an electrical outlet.



Image: Front view of the Bajaj ICX 190TS Induction Cooktop, highlighting its sleek design and control panel.

3.2 Control Panel Functions

The feather-touch control panel allows for easy selection of cooking modes and adjustments. Refer to the image below for button layout:



Image: Angled close-up view of the control panel on the Bajaj ICX 190TS Induction Cooktop, showing individual buttons and the digital display.

- **ON/OFF Button:** Powers the cooktop on or off.
- **Digital Display:** Shows power level, temperature, timer, or error codes.
- **Timer Button:** Activates and adjusts the cooking timer.
- **'-' and '+' Buttons:** Adjust power levels, temperature, or timer settings.
- **Keep Warm Button:** Maintains food at a warm temperature.
- **Manual Button:** Allows for manual adjustment of power/temperature.
- **Preset Menu Buttons:** Dedicated buttons for specific cooking functions:
  - Curry
  - Fry
  - Idli
  - Roti
  - Milk Tea
  - Boil
  - Cook (General cooking)

4. Setup and Installation

4.1 Unpacking

Carefully remove the cooktop from its packaging. Check for any damage during transit. Ensure all included components are present:

- Bajaj ICX 190TS Induction Cooktop (1N)
- Instruction Manual (1N)

- Warranty Card (1N)

4.2 Placement

- Place the cooktop on a flat, stable, and heat-resistant surface.
- Ensure there is adequate space around the cooktop for ventilation (at least 10-15 cm from walls or other appliances). Do not block the air vents.
- Keep the cooktop away from water sources and direct sunlight.

4.3 Power Connection

- Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the appliance.
- Avoid using extension cords if possible. If an extension cord is necessary, ensure it is rated for the appliance's wattage.

5. Operating Instructions

5.1 Suitable Cookware

The Bajaj ICX 190TS Induction Cooktop requires induction-compatible cookware. This typically includes:

- Cast iron
- Enamelled iron
- Steel
- Stainless steel (magnetic base)
- Pots/pans with a flat bottom and a diameter between 12 cm and 26 cm.

To check if your cookware is compatible, hold a magnet to the bottom. If the magnet sticks, the cookware is suitable for induction.

5.2 Basic Operation

1. Place suitable cookware with food on the center of the glass cooking surface.
2. Press the **ON/OFF** button to power on the cooktop. The digital display will light up.
3. Select your desired cooking mode:
    - **Manual Mode:** Press the **Manual** button. Use the **'+'** and **'-'** buttons to adjust the power level or temperature. The display will show the selected setting.
    - **Preset Menu:** Press one of the dedicated preset buttons (e.g.,**Curry**, **Fry**, **Boil**). The cooktop will automatically set the appropriate power and temperature for that function.
4. The cooktop will begin heating. The auto pan detection feature ensures heating only occurs when compatible cookware is present.
5. To stop cooking, press the **ON/OFF** button. The cooktop will turn off, and the display may show "H" indicating the surface is still hot.

5.3 Timer Function

1. While cooking, press the **Timer** button. The display will show a default time or flash.
2. Use the **'+'** and **'-'** buttons to set the desired cooking time.

3. Once the time is set, the display will revert to showing the power/temperature, and the timer will count down.
4. When the timer expires, the cooktop will automatically turn off and emit an audible signal.

5.4 Keep Warm Function

After cooking, you can use the **Keep Warm** function to maintain your food at a serving temperature.

1. With the cooktop on and food in suitable cookware, press the**Keep Warm** button.
2. The cooktop will switch to a low power setting to keep the food warm.
3. Press **ON/OFF** to exit the Keep Warm function.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Bajaj ICX 190TS Induction Cooktop.

6.1 Cleaning the Cooktop

1. Always unplug the cooktop from the power outlet and allow it to cool completely before cleaning.
2. Wipe the glass cooking surface with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive ceramic hob cleaner.
3. Clean the control panel with a soft, slightly damp cloth. Do not use excessive water or abrasive cleaners.
4. Wipe the exterior housing with a soft, dry cloth.
5. Never immerse the cooktop in water or any other liquid.

6.2 Anti-Roach Gel

The Bajaj ICX 190TS Induction Cooktop comes with an effective repellent to kitchen cockroaches, providing an Anti-roach Gel. Follow the instructions provided with the gel for application to help protect your appliance from pests.

7. Troubleshooting

If you encounter issues with your induction cooktop, refer to the following table for common problems and solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Cooktop does not turn on.	No power supply; Power cord not plugged in; Fuse blown.	Check power outlet; Ensure cord is securely plugged in; Check household fuse/circuit breaker.
No heating, but cooktop is on.	Cookware not induction-compatible; Cookware not centered; Cookware too small/large.	Use induction-compatible cookware; Center cookware on the cooking zone; Use cookware within recommended size (12-26 cm diameter).
Display shows "E0" or other error code.	Internal malfunction; Overheating; Sensor error.	Turn off and unplug the cooktop for 10 minutes, then restart. If error persists, contact customer service.

Problem	Possible Cause	Solution
Fan continues to run after turning off.	Normal operation to cool internal components.	This is normal. The fan will stop automatically once the internal temperature has cooled sufficiently.

8. Specifications

Detailed technical specifications for the Bajaj ICX 190TS Induction Cooktop:



Image: Angled view of the Bajaj ICX 190TS Induction Cooktop with key dimensions (length, width, height) indicated.

Feature	Detail
Brand	Bajaj
Model Number	ICX 190TS (740303)
Installation Type	Counter-Top
Special Features	Electric, Voltage Stabilizer, Auto Pan Detection, Anti-Roach Gel
Burner Type	Induction
Number of Heating Elements	1 (single zone)

Feature	Detail
Colour	Black
Control Console	Feather-Touch Buttons
Wattage	1900 Watts (Max 2000 Watts)
Fuel Type	Electric
Material	Glass
Item Weight	2 kg 30 g
Item Dimensions (LxWxH)	38.7 x 27.2 x 6.5 Centimeters

9. Warranty and Support

9.1 Warranty Information

The Bajaj ICX 190TS Induction Cooktop comes with a **1-year warranty** from the date of purchase. Please refer to the included Warranty Card for detailed terms and conditions. Retain your purchase receipt as proof of purchase for warranty claims.

9.2 Customer Support

For any queries, service requests, or assistance, please contact Bajaj Consumer Care:

- **Telephone:** 022 - 41280000
- **Email:** consumercare@bajajelectrical.com
- **Address:** M/S. BAJAJ ELECTRICALS LIMITED, # 45/47 VEER NARIMAN ROAD, MUMBAI-400001, MAHARASHTRA.

When contacting support, please have your product model number (ICX 190TS or 740303) and purchase details ready.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question