Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wster WS-589

Wster WS-589 Bluetooth Car Speaker User Manual

Model: WS-589

Introduction

Thank you for purchasing the Wster WS-589 Bluetooth Car Speaker. This manual provides detailed instructions for the proper use, setup, and maintenance of your device. Please read this manual thoroughly before operation to ensure optimal performance and longevity of your speaker.
The WS-589 is a versatile portable speaker featuring Bluetooth 5.0 connectivity, FM radio, TF card and USB flash disk support, TWS (True Wireless Stereo) functionality, and hands-free calling. It is designed for convenient audio playback and communication on the go.

Safety Information

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the device yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from water and other liquids. This product is not waterproof.
- Use only the specified charging voltage (5V) and the included USB cable for charging.
- Do not operate the speaker at excessively high volumes for prolonged periods to prevent hearing damage.

Package Contents

Please check the package for the following items:

- Wster WS-589 Bluetooth Car Speaker
- USB Charging Cable
- User Manual (this document)

Product Overview

The Wster WS-589 Bluetooth Car Speaker is designed to resemble a pickup truck, integrating audio functionality within its unique form factor. Below is an image illustrating the product and its packaging.



Image: Wster WS-589 Bluetooth Car Speaker and its packaging. The speaker is green and designed to resemble a pickup truck. The box displays the "WSTER" logo and "MUSIC Car Speaker" text.

While specific button layouts may vary slightly, common controls typically include power on/off, volume up/down, play/pause, mode selection (Bluetooth, FM, TF/USB), and track navigation. Ports usually include a USB charging port, a TF card slot, and a USB-A port for flash drives.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the included USB charging cable to the speaker's charging port and the other end to a 5V USB power adapter (not included) or a computer USB port. The charging indicator light will typically illuminate during charging and turn off or change color when fully charged. A full charge provides approximately 5-6 hours of music playback at comfortable volume.

2. Powering On/Off

Press and hold the Power button (usually marked with● or ▪) for a few seconds to turn the speaker on or off. A voice prompt or indicator light will confirm the status.

Operating Instructions

1. Bluetooth Mode

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light and/or a voice prompt.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "WS-589" or "Wster" from the list of devices.
4. Once paired, the speaker will confirm with a voice prompt or a solid LED light. You can now play audio from your device through the speaker.
5. To disconnect, simply turn off Bluetooth on your device or turn off the speaker.

2. FM Radio Mode

1. Turn on the speaker. Press the "M" (Mode) button to switch to FM Radio mode.
2. Press the Play/Pause button (often marked with ►||) once to automatically scan and save available FM stations (88-108 MHz). This process may take a few minutes.
3. Use the Previous/Next track buttons (◀◀ / ▶▶) to navigate between saved stations.
4. For better reception, ensure the speaker is in an open area.

3. TF Card / USB Flash Disk Mode

1. Insert a TF (MicroSD) card or a USB flash disk containing MP3 audio files into the respective slot/port on the speaker.
2. The speaker will automatically detect the storage device and switch to TF Card or USB mode, beginning playback of the first compatible audio file.
3. Use the Play/Pause button to control playback. Use the Previous/Next track buttons to skip tracks.

4. Hands-Free Calling

When connected via Bluetooth to your smartphone:

- **Answering a Call:** Press the Play/Pause button once to answer an incoming call.
- **Ending a Call:** Press the Play/Pause button once during a call to end it.
- **Rejecting a Call:** Press and hold the Play/Pause button for a few seconds to reject an incoming call.
- **Redialing:** Double-press the Play/Pause button to redial the last number called.

5. TWS (True Wireless Stereo) Function (If Supported)

If you have two WS-589 speakers, you can pair them together for a stereo sound experience:

1. Ensure both speakers are turned off and not connected to any Bluetooth device.
2. Turn on both speakers. They should both be in Bluetooth pairing mode.
3. On one of the speakers (this will be the primary speaker), press and hold the TWS button (or a designated button, refer to specific product markings if available) for a few seconds.
4. The speakers will attempt to pair with each other. Once successfully paired, you will hear a confirmation tone or voice prompt.
5. Now, connect your mobile device to the primary speaker via Bluetooth as described in the "Bluetooth Mode" section. Audio will play through both speakers in stereo.

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the speaker. Do not use abrasive cleaners, alcohol, or chemical solvents.

- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use, to maintain battery health.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode; turn on Bluetooth on device; move device closer (within 10 meters).
No sound.	Volume too low; incorrect mode; paused playback.	Increase volume on speaker and device; switch to correct mode (Bluetooth, TF, USB, FM); press Play.
Poor FM radio reception.	Weak signal; interference.	Relocate the speaker to an area with better signal; perform auto-scan again.
TF card/USB not recognized.	Incorrect file format; card/drive not inserted correctly; corrupted media.	Ensure files are MP3 format; reinsert card/drive; try a different card/drive.

Specifications

Model Name	WS-589 (Music Truck Speaker)
Brand	Wster
Bluetooth Version	5.0
Output Power	10 Watts
Horn Size	1 x 2.5 inch
Impedance	4 Ω
Frequency Response	100-18KHz
Battery Capacity	1800mAh (Built-in Lithium Battery)
Power Supply Voltage	5V
Music Playing Time	5-6 hours (at comfortable volume)
FM Radio Frequency	88-108 MHz
Connectivity	Bluetooth, TF Card, USB, FM Radio
Special Features	TWS, Hands-Free Talking, Super Bass

Product Dimensions	8.5"D x 4"W x 3.75"H
Included Components	USB Cable

Warranty and Support

For warranty information or technical support, please refer to the retailer or point of purchase. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, you may also attempt to contact the manufacturer, Wster, through their official channels if available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question