Ikea IK.604.740.72

Ikea BESTÅ TV Bench Instruction Manual

Model: IK.604.740.72

1. Introduction

Thank you for choosing the Ikea BESTÅ TV Bench. This versatile media unit, measuring 180 x 40 x 38 cm, features a stylish stained oak effect and white finish, designed to complement various home decors. It offers practical storage solutions and smart cable management to keep your entertainment area tidy.

Key features of your BESTÅ TV Bench include:

- **Flexible Placement:** Can be placed on the floor or mounted on the wall to optimize floor space.
- **Adaptable Design:** Compatible with various frame sizes, allowing for a customized solution to fit your television.
- **Integrated Cable Management:** A dedicated cable outlet on the top surface facilitates easy routing of cables.
- **Stability:** Adjustable feet ensure the TV bench remains stable even on uneven floor surfaces.
- **Ample Storage:** Provides significant storage space for media devices and accessories.



Image 1: Overview of the Ikea BESTÅ TV Bench, showcasing its three compartments and stained oak effect finish.

2. Setup

Assembly of the Ikea BESTÅ TV Bench is required. Please refer to the detailed assembly instructions included in the product packaging for step-by-step guidance. Ensure all components are present and follow the instructions carefully to ensure proper construction and stability.

Placement Options:

- **Floor Standing:** Place the TV bench directly on the floor. Use the adjustable feet to level the unit on uneven surfaces.
- **Wall Mounting:** For a floating look and to free up floor space, the TV bench can be mounted to the wall. Ensure you use appropriate wall fasteners for your wall type (sold separately) and follow the specific wall-mounting instructions provided in the assembly manual. Always ensure the wall can support the weight of the unit and its contents.

3. Operating and Features

Cable Management:

The BESTÅ TV Bench is designed with integrated cable management to help keep your cables organized and out of sight. A cable outlet is located on the top surface of the unit, allowing you to easily route power and signal cables from your TV and media devices into the bench's compartments.



Image 2: Close-up of the cable outlet on the top surface, showing cables neatly routed through.

Additional openings and channels are provided at the back of the unit to guide cables between compartments and out to power sources, preventing tangles and dust accumulation.



Image 3: View of the rear cable management system, illustrating how cables can be organized within and behind the unit.

Adjustable Feet:

The TV bench is equipped with adjustable feet. These can be rotated to fine-tune the height of the unit, ensuring it remains stable and level even on slightly uneven floors. Adjust each foot individually until the bench is firm and does not wobble.

4. Maintenance

To ensure the longevity and appearance of your Ikea BESTÅ TV Bench, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a dry cloth. For more stubborn marks, a damp cloth with a mild cleaner can be used, followed immediately by drying with a clean, dry cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong solvents, or chemical polishes, as these can damage the finish.
- **Protect from Moisture:** Avoid prolonged exposure to moisture. Wipe up spills immediately.

- **Sunlight Exposure:** Protect the unit from direct sunlight to prevent fading or discoloration over time.

5. Troubleshooting

If you encounter any issues with your BESTÅ TV Bench, consider the following:

- **Wobbling Unit:** Check if the adjustable feet are properly leveled. Ensure all assembly screws are tightened.
- **Difficulty with Assembly:** Re-read the assembly instructions carefully. Ensure all parts are correctly oriented and connected. Do not force components together.
- **Damaged Parts:** If any parts are damaged during unboxing or assembly, do not proceed with assembly. Contact Ikea customer support for replacement parts.

For further assistance, please refer to the contact information provided in the Warranty and Support section.

6. Specifications

Feature	Detail
Brand	Ikea
Model Number	IK.604.740.72
Dimensions (L x W x H)	180 x 40 x 38 cm
Finish	Stained oak effect, white
Assembly Required	Yes
Shape	Oblong
Care Instructions	Wipe with a dry cloth
Manufacturer	IKEA
Date First Available	January 31, 2023
Spare Parts Availability	Information unavailable

7. Warranty and Support

For information regarding warranty coverage, returns, or to obtain replacement parts, please refer to the documentation provided with your purchase or visit the official Ikea website for your region. Ikea customer service can provide assistance with product-related inquiries, assembly questions, and troubleshooting.

Always retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question