IKEA UTESPELARE

IKEA UTESPELARE Gaming Desk and Chair

INSTRUCTION MANUAL

Introduction

This manual provides essential information for the assembly, operation, and maintenance of your IKEA UTESPELARE Gaming Desk and Chair. Please read these instructions carefully before use to ensure proper functionality and longevity of your product.



Figure 1: The IKEA UTESPELARE Gaming Desk and Chair set, featuring a black desk with a perforated back panel and a black gaming chair with blue accents and a quilted pattern.

Safety Information

For your safety and to prevent damage to the product, observe the following guidelines:

- The chair is equipped with safety castors designed to prevent unexpected rolling when not in use. These castors lock when the chair is not under load.
- Ensure all components are securely fastened before use. Periodically check and tighten any loose screws or fittings.
- Do not stand on the chair or desk.
- Keep small parts away from children during assembly.

Components Included

The IKEA UTESPELARE Gaming Desk and Chair package includes the following main components:

- Gaming Desk (Black, Laminated Engineered Wood top with Alloy Steel frame)
- Gaming Chair (Black, with adjustable safety castors and synchronised seat and back tilt mechanism)
- Cable management net for the desk
- Pair of monitor arms

Setup and Assembly

While the product is listed as "Required Assembly: No" for the desk, some initial setup and minor assembly for the chair or specific features may be necessary. Follow the included graphical instructions for detailed steps.

Desk Setup:

1. Unpack all components and verify against the components list.
2. Place the desk frame in the desired location.
3. Attach the cable management net to the designated points under the desk.
4. Adjust the desk height to your preference. The desk legs feature markings for height adjustment.



Figure 2: Desk leg with height adjustment markings (680mm to 780mm).

5. Utilize the perforated back panel for improved airflow and cable routing.



Figure 3: Perforated back panel for cable management and ventilation.

Chair Assembly:

1. Attach the chair base with safety castors to the gas lift cylinder.



Figure 4: Chair base with safety castors.

2. Mount the seat and backrest assembly onto the gas lift cylinder.
3. Ensure all connections are firm and stable.

Operating Instructions

Desk Operation:

- **Height Adjustment:** The desk features a manual lifting mechanism. Adjust the height by loosening the fasteners on the legs, setting to the desired height (between 68 cm and 78 cm), and re-tightening securely.
- **Cable Management:** Use the integrated cable management net and the perforated back panel to organize and route your cables, keeping your workspace tidy.

Chair Operation:

- **Height Adjustment:** Use the lever located under the seat to adjust the chair's height. Pull the lever up while seated to lower, or pull up while standing to raise.



Figure 5: Chair height adjustment lever and tilt mechanism.

- **Tilt Mechanism:** The chair features a synchronised seat and back tilt mechanism. Use the other lever (if present, or adjust the same lever differently) to recline the backrest and tilt the seat simultaneously for optimal comfort.
- **Safety Castors:** The castors are designed to lock when you stand up, preventing the chair from rolling away. They unlock when you sit down, allowing for movement.
- **Storage Pocket:** A mesh pocket is located on the back of the chair for convenient storage of small items like manuals or magazines.



Figure 6: Mesh storage pocket on the back of the chair.

Maintenance and Care

Proper care will extend the life of your IKEA UTESPELARE Gaming Desk and Chair:

- **Cleaning:** Wipe surfaces with a damp cloth. For best results, follow with a dry cloth to remove any moisture. Avoid abrasive cleaners or harsh chemicals.
- **Inspection:** Periodically inspect all screws and fittings to ensure they are tight. Re-tighten as necessary to maintain stability and safety.
- **Avoid Overloading:** Do not place excessive weight on the desk or chair beyond their intended capacity.

Troubleshooting

If you encounter issues with your product, consider the following common solutions:

- **Desk Wobbles:** Ensure all leg fasteners are securely tightened and the desk is on a level surface. Adjust leg levelers if present.

- **Chair Not Adjusting Height:** Check if the gas lift lever is fully engaged. Ensure there is no obstruction. If the issue persists, the gas lift cylinder may need replacement.
- **Chair Casters Not Rolling Smoothly:** Clean any debris (hair, dust) from the casters. Ensure the safety castors are disengaged when seated.
- **Squeaking Noises:** Apply a small amount of silicone spray to moving parts or joints if squeaking occurs. Avoid oil-based lubricants on plastic components.

Specifications

Feature	Detail
Brand	IKEA
Model Name	UTESPELARE
Model Number	603000
Color	Black
Style	Modern
Desk Top Material	Engineered Wood (Laminated)
Desk Base Material	Alloy Steel
Chair Base Material	Alloy Steel
Desk Height Adjustment	Manual, 68 cm - 78 cm (26.8 inches - 30.7 inches)
Desk Tabletop Thickness	0.75 Inches
Chair Special Feature	Adjustable, Safety Castors, Synchronised Seat and Back Tilt Mechanism
Included Components	Cable management net, pair of monitor arms, chair with adjustable safety castors and synchronised seat and back tilt mechanism
Product Care	Wipe with Damp Cloth, Wipes with Dry
Room Type	Game Recreation Room

Warranty Information

The IKEA UTESPELARE Gaming Desk and Chair comes with a Full Warranty. For specific terms and conditions, please refer to the warranty documentation provided with your purchase or visit the official IKEA website. This warranty covers manufacturing defects and material flaws under normal use.

Customer Support

For further assistance, spare parts, or warranty claims, please contact IKEA customer service. You can find contact information on the official IKEA website or in the documentation included with your product.

IKEA Official Website: www.ikea.com

© 2023 IKEA. All rights reserved. UTESPELARE is a registered trademark of Inter IKEA Systems B.V.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question