Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-RC4390-T-QYSY

ALLIMITY Replacement Remote Control User Manual

Model: QYSY-RC4390-T-QYSY

1. Introduction

This user manual provides detailed instructions for the ALLIMITY Replacement Remote Control, designed to be a direct replacement for various television models from brands such as Telefunken, VANGUARD, AYA, ONWA, QILIVE, and Saba. This remote control offers full functionality without the need for complex programming, ensuring a seamless user experience.

2. Product Overview

The ALLIMITY Replacement Remote Control is an ergonomic device designed for comfortable handling and intuitive operation. It features all the essential buttons found on original remote controls, including power, channel navigation, volume control, number pad, and dedicated buttons for popular streaming services like Netflix and YouTube.





Figure 2.1: Front View of the Remote Control. This image displays the front of the ALLIMITY replacement remote control, highlighting its button layout including the power button, number pad, navigation keys, volume and channel controls, and dedicated Netflix and YouTube buttons.





Figure 2.2: Back View of the Remote Control. This image shows the rear side of the ALLIMITY replacement remote control, featuring the battery compartment cover at the bottom.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control (refer to Figure 2.2).
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: No programming is required. The remote control is ready for use immediately after battery installation for compatible models.

4. Operating Instructions

This replacement remote control is designed to function identically to your original remote for a wide range of compatible TV models. Simply point the remote control towards your television and press the desired button.

4.1 Basic Functions

- **Power Button ( ):** Turns the TV on or off.
- **Number Pad (0-9):** Directly selects channels.
- **Volume Up/Down (V+ / V-):** Adjusts the volume level.
- **Channel Up/Down (P+ / P-):** Changes channels sequentially.
- **Mute ( ):** Mutes or unmutes the TV audio.
- **Navigation Buttons (▲ ▼ ◀ ▶):** Navigates through menus and options.
- **OK Button:** Confirms selections.
- **Back Button:** Returns to the previous screen or menu.
- **Exit Button:** Exits the current menu or application.
- **Netflix / YouTube Buttons:** Direct access to Netflix and YouTube applications (if supported by your TV model).

4.2 Compatible Models

This remote control is compatible with numerous models, including but not limited to:

- D32H289N4CWI, TE43292S31Y2P, L55U405N4CWH, SOMNIA40DSTV, 55DTU652, D32H287M4CWI, D40U297M4CW, D50U293N4CWH, XU43E512, JT-55UBS300, D32H289N4CWD, D43U600M4CWII, D40U298N4CWH, SOMNIA24ESTV, 49DTU652, JT-65UBS300, D55U297N4CWH, D50U600M4CWII, D43U700M4CWH, TFL32SWB17/2, D65U400N4CWH, 32DTH531, XU55E512, D32F289M4CWII, D49U700M4CWH, D43U297N4CWH, 40DTF531, L24H472H4F4CWV-WI
- 49FHD19T2STV, A55UHD4805, V32289SMW, V55289UHD, S3217V, SB55UHD18, SB40FDS19W, SB32HDS19, S55U4K17
- Q.40-822, Q32-822, Q55-182, 32278, Q43-372, Q.55-181 (V3), 24470, Q43-371-2, 30100824, Q24-822, Q32-372

5. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

6. Troubleshooting

If you encounter issues with your remote control, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote is not working.	Dead or incorrectly inserted batteries.	Check battery polarity (+/-). Replace with fresh AAA alkaline batteries.
Remote has limited range or intermittent response.	Weak batteries; Obstruction between remote and TV; Infrared sensor on TV is blocked.	Replace batteries. Ensure clear line of sight to the TV's infrared sensor. Remove any obstructions.
Certain buttons do not work.	Button stuck or damaged; TV model incompatibility for specific advanced functions.	Gently press the button multiple times to dislodge any debris. Verify if the function is supported by your specific TV model.

7. Specifications

Feature	Detail
Brand	ALLIMITY
Item Model Number	QYSY-RC4390-T-QYSY
Product Dimensions	4 x 12 x 0.3 cm
Item Weight	50 g
Color	Black
Special Features	Ergonomic
Max Number of Supported Devices	10 (refers to the number of different TV models it can replace, not simultaneous control)
Manufacturer	ALLIMITYQYSY
Date First Available	15 July 2024

8. Warranty and Support

For any inquiries or support regarding your ALLIMITY Replacement Remote Control, please refer to the seller or retailer

from whom the product was purchased. Specific warranty details may vary by region and seller. Please retain your proof of purchase for any warranty claims.
For general product information or troubleshooting not covered in this manual, you may also visit the ALLIMITY brand's official support channels if available, or contact the customer service of the platform where you made your purchase.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BW982KZN

More documents and user manuals: **https://manuals.plus/**