Zizo SPK-TDT23-OBK

ZIZO Thunder T23 Wireless Bluetooth Speaker

User Manual

Product Overview

The ZIZO Thunder T23 is a portable wireless Bluetooth speaker designed to deliver high-definition audio. It features Bluetooth V5.1 for stable wireless connectivity and True Wireless Pairing (TWS) technology, allowing two Thunder T23 speakers to be linked for an enhanced stereo sound experience. The speaker is equipped with a long-lasting rechargeable battery, making it suitable for both indoor and outdoor use.



Figure 1: Front view of the ZIZO Thunder T23 Wireless Bluetooth Speaker, showcasing its vibrant LED light display and sturdy handle.

Setup

Before initial use, ensure the speaker is fully charged. Use a compatible USB charging cable to connect the speaker to a power source.

1. Charging the Speaker

- Connect the charging cable to the speaker's charging port.

- Connect the other end of the cable to a USB power adapter (e.g., wall charger, computer USB port).
- The charging indicator light will illuminate during charging and typically turn off or change color when fully charged.
- A full charge provides approximately 3 hours of playback at maximum volume or 7 hours at 50% volume.

2. Powering On/Off

- To power on, press and hold the Power button located on the control panel until the indicator light illuminates and an audible prompt is heard.
- To power off, press and hold the Power button again until the indicator light turns off and an audible prompt is heard.

Operating Instructions



Figure 2: Top view of the ZIZO Thunder T23, highlighting the integrated control panel and connectivity ports.

1. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED light).
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "ZIZO Thunder T23" from the list of found devices.
4. Once paired, the speaker will emit an audible confirmation, and the LED light will stop flashing.
5. The Bluetooth connecting range is approximately 10 meters (33 feet) in an open environment.

2. True Wireless Pairing (TWS)

TWS allows you to connect two ZIZO Thunder T23 speakers together for a stereo audio experience.

1. Ensure both Thunder T23 speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker, press and hold the**Mode** button or a dedicated TWS button (if present) until you hear a pairing prompt.
3. The two speakers will automatically connect to each other. Once connected, one speaker will act as the master and the other as the slave.
4. Now, connect your device to the master speaker via Bluetooth as described in the "Bluetooth Pairing" section.

3. Basic Controls

- **Power Button:** Press and hold to power on/off.
- **Play/Pause Button:** Press to play or pause audio playback.
- **Volume Up (+):** Press to increase volume. Press and hold to skip to the next track.
- **Volume Down (-):** Press to decrease volume. Press and hold to skip to the previous track.
- **Mode Button:** Press to switch between Bluetooth, AUX, and USB playback modes.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your ZIZO Thunder T23 speaker.

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the speaker. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Recharge the speaker regularly, even if not in constant use. Do not expose the speaker to temperatures above 60°C (140°F) as this can damage the battery.
- **Water Resistance:** This speaker is not specified as water-resistant. Avoid exposure to water or excessive moisture.

Troubleshooting

If you encounter issues with your ZIZO Thunder T23 speaker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker fully. Press and hold the Power button for a few seconds.
Cannot pair via Bluetooth.	Speaker not in pairing mode; Device Bluetooth off; Speaker too far; Interference.	Ensure speaker is in pairing mode. Turn device Bluetooth off/on. Move speaker closer to device. Avoid strong electromagnetic interference.
No sound or low volume.	Volume too low on speaker or device; Incorrect mode selected.	Increase volume on both speaker and connected device. Press the Mode button to ensure correct input mode (Bluetooth, AUX, USB).
Sound distortion.	Volume too high; Speaker too far from device; Low battery.	Reduce volume. Move speaker closer to the device. Charge the speaker.
True Wireless Stereo (TWS) pairing fails.	Speakers not in TWS pairing mode; One speaker already connected to a device.	Ensure both speakers are disconnected from other devices. Follow TWS pairing instructions carefully.

Specifications

Model Number	SPK-TDT23-OBK
Bluetooth Version	V5.1
Speaker Size	2 inch*2
RMS Power Output	8W, 4Ω
Peak Power Output	16W, 4Ω
Battery Capacity	3.7V, 1500mAh
Play Time	3 hours (max volume), 7 hours (50% volume)
Frequency Response	80HZ-20KHZ
Bluetooth Connecting Range	10m (33 feet)
Product Dimensions	11 x 8.71 x 25.5 cm
Colour	Obsidian Black

Warranty and Support

The ZIZO Thunder T23 Wireless Bluetooth Speaker is backed by a ZIZO one-year warranty.
For detailed information regarding warranty terms and conditions, please visit the official ZIZO website:

zizowireless.com/warranty

For further assistance or technical support, please contact ZIZO customer service through their official channels.

© 2023 ZIZO. All rights reserved.

Model: SPK-TDT23-OBK

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question