K&F CONCEPT A101XS

K&F Concept Trail Camera A101XS User Manual

Model: A101XS

Introduction Components Setup Operation Settings Media Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the K&F Concept Trail Camera A101XS. This manual provides detailed instructions for setting up, operating, and maintaining your trail camera. Designed for wildlife monitoring, hunting, and home security, the A101XS captures high-quality 24MP images and 1296P video with advanced features like no-glow infrared night vision and a rapid 0.2-second trigger speed. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Image 1.1: The K&F Concept A101XS Trail Camera, showcasing its camouflage design and key features like infrared night vision, high-speed trigger, 30 FPS smooth picture, high-definition image, IP66 protection, and P.I.R motion detector.

2. Package Contents and Camera Features

2.1. What's in the Box

- 1 x K&F Concept Trail Camera A101XS
- 1 x 64GB SD Card
- 4 x AA Batteries
- 1 x Mounting Strap
- 1 x USB Cable (for data transfer, inferred from "Wireless Communication Technology: USB")
- 1 x User Manual (this document)




Image 2.1: The trail camera shown with its included accessories: a 64GB SD card, four AA batteries, and a mounting strap.

2.2. Key Features

- **High-Resolution Imaging:** Captures 24 Megapixel (MP) still images and 1296P High Definition (HD) video at 30 frames per second (fps).
- **No-Glow Night Vision:** Equipped with 940nm infrared LEDs for discreet night recording without disturbing wildlife.
- **Fast Trigger Speed:** Detects motion and triggers recording in as little as 0.2 seconds.
- **Wide Detection Angle:** Features a 120° field of view for comprehensive coverage.
- **Durable Design:** IP66 waterproof and shockproof rating ensures reliable operation in various weather conditions (-20°C to 60°C).
- **2.0-inch LCD Screen:** Built-in color LCD for easy menu navigation and media playback.
- **Versatile Recording Modes:** Supports time-lapse, timer, loop recording, and continuous shooting.
- **Data Overlay:** Records time stamps and temperature readings on captured media.

3. Setup Guide

3.1. Battery Installation

1. Open the camera's casing by unlatching the side clips.
2. Locate the battery compartment. Insert the four included AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
3. Close the battery compartment securely.

3.2. SD Card Installation

1. With the camera casing open, locate the SD card slot.
2. Insert the 64GB SD card into the slot with the metal contacts facing the back of the camera until it clicks into place.
3. To remove, press the SD card gently until it pops out.
4. **Note:** Ensure the camera is powered off before inserting or removing the SD card to prevent data corruption.



Image 3.1: The trail camera with its casing open, revealing the 2.0-inch color LCD screen and the battery compartment, ready for battery and SD card insertion.

3.3. Mounting the Camera

1. Select a suitable location for monitoring, such as a tree or post.
2. Thread the included mounting strap through the slots on the back of the camera.
3. Securely fasten the strap around the chosen object, ensuring the camera is stable and pointed towards the desired area. Adjust the angle as needed.

4. Operating Instructions

4.1. Powering On/Off

- To power on, slide the power switch to the "ON" position. The LCD screen will illuminate.
- To power off, slide the power switch to the "OFF" position.

4.2. Mode Selection

The camera typically offers three main modes: Photo, Video, and Photo+Video. Use the mode switch or menu options to select your desired recording mode.

- **Photo Mode:** Captures still images when motion is detected.
- **Video Mode:** Records video clips when motion is detected.
- **Photo+Video Mode:** Captures a still image followed by a video clip when motion is detected.

4.3. Motion Detection and Triggering

The camera utilizes a Passive Infrared (PIR) motion sensor to detect movement. Once motion is detected within its 120° field of view, the camera triggers rapidly.




Image 4.1: A deer in motion, illustrating the camera's fast 0.2-second trigger speed, which allows for capturing quick movements effectively.




Image 4.2: An illustration of the camera's 120-degree wide detection angle, capturing a broad view of deer in a natural habitat.

4.4. Night Vision

The A101XS features no-glow infrared LEDs (940nm) for night vision. This technology allows the camera to capture clear images and videos in low-light or complete darkness without emitting a visible flash that could startle wildlife.



Image 4.3: Two wild boars captured at night, demonstrating the camera's smart night vision capabilities for crisp images in darkness, avoiding overexposure or underexposure.

5. Camera Settings

Access the camera's menu via the 2.0-inch LCD screen to configure various settings. Use the navigation buttons (usually Up, Down, Left, Right, OK/Menu) to browse and select options.

5.1. Date and Time

Set the current date and time to ensure accurate timestamps on your recordings.

5.2. Photo/Video Resolution

- **Photo Resolution:** Select from available options, up to 24MP. Higher resolution results in larger file sizes.
- **Video Resolution:** Select from available options, up to 1296P.

5.3. PIR Sensitivity

Adjust the PIR sensor sensitivity (Low, Medium, High) based on the environment to prevent false triggers or missed

events. High sensitivity is suitable for capturing smaller, distant movements, while Low is for close-range or busy areas.

5.4. Trigger Interval

Set the delay between consecutive triggers. A shorter interval captures more events, but fills the SD card faster.

5.5. Time-Lapse Mode

Configure the camera to take photos at set intervals over a long period, useful for observing slow processes like plant growth or construction.

5.6. Timer Function

Schedule the camera to operate only during specific hours of the day.

5.7. Loop Recording

When enabled, the camera will overwrite the oldest files when the SD card is full, ensuring continuous recording.

5.8. Continuous Shooting

Set the number of photos taken per trigger event (e.g., 1-3 photos).

6. Media Management

6.1. Viewing Photos and Videos on Camera

Switch the camera to "Playback" mode (if available) or navigate through the menu to view captured media directly on the 2.0-inch LCD screen. Use the navigation buttons to scroll through files.

6.2. Transferring Files to a Computer

1. **Using the SD Card:** Remove the SD card from the camera and insert it into a compatible card reader connected to your computer. The card will appear as a removable drive, allowing you to copy files.
2. **Using a USB Cable:** Connect the camera to your computer using a USB cable. The camera may appear as a mass storage device, allowing direct file transfer.

7. Maintenance

7.1. Cleaning

- Wipe the camera's exterior with a soft, damp cloth. Avoid harsh chemicals.
- Gently clean the lens and PIR sensor window with a lens cleaning cloth to ensure clear images and proper detection.

7.2. Battery Care

- Replace batteries when the low battery indicator appears on the LCD.
- Remove batteries if the camera will not be used for an extended period to prevent leakage.

7.3. SD Card Care

- Format the SD card periodically (e.g., monthly) using the camera's menu to maintain optimal performance and prevent data corruption.

- Use high-quality SD cards (Class 10 or higher recommended).

7.4. Environmental Protection

While the camera is IP66 waterproof, avoid submerging it in water. Ensure all latches are securely closed to maintain its weather resistance.



Image 7.1: The trail camera securely mounted on a tree during rainfall, highlighting its IP66 waterproof and weather-resistant design, capable of operating in temperatures from -20°C to 60°C.

8. Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Low or dead batteries; incorrect battery polarity.	Replace batteries with fresh ones; ensure correct polarity.

Problem	Possible Cause	Solution
Camera not triggering or missing events.	PIR sensor obstructed; sensitivity too low; trigger interval too long; camera positioned incorrectly.	Clear sensor area; increase PIR sensitivity; shorten trigger interval; reposition camera for optimal detection.
Poor image/video quality (blurry, dark).	Dirty lens; low light conditions; incorrect resolution settings.	Clean the lens; ensure adequate lighting or proper night vision settings; check resolution settings.
SD card error or "not compatible" message.	SD card not formatted; faulty SD card; incompatible SD card type.	Format the SD card in the camera; try a different, high-quality SD card (Class 10 or higher).
Short battery life.	Frequent triggers; extreme temperatures; low-quality batteries.	Reduce PIR sensitivity or increase trigger interval; use high-quality alkaline or rechargeable batteries; avoid extreme temperatures.

9. Technical Specifications

Feature	Detail
Effective Still Resolution	24 MP
Video Capture Resolution	1296p (30 fps)
Trigger Speed	0.2 seconds
Viewing Angle / Field Of View	120 Degrees
Night Vision Range	65 Feet (Infrared, No Glow)
International Protection Rating	IP66 (Waterproof)
Power Source	Battery Powered (4 x AA Batteries included)
Included Components	Trail camera, 64GB SD card, 4 batteries, mounting strap
Connectivity Technology	Wireless (for Wi-Fi connectivity, though USB is also mentioned for communication)
Wireless Communication Technology	USB (for data transfer) / Wi-Fi (for connectivity protocol)
Display	2.0" LCD Color Screen
Operating Temperature	-20°C to 60°C (inferred from IP66 image)
Specific Uses For Product	Game & Trail, Monitoring, Surveillance, Home Security
Item Weight	1.04 pounds
Package Dimensions	5.91 x 5.67 x 2.64 inches

10. Warranty and Customer Support

K&F Concept products are designed for reliability and performance. For specific warranty details, please refer to the warranty card included with your product or visit the official K&F Concept website.
If you encounter any issues or have questions regarding your K&F Concept Trail Camera A101XS, please contact our customer support team. Contact information can typically be found on our official website or on the product packaging.
Online Resources: For additional support, FAQs, and firmware updates, please visit the K&F Concept official website: K&F CONCEPT Store on Amazon

© 2024 K&F Concept. All rights reserved.