**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**GDOR JUICER2138**

# GDOR Centrifugal Juicer 1300W User Manual

Model: JUICER2138

## 1. Introduction

Thank you for purchasing the GDOR Centrifugal Juicer 1300W. This manual provides important information regarding the safe operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and retain it for future reference.

## 2. Important Safety Instructions

**WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions.**

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is unplugged before assembling, disassembling, or cleaning.
- Keep hands and utensils away from the moving blade during operation.
- Do not operate the appliance with a damaged cord or plug.
- This appliance is for household use only.
- Always ensure the cover is properly locked in place before operating.
- Do not use fingers to push food down the feed chute; always use the food pusher provided.

## 3. Product Overview

### 3.1 Components

1. Food Pusher
2. Transparent Cover
3. Filter Basket (with cutting blade)
4. Juice Collector/Spout
5. Pulp Container
6. Motor Base (with control dial)

7. Safety Locking Arm
8. Juice Jug (not always included, check packaging)
9. Cleaning Brush

### 3.2 Product Diagram

*Image: An exploded view diagram showing all the individual parts of the GDOR Centrifugal Juicer, including the food pusher, cover, filter basket, juice collector, pulp container, and motor base.*

## 4. Setup and Assembly

1. Before first use, wash all removable parts (food pusher, cover, filter basket, juice collector, pulp container) in warm soapy water, rinse thoroughly, and dry. Wipe the motor base with a damp cloth.
2. Place the motor base on a dry, flat, stable surface.
3. Position the pulp container under the pulp ejection spout on the motor base.
4. Place the juice collector onto the motor base, ensuring the spout aligns correctly.
5. Insert the filter basket firmly into the juice collector, ensuring it clicks into place.
6. Place the transparent cover over the filter basket and juice collector, aligning the feed chute with the opening.
7. Lift the safety locking arm and secure it into the grooves on the cover until it locks into place. The juicer will not operate if the locking arm is not secured.
8. Place a juice jug or glass under the juice spout.

*Image: The GDOR Centrifugal Juicer fully assembled and ready for use, showing the motor base, pulp container, juice collector, filter basket, cover, and safety locking arm in position.*

## 5. Operating Instructions

### 5.1 Food Preparation

- Wash all fruits and vegetables thoroughly.
- For fruits with hard pits (e.g., peaches, plums, cherries), remove the pits before juicing.
- Remove large seeds from fruits like melons.
- Peel citrus fruits (oranges, lemons, grapefruits) as their peels can impart a bitter taste.
- The 3.2-inch feed chute can accommodate whole fruits and vegetables like small apples or carrots. For larger items, cut them into smaller pieces that fit easily into the chute.

### 5.2 Juicing Process

1. Ensure the juicer is correctly assembled and the safety locking arm is secured.
2. Plug the power cord into a 120V AC outlet.
3. Turn the control dial to the desired speed setting:
    - **"I" (Low Speed):** For softer fruits and vegetables (e.g., berries, grapes, tomatoes, cucumbers).
    - **"II" (High Speed):** For harder fruits and vegetables (e.g., apples, carrots, celery, beets).
4. With the motor running, gradually feed the prepared fruits and vegetables into the feed chute. Use the food pusher

to gently guide them down. Do not force food into the chute.

5. Juice will flow from the spout into your jug, and pulp will collect in the pulp container.
6. When finished juicing, turn the control dial to "OFF" and unplug the appliance.

### 5.3 Juicing Tips

- For maximum juice extraction, process ingredients slowly and steadily.
- Alternate between soft and hard ingredients to optimize performance.
- Do not continuously operate the juicer for more than 1 minute. Allow it to rest for 2 minutes between cycles to prevent overheating.
- Empty the pulp container and juice jug as needed during extended juicing sessions.

## 6. Maintenance and Cleaning

Clean the juicer immediately after each use to prevent pulp from drying and sticking, which makes cleaning more difficult.

1. Turn the control dial to "OFF" and unplug the juicer from the power outlet.
2. Disengage the safety locking arm and remove the cover.
3. Carefully remove the filter basket, juice collector, pulp container, and food pusher.
4. Rinse all removable parts under running water. Use the provided cleaning brush to remove pulp from the filter mesh.
5. Wash these parts in warm, soapy water. They are also dishwasher safe (top rack recommended).
6. Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
7. Dry all parts thoroughly before reassembling or storing.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Juicer does not turn on. | Not plugged in.<br>Safety locking arm not secured.<br>Overheat protection activated. | Ensure power cord is securely plugged into a working outlet.<br>Ensure the safety locking arm is fully engaged.<br>Unplug and let the unit cool down for at least 30 minutes. |
| Motor stops during operation. | Too much food pushed at once.<br>Filter basket clogged.<br>Overheat protection activated. | Reduce the amount of food.<br>Turn off, unplug, disassemble, clean the filter basket, and reassemble.<br>Unplug and let the unit cool down for at least 30 minutes. |
| Excessive vibration or noise. | Improper assembly.<br>Filter basket not seated correctly. | Turn off, unplug, disassemble, and reassemble all parts correctly.<br>Ensure the filter basket is firmly in place. |
| Pulp is wet. | Filter basket clogged.<br>Too much soft fruit. | Clean the filter basket thoroughly.<br>Process soft fruits more slowly or alternate with harder fruits. |

## 8. Specifications

- **Model:** JUICER2138
- **Power:** 1300W
- **Voltage:** 120V ~ 60Hz
- **Material:** Stainless Steel, BPA-free Plastic
- **Feed Chute Size:** 3.2 inches (approx. 80mm)
- **Special Features:** Portable, Dual Speed Control
- **Product Care:** Dishwasher Safe (removable parts), Hand Wash Only (motor base wipe)

## 9. Warranty and Support

GDOR products are manufactured to high-quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official GDOR website. If you encounter any issues or require technical assistance, please contact GDOR customer support through the contact information provided on our website or your purchase documentation.
For further assistance, please visit: GDOR Official Store on Amazon

© 2023 GDOR. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B0BWJFPVYB**

More documents and user manuals: **https://manuals.plus/**