Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Arktronic 32

Arktronic 32 Inch Digital Picture Frame User Manual

Model: 32

1. Introduction

Thank you for choosing the Arktronic 32 Inch Digital Picture Frame. This device allows you to display your cherished photos and videos with a stunning 1920x1080 Full HD resolution on a matte IPS screen. With Wi-Fi connectivity, remote control operation, and ample storage, sharing and viewing your memories is simple and convenient.

1.1 What's in the Box

Verify that all items are present in the package:

- Arktronic 32 Inch Digital Picture Frame
- Remote Control
- Swivel Wall Mount (VESA Spec 100 x 100mm)
- Screwdriver
- Screws & Wall Anchors
- Power Cord (70.87 inches)
- User Manual Quick Start Guide




Figure 1: Package Contents

2. Setup

2.1 Powering On

1. Connect the power cord to the Type-C port on the back of the frame.
2. Plug the power adapter into a wall outlet. The frame will automatically begin the startup process.



Figure 2: Back Panel Connections

2.2 Connecting to Wi-Fi

1. Upon initial startup, the frame will guide you through language selection. Use the included remote control to navigate.
2. Select your preferred language.
3. The frame will then prompt you to connect to a Wi-Fi network. Select your network and enter the password using the remote control.
4. Ensure the frame is successfully connected to Wi-Fi for full functionality.

2.3 VPhoto App Connection

The VPhoto app is essential for sharing photos and videos to your frame.

1. Download the 'VPhoto' app from the Apple App Store or Google Play Store on your smartphone.
2. Create an account within the app.
3. On your digital picture frame, navigate to **Settings > My Frame** to find the connection code (QR code).
4. Open the VPhoto app on your phone and scan the QR code displayed on the frame to link your device.
5. Once connected, you can invite family and friends to share content by providing them with the connection code.



Figure 3: Connecting via VPhoto App

2.4 Mounting Options

The frame includes a swivel wall mount for flexible placement.

- The included VESA 100x100mm swivel mount allows for both vertical (portrait) and horizontal (landscape) orientations.
- Use the provided screwdriver, screws, and wall anchors to securely install the mount on your wall.
- The frame features an auto-rotate function that automatically adjusts the display orientation when the frame is rotated.



Figure 4: Swivel Wall Mount

3. Operating the Digital Picture Frame

3.1 Displaying Photos and Videos

The Arktronic frame supports various image formats (JPG, GIF, BMP, PNG) and video formats (MPEG1, MPEG2, MPEG4, Xvid, AVI, M-JPEG, H.264.MOV, VOB, MKV, DIVX4, DIVX5).

- **Via VPhoto App/Email:** Upload photos and videos directly from your smartphone or email to the frame using the VPhoto app.
- **Via USB/Micro SD:** Insert a USB flash drive or Micro SD card (up to 64GB, external converter may be required for Micro SD) into the designated ports to play content directly or import to internal storage.




Figure 5: Displaying Art on the Frame

3.2 Internal Storage

The frame comes with 64GB of built-in memory, capable of storing approximately 160,000 photos. You can import and export images or videos between internal storage and external devices.



Figure 6: 64GB Storage Capacity

3.3 Remote Control Functions

The included remote control provides convenient navigation and access to various features:

- **Navigation:** Use arrow keys to move through menus and select options.
- **Playback:** Control slideshows, video playback, and background music.
- **Settings Access:** Adjust brightness, volume, slideshow mode, and other settings.



Figure 7: Remote Control in Use

3.4 Multi-functionality and Customization

The frame offers several features to enhance your viewing experience:

- **Background Music:** Play music during photo slideshows.
- **Sleep Mode:** Schedule the frame to turn off/on automatically.
- **Image Zoom:** Zoom in on photos for detailed viewing.
- **Adjustable Brightness:** Customize display brightness to suit ambient lighting.
- **Slideshow Mode:** Choose from various slideshow transitions and intervals.
- **Playback Order:** Adjust the order in which photos and videos are displayed.
- **Captions:** Display captions at the bottom of photos to add context or stories.
- **Light Sensor:** Automatically adjusts screen brightness based on ambient light.
- **Volume Adjustment:** Control audio output for videos and music.
- **Touch Sounds:** Enable or disable audible feedback for interactions.
- **Language:** Change the system language.
- **Date & Time:** Set or synchronize the frame's date and time.
- **Alarm:** Set alarms directly on the frame.
- **Notification Sound:** Customize notification sounds.

3.5 Auto-Rotate Feature

The frame automatically detects its orientation (portrait or landscape) and adjusts the display accordingly, ensuring your content is always shown correctly.

Your browser does not support the video tag.

Video 1: Demonstrating the Arktronic 32 inch frame's auto-rotate feature and its use as an art display in various home settings.

4. Maintenance

4.1 Cleaning the Screen

To clean the matte display, gently wipe it with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.

4.2 Factory Data Reset

If you encounter persistent issues or wish to clear all user data, you can perform a factory data reset:

1. Navigate to **Settings > Factory Data Reset** using the remote control.
2. Follow the on-screen prompts to confirm the reset. Note that deleting users requires an internet connection.

5. Troubleshooting

If you experience problems with your Arktronic Digital Picture Frame, refer to the following common issues and solutions:

- **No Power:** Ensure the power cord is securely connected to both the frame and a working power outlet. Try a different outlet.
- **No Wi-Fi Connection:** Check your router and ensure it is functioning correctly. Re-enter your Wi-Fi password in the frame's settings. Ensure the frame is within range of your Wi-Fi signal.
- **Cannot Upload Photos/Videos:** Verify the frame is connected to Wi-Fi. Ensure the VPhoto app is correctly linked to your frame. Check the file formats of your content; ensure they are supported.
- **Images Not Displaying Correctly:** Check the image resolution and aspect ratio. The frame supports 1920x1080 FHD. Ensure the auto-rotate feature is enabled if you expect automatic orientation changes.
- **Remote Control Not Responding:** Check the batteries in the remote control (AAA batteries, not included). Ensure there are no obstructions between the remote and the frame's sensor.

For further assistance, consult the 'Help' section within the frame's settings or contact customer support.

6. Specifications

Feature	Detail
Screen Size	32 Inches
Resolution	1920x1080 (FHD)
Display Type	IPS Matte Display
Internal Storage	64GB
Connectivity	Wi-Fi (2.4GHz/5GHz), USB, Micro SD
Supported Image Formats	JPG, GIF, BMP, PNG
Supported Video Formats	MPEG1, MPEG2, MPEG4, Xvid, AVI, M-JPEG, H.264.MOV, VOB, MKV, DIVX4, DIVX5
Product Dimensions	29 x 17 x 0.99 inches
Item Weight	18.76 pounds
Manufacturer	Arktronic

7. Warranty and Support

Arktronic provides the following assurances for your product:

- **30-Day Money Back Commitment:** If you are not satisfied with your purchase, you may return it within 30 days for a full refund.

- **1-Year Worry-Free Warranty:** The product is covered by a 1-year warranty against manufacturing defects.
- **Lifetime Professional Service:** Arktronic offers ongoing professional support for the lifetime of the product.

For technical support or warranty claims, please refer to the contact information provided in the 'Help' or 'About' sections of your frame's settings, or visit the official Arktronic website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BWMKX5QQ

More documents and user manuals: **https://manuals.plus/**