Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY EN2D36H

Instruction Manual for Allimity EN2D36H Replacement Remote Control

Model: EN2D36H

Introduction

This manual provides essential information for the setup, operation, and maintenance of your Allimity EN2D36H replacement remote control, designed for Hisense Smart TVs. This remote is a direct replacement and requires no programming.

The remote control is compatible with various Hisense Smart TV models and features dedicated shortcut buttons for popular streaming applications such as Disney, Prime Video, Pluto TV, PLEX, DEEZER, Peacock, Kid, TUBI, Netflix, VIDAA-TV, and FUBO-TV.

Package Contents

- 1 x Allimity EN2D36H Replacement Remote Control

Note: Batteries and a printed manual are not included in the package.

Setup

Battery Installation

The Allimity EN2D36H remote control requires two (2) AAA alkaline batteries for operation. Please follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Figure 1: Rear view of the remote control with the battery compartment open, illustrating the correct orientation for battery insertion.

Once the batteries are installed, the remote control is ready for immediate use with your compatible Hisense Smart TV. No additional programming or setup is required.

Operating Instructions

The Allimity EN2D36H remote control provides intuitive access to your Hisense Smart TV's functions. Below is a general guide to its key features:





Figure 2: Front view of the Allimity EN2D36H remote control, displaying the layout of all buttons.

Key Functions:

- **Power Button ( )**: Turns the TV on or off.
- **Input Button**: Cycles through available input sources (HDMI, AV, etc.).
- **Navigation Pad (Up, Down, Left, Right, OK)**: Used to navigate menus and select options.
- **Back Button (↶)**: Returns to the previous screen or menu.
- **Exit Button**: Exits the current menu or application.
- **Home Button (⌂)**: Accesses the TV's main smart hub or home screen.
- **Volume Up/Down (VOL +/-)**: Adjusts the audio volume.
- **Channel Up/Down (CH +/-)**: Changes TV channels.
- **Mute Button ( )**: Mutes or unmutes the TV audio.
- **Number Buttons (0-9)**: Directly input channel numbers.
- **Playback Controls**: Includes Play/Pause, Fast Forward, Rewind, Stop, and Skip buttons for media playback.

Dedicated App Buttons:

This remote features 12 dedicated shortcut buttons for quick access to popular streaming services and applications:

- Disney
- Prime Video
- Pluto TV
- PLEX
- DEEZER
- Peacock
- Kid
- TUBI
- Netflix
- VIDAA-TV
- FUBO-TV
- (One more app button is present, but not explicitly named in the product description, typically a generic app launcher or another popular service.)

Simply press the desired app button to launch the corresponding application on your Hisense Smart TV, provided the app is installed and configured on your television.

Maintenance

To ensure the longevity and optimal performance of your remote control, please follow these maintenance guidelines:

- **Cleaning**: Wipe the remote control regularly with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage**: Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops**: While made of durable ABS material, repeated drops can damage internal components or the casing. Handle with care.
- **Liquid Exposure**: Keep the remote control away from liquids. Liquid damage can cause malfunctions and is typically not covered under warranty.

Troubleshooting

If you encounter issues with your Allimity EN2D36H remote control, please refer to the following common troubleshooting steps:

- **Remote Not Responding**:
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and line of sight of the TV.
- **Specific Buttons Not Working**:
  - This could indicate a stuck button or internal damage. Try gently pressing the button multiple times. If the issue persists, consider replacing the remote.
- **App Buttons Not Launching Apps**:
  - Ensure the specific app is installed and updated on your Hisense Smart TV.
  - Verify your TV has an active internet connection.
  - Some app buttons may require initial setup or login within the TV's smart hub.
- **Remote Control Feels Sluggish**:
  - This is often a sign of low battery power. Replace the batteries.

If these steps do not resolve the issue, the remote control may be faulty and require replacement.

Specifications

Model Number	EN2D36H
Brand	ALLIMITY

Compatible Devices	Hisense Smart Televisions
Connectivity Technology	Infrared (IR)
Power Supply	2 x AAA Alkaline Batteries (Not Included)
Product Dimensions	6 x 1.8 x 0.5 inches (approximately)
Item Weight	2 ounces (approximately, without batteries)
Special Feature	No Programming Required

Warranty and Support

Warranty Information

This Allimity EN2D36H replacement remote control comes with a**60-day warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as described under normal use.

The warranty does not cover damage resulting from:

- Accidental damage, misuse, abuse, or neglect.
- Unauthorized repairs or modifications.
- Liquid damage or exposure to extreme temperatures.
- Normal wear and tear.

Customer Support

For warranty claims, technical assistance, or any questions regarding your Allimity EN2D36H remote control, please contact the seller or manufacturer through the platform where the purchase was made. Please have your order details ready when contacting support.

© 2023 ALLIMITY. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BWQPTXKB

More documents and user manuals: **https://manuals.plus/**