TODO DP 2IN1

TODO DP 2IN1 Electric Folding Treadmill User Manual

Model: DP 2IN1

1. Introduction

Thank you for choosing the TODO DP 2IN1 Electric Folding Treadmill. This manual provides essential information for the safe and efficient use, setup, operation, and maintenance of your new fitness equipment. Please read this manual thoroughly before initial use and retain it for future reference.

2. Safety Information

To ensure your safety and prolong the life of your treadmill, please observe the following precautions:

- Always place the treadmill on a flat, stable surface.
- Ensure adequate clear space around the treadmill for safe operation and emergency exits.
- The maximum user weight for this treadmill is 120 kg. Do not exceed this limit.
- Always attach the emergency stop safety clip to your clothing before starting your workout.
- Do not allow children or pets near the treadmill while it is in operation.
- Consult a physician before starting any new exercise program.
- Wear appropriate athletic footwear during use.
- Keep hands and feet clear of all moving parts.
- Unplug the treadmill from the power outlet when not in use or before cleaning and maintenance.

3. Product Features

The TODO DP 2IN1 Electric Folding Treadmill offers versatile functionality for your home fitness needs:

- **Dual Operating Modes:**
  - **Walking Pad Mode:** With the handrail folded, operate as a walking pad at speeds of 1-6 km/h. Ideal for under-desk use or light exercise.
  - **Fitness Treadmill Mode:** With the handrail lifted, use as a traditional treadmill for walking, jogging, or running at speeds of 1-12 km/h.
- **Remote Control:** Conveniently adjust speed and start/stop the treadmill.

- **LCD Display:** Monitor key workout data including speed, training time, distance, calories burned, and steps.
- **Compact and Space-Saving Design:** Easily folds for storage under a sofa or bed, requiring only 12 cm of vertical space. Integrated transport wheels facilitate movement.
- **Running Surface:** Generous 110 x 40 cm running belt provides ample space for comfortable exercise.
- **Joint Protection:** Features a 5-layer running belt designed for noise reduction and cushioning to protect your joints.



Image: The treadmill demonstrating its two modes: a walking pad with handrail folded (1-6 km/h) and a fitness treadmill with handrail unfolded (6-12 km/h).



Image: Illustration of the treadmill's 5-layer running belt for joint protection and noise reduction, with a maximum weight capacity of 120 kg.



Image: The treadmill folded and stored under a sofa, demonstrating its compact, space-saving design that requires only 12 cm of height.

4. Setup Instructions

The TODO DP 2IN1 treadmill comes largely pre-assembled. Follow these steps for quick setup:

1. **Unpack:** Carefully remove the treadmill from its packaging.
2. **Position:** Place the treadmill on a firm, level surface with sufficient clear space around it.
3. **Unfold Handrail (if applicable):** If you intend to use the treadmill in Fitness Treadmill Mode, lift the handrail into its upright position.
4. **Secure Handrail:** Locate the two handrail buttons (usually on the sides of the main rail). Insert and secure these buttons to lock the handrail in place. Ensure it is firmly locked before use.
5. **Connect Power:** Plug the power cord into a grounded electrical outlet.

5. Operating Instructions

Familiarize yourself with the controls and display before beginning your workout.

5.1. Power On/Off

- Ensure the treadmill is plugged in.
- Press the power button on the main rail or the remote control to turn the treadmill on.
- To turn off, press the power button again or use the remote control.

5.2. Using the Remote Control



Image: The remote control for the treadmill, featuring buttons for Start/Stop and Speed adjustment.

- The remote control allows you to start, stop, and adjust the speed of the treadmill.
- Press the 'Start' button to begin the running belt movement.
- Use the 'Speed +' and 'Speed -' buttons to increase or decrease the speed.
- Press the 'Stop' button to halt the running belt.

5.3. Understanding the LCD Display



Image: The LCD monitor showing workout data such as time, distance, calories, and steps. Also visible are safety clips and a phone holder.
The clear LCD display provides real-time feedback on your workout:

- **Speed:** Current speed in km/h.
- **Time:** Duration of your workout.
- **Distance:** Total distance covered during the session.

- **Calories:** Estimated calories burned.
- **Steps:** Number of steps taken.

5.4. Emergency Stop

In case of an emergency or if you need to stop the treadmill immediately, pull the safety clip from its designated slot on the console. The treadmill will stop instantly.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your treadmill.

- **Cleaning:** Wipe down the treadmill surfaces with a damp cloth after each use to remove sweat and dust. Do not use abrasive cleaners.
- **Belt Lubrication:** Periodically check the running belt for proper lubrication. Refer to the separate lubrication instructions (if provided with your unit) or consult customer support for guidance.
- **Belt Tension and Alignment:** Over time, the running belt may require tension adjustment or alignment. If the belt slips or moves off-center, refer to the specific instructions in a detailed service manual or contact customer support.
- **Storage:** When not in use, fold the treadmill and store it in a dry, clean place away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter any issues with your treadmill, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Treadmill does not power on.	Power cord not properly connected; power outlet issue; safety key not in place.	Ensure power cord is securely plugged into a working outlet. Check if the safety key is correctly inserted.
Running belt stops or slows unexpectedly.	Overload (user weight exceeds limit); belt friction; motor overheating.	Ensure user weight is within 120 kg limit. Check for proper belt lubrication. Allow treadmill to cool down.
Display not showing data correctly.	Loose connection; sensor issue.	Check all cable connections. If the problem persists, contact customer support.
Unusual noise during operation.	Loose parts; belt misalignment; motor issue.	Inspect for any loose screws or components. Check belt alignment. If noise continues, discontinue use and contact support.

If the problem persists after attempting these solutions, please contact TODO customer support.

8. Specifications

Detailed specifications for the TODO DP 2IN1 Electric Folding Treadmill:



Image: Dimensional diagram of the treadmill, indicating its handle height (94 cm), running belt (110L x 40W cm), and overall folded/unfolded dimensions.

Feature	Specification
Brand	TODO
Model Name	DP 2IN1
Product Dimensions (Unfolded)	133D x 50W x 94H Centimeters
Product Dimensions (Folded)	142D x 50W x 12H Centimeters (approx.)
Item Weight	24 Kilograms
Material	Alloy Steel (Frame)
Maximum Speed	12 Kilometers per Hour
Minimum Speed (Walking Pad Mode)	1 Kilometers per Hour
Maximum Weight Recommendation	120 Kilograms

Feature	Specification
Running Surface (Deck)	110 cm (Length) x 40 cm (Width)
Display Type	LCD
Power Source	Corded Electric
Motor Horsepower	0.75 Horsepower
Included Components	TODO Treadmill

9. Warranty and Support

TODO provides a **2-year warranty service** for this folding treadmill under normal use conditions. This warranty covers free replacement of accessories from the date of your order.
For warranty claims, technical assistance, or any questions regarding your TODO DP 2IN1 Electric Folding Treadmill, please contact TODO customer support through your purchase platform or the official TODO website. Please have your purchase details and model number (DP 2IN1) ready when contacting support.

© 2026 TODO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question