Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UGREEN 15609

UGREEN 67" Cell Phone Selfie Stick Tripod User Manual

Model: 15609

Introduction

Thank you for choosing the UGREEN 67" Cell Phone Selfie Stick Tripod. This versatile 3-in-1 device functions as an extendable tripod, a selfie stick, and a phone floor stand. It is designed for compatibility with various smartphones, GoPro cameras, and digital cameras, making it ideal for selfies, vlogs, live streaming, group photos, and video conferences. This manual provides essential information for the proper setup, operation, and maintenance of your device.





Image: The UGREEN 67-inch Selfie Stick Tripod, shown fully assembled with a smartphone mounted, alongside its detachable Bluetooth remote control.

Product Components

The UGREEN Selfie Stick Tripod consists of several key components designed for ease of use and versatility.

- **Extendable Pole:** Multi-section telescopic pole for adjustable height.
- **Tripod Base:** Collapsible legs with non-slip foot pads for stability.
- **Phone Clamp:** Securely holds smartphones, adjustable for various sizes.
- **Mount Arm:** Allows for 360° rotation and 190° angle adjustment of the phone clamp.
- **Bluetooth Remote Control:** Detachable wireless remote for capturing photos and videos from a distance.
- **Cold Shoe Port:** Integrated on the mount for attaching accessories like fill lights or microphones.

Setup Instructions

1. **Unfold the Tripod:** Gently pull the tripod legs outwards until they are fully extended and stable. Ensure the non-slip foot pads are firmly on the ground.
2. **Attach the Phone Clamp:**
    - Locate the phone clamp and the main tripod pole.
    - Identify the black screw on the tripod pole and the silver screw on the phone clamp.

- Align the phone clamp with the top of the tripod pole.
- Slide the phone clamp onto the tripod pole and fasten it securely using the screws.
- Ensure the flip lock is engaged to prevent accidental detachment.



Image: Visual guide for attaching the phone clamp to the tripod pole, highlighting the flip lock and screw connections.

3. **Insert Smartphone:** Open the phone clamp and carefully place your smartphone inside, ensuring it is centered and held firmly.
4. **Pair Bluetooth Remote:**
   - Remove the detachable Bluetooth remote control from its storage groove.
   - Turn on the remote control (usually by pressing and holding a button). An indicator light will flash.
   - On your smartphone, go to Bluetooth settings and search for available devices.
   - Select "UGREEN-LP354" (or similar model name) from the list to pair. The indicator light on the remote will stop flashing once paired.



Image: A hand holding the Bluetooth remote control, with a smartphone screen displaying "UGREEN-LP354 Connected" in its Bluetooth settings.

Operating Instructions

1. Using as a Tripod

1. **Adjusting Height:** Unlock the telescopic pole sections by twisting them or releasing the flip locks (depending on the specific design). Extend the pole to your desired height, up to a maximum of 67 inches (170 cm). Secure the sections by twisting or engaging the flip locks.



Image: The tripod shown at four different height levels, illustrating its extendable nature up to 67 inches.

2. **Adjusting Angle:** The mount arm allows for 360° horizontal rotation and 190° vertical flipping. Loosen the

adjustment knob on the mount arm, position your device as desired, and then tighten the knob to secure it.



Image: Graphics demonstrating the 360-degree rotation and 190-degree vertical adjustment capabilities of the phone mount.

3. **Using the Cold Shoe Port:** If you have compatible accessories like a fill light or external microphone, attach them to the cold shoe port on the mount arm for enhanced recording.

2. Using as a Selfie Stick

1. **Convert to Selfie Stick:**
    - Ensure the tripod legs are folded inwards.
    - Rotate the bottom screw to loosen the tripod base from the main pole.
    - Rotate the tripod rotation axis to fully collapse the legs against the pole.
    - The device can now be held as a selfie stick.



Image: Step-by-step visual instructions on converting the tripod into a selfie stick by rotating the bottom screw and the tripod rotation axis.

2. **Capture Photos/Videos:** Use the paired Bluetooth remote control to wirelessly trigger your smartphone's camera shutter. The remote has a range of up to 10 meters (33 feet).

3. Compatibility

The UGREEN Selfie Stick Tripod is compatible with a wide range of devices, including:

- Smartphones (e.g., iPhone 14 Pro Max, Samsung Galaxy S22, Google Pixel 5)
- GoPro cameras
- Digital cameras
- Action cameras



Image: A visual representation of the tripod's compatibility with different devices, including various smartphone models, GoPro, and digital

cameras.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Storage:** When not in use, fold the tripod to its compact size (approximately 19 inches) and store it in a cool, dry place away from direct sunlight.
- **Battery Replacement (Remote):** The Bluetooth remote control uses a CR2430 battery. If the remote stops responding, replace the battery by opening the battery compartment (refer to the remote's specific instructions if available).
- **Avoid Overloading:** Do not exceed the maximum weight limit of 1.1 pounds (approximately 500g) to prevent damage to the tripod and your device.

Troubleshooting

Problem	Possible Cause	Solution
Bluetooth remote not pairing.	• Remote battery is low or dead. • Remote is not in pairing mode. • Bluetooth on phone is off. • Too far from the phone.	• Replace the CR2430 battery. • Press and hold the remote button to enter pairing mode. • Enable Bluetooth on your smartphone. • Ensure the remote is within 10 meters of the phone.
Tripod feels unstable.	• Legs not fully extended or locked. • Uneven surface. • Device too heavy.	• Ensure all telescopic sections and tripod legs are fully extended and locked. • Place the tripod on a flat, stable surface. • Verify your device's weight does not exceed 1.1 pounds (640g).
Phone clamp not holding device securely.	• Clamp not tightened properly. • Device size incompatible.	• Ensure the phone clamp is securely fastened to the tripod and the phone is properly seated. • Check if your device fits within the clamp's adjustable range.

Specifications

Feature	Detail
Brand	UGREEN
Model Number	15609
Material	Aluminium Alloy
Maximum Height	170 cm (67 inches)
Minimum Height (Folded)	48 cm (19 inches)

Feature	Detail
Item Weight	640 Grams
Weight Limit	1.1 Pounds (approx. 500g)
Bluetooth Version	5.0
Bluetooth Remote Range	Up to 10 meters
Remote Battery Type	CR2430 (included)
Rotation Angle	360° (horizontal)
Tilt Angle	190° (vertical)
Compatible Devices	Smartphones, GoPro, Digital Cameras, Action Cameras

Warranty Information

UGREEN products typically come with a standard manufacturer's warranty. Please refer to the warranty card included with your product packaging or visit the official UGREEN website for detailed warranty terms and conditions specific to your region. Keep your purchase receipt as proof of purchase for any warranty claims.

Customer Support

For technical assistance, troubleshooting, or general inquiries regarding your UGREEN 67" Cell Phone Selfie Stick Tripod, please contact UGREEN customer support through their official website or the contact information provided in your product packaging.

- **Online Support:** Visit the official UGREEN website for FAQs, support articles, and contact forms.
- **Email Support:** Refer to your product documentation for the customer service email address.

© 2023 UGREEN. All rights reserved.
This manual is for informational purposes only. UGREEN reserves the right to change product specifications without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BWRSC94N

More documents and user manuals: **https://manuals.plus/**