## Furologee B0BX473XDD

# Furologee TV Stand with Power Outlets and 7 Fabric Drawers

Model: B0BX473XDD

Brand: Furologee

## 1. Introduction

This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your Furologee TV Stand with Power Outlets and 7 Fabric Drawers. Please read this manual thoroughly before beginning assembly or use to ensure safe and correct operation of the product. Keep this manual for future reference.




Image 1.1: Furologee TV Stand in use.

The Furologee TV Stand is designed to provide versatile storage and media support for various rooms, including bedrooms, living rooms, and home offices. It features integrated power outlets and USB ports for convenient device charging, along with seven fabric drawers and two open shelves for organized storage.

Your browser does not support the video tag.

Video 1.1: Overview of the Furologee TV Stand's features and design.

## 2. Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- **Weight Capacity:** Do not exceed the maximum weight limits for the shelves. The top shelf supports up to 100 lbs, and the middle shelf supports up to 66 lbs.
- **Anti-Tip Kit:** Always install the included anti-tip kit to prevent the unit from tipping over, especially in households with children or pets.
- **Electrical Safety:** Ensure the power cord is properly connected to a grounded outlet. Do not overload the

power outlets or USB ports. Keep liquids away from the power strip.

- **Assembly:** Assemble the unit on a soft, clean surface to prevent scratches. Ensure all screws and fasteners are tightened securely before use.
- **Placement:** Place the TV stand on a level surface to ensure stability.




Image 2.1: Anti-tip kit and adjustable feet for stability.

## 3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer service.

- Metal Frame Components (various sizes)
- Wooden Boards (Top, Middle Shelf, Back Support)
- 7 Fabric Drawers with Front Panels and Handles
- Power Outlet Unit with 2 AC Outlets and 2 USB Ports
- Hardware Kit (screws, bolts, Allen wrench)

- Anti-Tip Kit
- Adjustable Feet (pre-attached or separate)
- Instruction Manual

## 4. Assembly Instructions

Follow these step-by-step instructions carefully. It is recommended to have two people for assembly.

Your browser does not support the video tag.

Video 4.1: Detailed assembly guide for the Furologee TV Stand.

1. **Step 1: Assemble the Base Frame.** Connect the bottom horizontal metal bars to the vertical side frames using the specified screws (refer to parts labeled 3, 4, and screws C in the video at 0:06).
2. **Step 2: Attach Crossbars.** Secure the internal crossbars (parts 9) to the base frame using screws C (video at 0:09).
3. **Step 3: Install Vertical Supports.** Attach the smaller vertical supports (parts 1) to the frame (video at 0:11).
4. **Step 4: Secure the Middle Shelf.** Place the middle wooden shelf (part 7) onto the designated frame supports and secure it with screws D (video at 0:14).
5. **Step 5: Assemble the Top Frame.** Connect the upper horizontal metal bars (parts 8) to the vertical side frames using screws B (video at 0:18).
6. **Step 6: Install the Top Board.** Place the main top wooden board (part 5) onto the assembled top frame and secure it with screws B (video at 0:22).
7. **Step 7: Install the Power Outlet Unit.** Carefully insert the power outlet unit into the pre-cut opening on the top board and secure it as instructed (video at 0:26).
8. **Step 8: Assemble Fabric Drawers.** Fold each fabric drawer into shape, insert the bottom panel, and attach the handle to the front panel (video at 0:28).
9. **Step 9: Insert Drawers.** Slide the assembled fabric drawers into their respective compartments within the metal frame (video at 0:36).
10. **Step 10: Install Anti-Tip Kit.** Secure the anti-tip kit to the back of the unit and to the wall according to the separate instructions provided with the kit.

## 5. Operating Instructions

### 5.1 Using the Power Outlets

The integrated power strip on the top surface provides convenient access to power for your devices.

- **AC Outlets:** Plug in your TV, lamps, or other electronic devices into the two 120V/12A AC outlets.
- **USB Ports:** Use the two 5V/A2 USB ports to charge smartphones, tablets, or other USB-powered devices.
- **Power Cord:** Ensure the 6.6 ft power cord is fully extended and plugged into a functional wall outlet.




Image 5.1: Power outlets and USB ports for charging devices.

### 5.2 Utilizing Storage Drawers and Shelves

The unit offers ample storage with its seven fabric drawers and two open shelves.

- **Fabric Drawers:** The seven foldable fabric drawers are ideal for organizing clothes, accessories, media, or other personal items. They are designed for easy access and child safety.
- **Open Shelves:** The two-tier open shelves provide space for media devices, books, decorative items, or storage boxes.




Image 5.2: Fabric drawers providing versatile storage.

### 5.3 Versatile Placement

This unit can function as a TV stand, a console table, a sofa table, or a storage dresser, adapting to various room layouts and needs.




Image 5.3: Versatile uses of the TV stand in different room settings.

## 6. Maintenance

Proper care will extend the life of your TV stand.

- **Cleaning:** Wipe the wooden and metal surfaces with a damp cloth, then dry immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Drawers:** For minor spills, spot clean the fabric drawers with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

## 7. Troubleshooting

If you encounter any issues, refer to the following common problems and solutions:

- **Unit is Unstable/Wobbly:**
  - Ensure the unit is placed on a level surface.
  - Adjust the 360° adjustable feet on the bottom of the frame to stabilize the unit.
  - Verify all assembly screws are securely tightened.
  - Confirm the anti-tip kit is properly installed and secured to the wall.
- **Drawers Do Not Slide Smoothly:**
  - Check that the fabric drawers are correctly assembled and the bottom panel is fully inserted.
  - Ensure no items are obstructing the drawer's movement within the frame.
- **Power Outlets/USB Ports Not Working:**
  - Verify the main power cord is securely plugged into a functional wall outlet.
  - Check if the power outlet unit is correctly seated and connected within the top board.
  - Avoid overloading the outlets; unplug some devices if necessary.

If these solutions do not resolve the issue, please contact Furologee customer service for further assistance.

## 8. Specifications

| | |
|---|---|
| **Brand** | Furologee |
| **Model Number** | B0BX473XDD |
| **Product Dimensions** | 11.4"D x 39.4"W x 30.9"H |
| **Material** | Engineered Wood, Metal Frame, Fabric Drawers |
| **Number of Drawers** | 7 |
| **Number of Shelves** | 2 |
| **Power Outlets** | 2 AC Outlets (120V/12A), 2 USB Ports (5V/A2) |
| **Power Cord Length** | 6.6 ft |
| **Top Shelf Load Capacity** | 100 lbs |
| **Middle Shelf Load Capacity** | 66 lbs |
| **Color** | Rustic Brown |
| **Assembly Required** | Yes |




Image 8.1: Product dimensions and weight capacities.

## 9. Warranty and Support

Furologee is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, we offer customer service before and after your purchase. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact us.

Please refer to your purchase documentation or the retailer's website for information on how to contact Furologee customer support.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question