HMHAMA HCDM312

HMHAMA Washer Drain Pump Filter & Drain Button Filter Plug Instruction Manual

Model: HCDM312

Introduction

This instruction manual provides essential information for the installation, maintenance, and troubleshooting of your HMHAMA Washer Drain Pump Filter or Drain Button Filter Plug. These components are designed to trap lint and debris from the drain water, effectively protecting your washing machine's pump from blockages and ensuring proper drainage. Regular inspection and cleaning of this filter are crucial for the optimal performance and longevity of your LG washing machine.

Product Overview

The HMHAMA replacement part is available in two main types: the **Drain Button Filter Plug** and the **Pump Filter**. Both serve the critical function of preventing debris from entering and damaging the washing machine's drain pump.

Compatible Models:

This filter is compatible with various LG washing machine models. Please refer to the lists below to confirm compatibility:

- **Drain Button Filter Models:** WD-1015FB, WD-1025FB, WD-1074FHB, WD-1223FB, WD-1236TD, WD-1274FHB, WD-1435RD, WD-1438RD, WD-1480RD, WD-1481RD, WD-1485RD, WD-1488RD, WD-8013F, WD-8016F, WD-8023FB, WD11020D, WD11020D1, WD12020D, WD14700RD, WD14800RD.
- **Pump Filter Models:** F1069FD, F1069FD2, F1069FD3, F1069FD4, F1069FD6F, F1069FD7F, F1069FDF, F1495BD, F14A8FD, F14A8RDS, F14A8TDS, FH069FD4P, FH069FD7P, FH069FDP, FR2922NCZB, WD-1019BD, WD-1219BD, WD-1227RD, WD-1247RD, WD-1248RD.



Figure 1: The HMHAMA Washer Drain Pump Filter Plug, featuring a cylindrical mesh basket and a threaded cap for secure installation. This component is crucial for trapping lint and debris.



Figure 2: Various perspectives of the drain pump filter plug, illustrating its design from different angles, including the top, side, and bottom views. This helps in understanding its structure and how it fits into the washing machine.



Figure 3: A detailed side view of the filter plug, highlighting the mesh design of the basket and the robust threading on the cap. This view emphasizes the filtration mechanism.



Figure 4: The bottom view of the filter plug, showing the base of the basket and the internal structure designed to maximize debris collection while allowing water to pass through efficiently.

Setup and Installation

Replacing your washer drain pump filter is a straightforward process that typically takes 10-20 minutes. Follow these steps carefully to ensure a correct and safe installation:

1. **Safety First:** Before beginning any repair or maintenance, always unplug your washing machine from the power outlet to prevent electrical shock.

2. **Access the Filter:** Locate the drain pump filter access panel on your LG washing machine. This is typically found at the bottom front of the appliance, often behind a small door or cover.
3. **Prepare for Water Drainage:** Place a shallow pan or towels beneath the filter area to catch any residual water that may drain out when the filter is removed.
4. **Remove the Old Filter:** Slowly unscrew the existing drain pump filter by turning it counter-clockwise. Be prepared for water to flow out. Once fully unscrewed, carefully pull out the old filter.
5. **Inspect and Clean (Optional):** Before installing the new filter, it is advisable to inspect the filter housing for any remaining debris and clean it thoroughly.
6. **Install the New Filter:** Insert the new HMHAMA drain pump filter or drain button filter plug into the opening. Ensure it is properly aligned.
7. **Secure the Filter:** Screw the new filter clockwise until it is hand-tight. Do not overtighten, but ensure it is snug to prevent leaks. Verify that any rubber gasket or seal is properly seated to prevent leaks.
8. **Test:** Plug the washing machine back into the power outlet. Run a short cycle (e.g., rinse and spin) to check for any leaks around the newly installed filter.

Important: Wear work gloves to protect your hands during this process, as there may be sharp debris or dirty water.

Operating Principle

The HMHAMA Washer Drain Pump Filter and Drain Button Filter Plug operate passively as an integral part of your washing machine's drainage system. During the wash and rinse cycles, water containing lint, small objects, and other debris flows towards the drain pump. The filter acts as a barrier, trapping these particles before they can reach and clog the pump impeller or drain hose. This continuous filtration ensures efficient water drainage and prevents common issues such as poor washing performance or machine malfunctions caused by blockages.

Maintenance

Regular maintenance of your drain pump filter is essential for the efficient operation and longevity of your washing machine. A clogged filter can lead to drainage issues and potential damage to the pump.

Recommended Cleaning Frequency:

It is recommended to clean the drain pump filter every two weeks, or more frequently if you notice signs of slow drainage or if you wash items that produce a lot of lint (e.g., pet blankets).

Cleaning Procedure:

1. **Disconnect Power:** Always unplug the washing machine from the power outlet before cleaning the filter.
2. **Access and Remove:** Follow steps 2-4 from the "Setup and Installation" section to access and remove the filter.
3. **Clean the Filter:** Rinse the filter under running water to remove all trapped lint, hair, and debris. Use a small brush (like an old toothbrush) if necessary to dislodge stubborn particles from the mesh.
4. **Inspect for Damage:** While cleaning, inspect the filter for any signs of wear, cracks, or damage. If the filter basket is broken or the seal is compromised, it should be replaced.
5. **Clean Housing:** Wipe down the filter housing inside the washing machine to remove any slime or residue.
6. **Reinstall:** Reinsert the clean filter and screw it back into place securely, ensuring a tight seal to prevent leaks.
7. **Restore Power:** Plug the washing machine back in.

Troubleshooting

If your washing machine is experiencing drainage issues, the drain pump filter is often the first component to check.

Below are common symptoms and potential solutions related to the filter:

Symptom	Possible Cause	Solution
Washing machine will not drain	Clogged drain pump filter; blocked drain hose; faulty drain pump.	Clean the drain pump filter thoroughly. Check the drain hose for kinks or blockages. If issues persist, the drain pump may need professional inspection.
Leaking water from the front of the machine	Improperly installed filter; damaged filter gasket/seal; cracked filter housing.	Ensure the filter is screwed in tightly and correctly. Inspect the rubber gasket for damage and replace if necessary. Check the filter housing for cracks.
Washing machine overflowing	Severely clogged drain pump filter; drain pump malfunction.	Immediately unplug the machine. Clean the filter. If the problem continues, consult a qualified technician.
Not washing properly (e.g., clothes still wet)	Drainage issues preventing proper spin cycle; clogged filter.	Clean the drain pump filter. Ensure the machine can drain water effectively for the spin cycle to complete.
Filter basket detaches or doesn't stay together	Improper seating; manufacturing defect; wear and tear.	Ensure the filter is correctly aligned and fully screwed in. If the component is faulty, replacement may be necessary.

If troubleshooting steps do not resolve the issue, it is recommended to contact a qualified appliance repair technician.

Specifications

Attribute	Detail
Brand	HMHAMA
Model Number	HCDM312
Part Number	HCDM312
Item Weight	2.39 ounces (0.07 Kilograms)
Package Dimensions	4 x 2 x 2 inches
Color	Filter Plug
Style	Above Ground
Power Source	Electric (refers to the washer, not the filter itself)
Manufacturer	ZZHM
First Available Date	March 1, 2023

Warranty and Support

Specific warranty information for the HMHAMA Washer Drain Pump Filter / Drain Button Filter Plug is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product packaging or contact the manufacturer, HMHAMA, or the seller (ZZHM) directly through their official channels or the platform where the

product was purchased.
Always retain your proof of purchase for any warranty claims.

© 2025 HMHAMA. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question