Profi Cook PC-EWB 1253

PROFICOOK Ice Maker PC-EWB 1253 User Manual

Model: PC-EWB 1253

Introduction

Thank you for choosing the PROFICOOK Ice Maker PC-EWB 1253. This manual provides important information regarding the safe operation, maintenance, and troubleshooting of your new ice maker. Please read these instructions thoroughly before first use and keep them for future reference.



Image: The PROFICOOK Ice Maker PC-EWB 1253, a compact stainless steel unit, shown with an ice scoop and several ice cubes, highlighting its primary function.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the appliance.
- Do not touch cold surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plug, or any part of the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.

- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is intended for household use only.

Product Overview

Familiarize yourself with the components of your PROFICOOK Ice Maker.



Image: A detailed view of the PROFICOOK Ice Maker's control panel, showing buttons for power, ice size selection, and indicator lights. The image also highlights features like 8-12 kg ice production in 24 hours, electronic control with 6 indicator lights, two selectable ice cube sizes (small/large), and included ice scoop accessory.

Key Features:

- Stainless steel housing.
- Electronic control panel with indicator lights.
- Two selectable ice cube sizes (small/large).
- Produces ice cubes in approximately 10 minutes.
- Daily ice production capacity: 8-12 kg.
- Removable ice basket.
- Eco-save energy mode.
- Quiet operation.



Image: The PROFICOOK Ice Maker with its lid open, showing the removable black ice basket being lifted out, indicating easy access for

cleaning and ice retrieval.

Setup

1. **Unpacking:** Carefully remove the ice maker from its packaging. Retain the packaging for future storage or transport.
2. **Placement:** Place the ice maker on a stable, level surface away from direct sunlight and heat sources (e.g., ovens, radiators). Ensure there is adequate ventilation around the unit, leaving at least 10 cm of space on all sides.
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker, including the water reservoir and ice basket, with a mild detergent and warm water. Rinse thoroughly and dry.
4. **Power Connection:** Ensure the voltage of your power supply matches the rating label on the appliance (230V). Plug the power cord into a grounded wall outlet.

Operating Instructions

1. **Fill Water Reservoir:** Open the lid and fill the water reservoir with clean, potable water up to the MAX fill line. Do not overfill.
2. **Select Ice Size:** Press the "SELECT" button on the control panel to choose your desired ice cube size (small or large). An indicator light will illuminate next to your selection.
3. **Start Ice Production:** Press the "POWER" button to start the ice making cycle. The "ICE" indicator light will illuminate.
4. **Monitor Progress:** The ice maker will begin producing ice cubes in approximately 10 minutes. The "ICE FULL" indicator light will illuminate when the ice basket is full, and the machine will pause operation.
5. **Add Water Indicator:** If the water level is too low, the "ADD WATER" indicator light will illuminate, and the machine will stop. Refill the reservoir to resume operation.
6. **Collecting Ice:** Use the provided ice scoop to remove ice cubes from the basket. For best results, transfer ice to a freezer for storage.
7. **Stopping Operation:** To stop the ice maker at any time, press the "POWER" button.



Image: A close-up view inside the PROFICOOK Ice Maker, showing a collection of freshly made, bullet-shaped ice cubes filling the removable basket.

Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your ice maker.

Cleaning:

- **Daily Cleaning:** After each use, drain any remaining water from the reservoir. Wipe the interior with a soft cloth.
- **Weekly Cleaning:** For a more thorough cleaning, unplug the unit. Remove the ice basket and clean it with warm, soapy water. Clean the water reservoir and the ice-making components with a solution of water and mild detergent. Rinse all parts thoroughly with clean water.
- **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Descaling:

Depending on water hardness, mineral deposits may accumulate. Descale the unit every 1-3 months or as needed.

1. Mix a solution of water and vinegar (1:1 ratio) or a commercial descaling agent according to product instructions.
2. Pour the solution into the water reservoir.
3. Run the ice maker for a few cycles (without consuming the ice) to circulate the solution.
4. Drain the solution completely and rinse the reservoir multiple times with fresh water to remove any residue.
5. Run a few cycles with fresh water to flush out any remaining descaling agent before resuming ice production for consumption.

Storage:

If the ice maker will not be used for an extended period, drain all water, clean the unit thoroughly, and allow it to dry completely before storing in a cool, dry place.

Troubleshooting

Before contacting customer support, please refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Ice maker not turning on.	No power supply.	Check if the unit is plugged in and the outlet is working.
"ADD WATER" indicator is on.	Water reservoir is empty or low.	Fill the water reservoir to the MAX line.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice cubes are too small or not forming.	Water temperature too high; ambient temperature too high; insufficient water.	Use colder water; ensure proper ventilation; refill water reservoir.
Unusual noise during operation.	Unit not level; internal components vibrating.	Ensure the unit is on a stable, level surface. If noise persists, contact customer support.

Specifications

Attribute	Detail
Brand	Profi Cook
Model Name	1253 (Item model number: 501253)
Product Dimensions	30.5 x 22 x 30 cm (D x W x H)
Item Weight	7.3 kg
Capacity	1.5 litres (water reservoir)
Wattage	120 watts

Attribute	Detail
Voltage	230 Volts
Colour	Black / Stainless Steel
Manufacturer	PROFICOOK



Image: A diagram showing the dimensions of the PROFICOOK Ice Maker: 220 mm width, 305 mm depth, and 300 mm height.

Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or visit the official Profi Cook website. Please have your model number (PC-EWB 1253 or 501253) and purchase details ready when contacting support.

© 2023 Profi Cook. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question