Leevuopa B0BXGZ527Q

Leevuopa Wearable Panty Vibrator Instruction Manual

Brand: Leevuopa | Model: B0BXGZ527Q

1. Product Overview

The Leevuopa Wearable Panty Vibrator is a discreet and versatile intimate device crafted from supple, body-safe silicone. Its ergonomic, saddle-shaped design allows for comfortable and effortless placement within panties, providing stimulation without the need to remove clothing. This vibrator offers 12 distinct vibrating modes, controlled wirelessly via a compact remote. It is fully rechargeable for convenience and designed to be waterproof, making it suitable for various environments. Please note that while the vibrator itself is waterproof, the remote control is not and must be kept dry.



Image: Leevuopa Wearable Panty Vibrator and Remote Control

2. Safety Information

For general safety advice regarding intimate products, it is recommended to consult a healthcare provider or reference educational resources from reputable health organizations. Always ensure the product is clean before and after each use. Discontinue use if any discomfort or irritation occurs.

3. Package Contents

- 1 x Leevuopa Wearable Panty Vibrator
- 1 x Wireless Remote Control
- 1 x USB Magnetic Charging Cable

4. Setup

4.1 Charging the Vibrator

Before first use, fully charge the vibrator. Connect the included USB magnetic charging cable to the two small contact points on the vibrator. Plug the USB end into a compatible power source (e.g., wall adapter, computer, power bank). The indicator light on the vibrator will illuminate during charging and turn off when fully charged. A full charge typically takes approximately 1-2 hours.



Image: USB Magnetic Charging for the Vibrator

4.2 Initial Use and Pairing

The vibrator and remote control are typically pre-paired from the factory. To turn on the vibrator, press and hold the power button on the vibrator until it vibrates and the indicator light illuminates. To activate the remote, press any button. If the remote does not control the vibrator, ensure both devices are charged and within range (up to 10 meters).

5. Operating Instructions

5.1 Power On/Off

- **To Power On:** Press and hold the power button on the vibrator until it vibrates and the indicator light turns on.
- **To Power Off:** Press and hold the power button on the vibrator until it stops vibrating and the indicator light turns off.

5.2 Changing Vibration Modes

Once the vibrator is powered on, short press the power button on the vibrator or the mode button on the remote

control to cycle through the 12 distinct vibration modes. Experiment to find your preferred pattern and intensity.



Image: Overview of 12 Vibration Modes

5.3 Using the Remote Control

The wireless remote control allows for convenient operation from a distance of up to 10 meters. Use the buttons on the remote to power on/off the vibrator and cycle through the vibration modes. This feature is ideal for solo exploration or shared experiences with a partner.



Image: Wireless Remote Control Functionality

5.4 Wearable Use

The vibrator's compact and flexible design is specifically made for discreet wear. Simply position the vibrator within your panties, ensuring the textured nub is aligned for optimal clitoral pleasure. Its quiet operation ensures privacy during use.



Image: Discreet and Invisible Wear

6. Maintenance

6.1 Cleaning

Clean the vibrator thoroughly before and after each use. Wash the silicone body with mild soap and warm water. Rinse thoroughly and pat dry with a lint-free cloth. Do not submerge the remote control in water.

6.2 Storage

Store the vibrator and remote in a clean, dry place, away from direct sunlight and extreme temperatures. Keep them separate from other toys made of different materials to prevent material degradation.

7. Troubleshooting

- **Vibrator not turning on:** Ensure the vibrator is fully charged. Press and hold the power button for a few seconds.
- **Remote not responding:** Ensure the vibrator is powered on. Check that the remote is within the 10-meter

operating range.

- **Weak vibrations:** The battery might be low; recharge the vibrator. Cycle through the modes to ensure you are not on a lower intensity setting.

8. Specifications

Feature	Detail
Material	Silicone
Water Resistance Level	Waterproof (Vibrator only)
Package Dimensions	5.75 x 5.04 x 1.77 inches
Weight	4.16 ounces
Batteries	1 Lithium Ion battery (included)



Image: Product Size and Dimensions

9. Warranty and Support

For any product inquiries, technical support, or warranty information, please refer to the contact details provided on the product packaging or reach out to Leevuopa customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question