WOLTU CPS8147sz-2

WOLTU Camping Chair User Manual

Model: CPS8147sz-2
Brand: WOLTU

Introduction

Thank you for choosing the WOLTU Camping Chair. This manual provides important information regarding the setup, operation, maintenance, and troubleshooting of your new camping chair. Please read this manual thoroughly before use to ensure safe and optimal performance of the product. Keep this manual for future reference.

Safety Information

- Do not exceed the maximum load capacity of 150 kg (330 lbs). Overloading can cause damage to the chair and lead to injury.
- Ensure the chair is fully unfolded and stable on a flat, firm surface before sitting.
- Keep fingers and hands clear of moving parts during unfolding and folding to prevent pinching.
- Do not stand on the chair. It is designed for sitting only.
- Avoid exposing the chair to extreme weather conditions for prolonged periods, as this may reduce its lifespan.
- Keep away from open flames and excessive heat sources.
- Supervise children when they are near or using the chair.

Product Overview

The WOLTU Camping Chair is a versatile and portable seating solution designed for various outdoor and indoor activities. It features a durable construction, adjustable backrest, and convenient storage options.



Image: Two WOLTU camping chairs in black, showcasing their design and portability with included carrying bags.

Key Features:

- **2-in-1 Design:** Functions as both a fishing chair and a lounge chair with an adjustable backrest.
- **Lightweight & Portable:** Easy to fold and transport with a compact size and included storage bag.
- **Robust & Durable:** Constructed from thick 600D Oxford fabric and steel tubes, supporting up to 150 kg.
- **No Assembly Needed:** Ready to use right out of the bag.
- **Convenient Storage:** Equipped with a cup holder and a side storage pocket.
- **Removable Headrest:** For added comfort.



Image: Detail view of the integrated cup holder and side storage pocket, designed for convenience.

Setup

The WOLTU Camping Chair requires no assembly. It is designed for quick and easy setup.

1. Remove the chair from its storage bag.
2. Hold the top of the chair and gently pull the legs outwards until the chair is fully extended and locked into place. Ensure all four legs are firmly on the ground.
3. Verify that the chair is stable before use.



Image: Step-by-step visual guide for unfolding the chair and packing it into its storage bag.

Operating Instructions

Adjusting the Backrest:

The chair's backrest can be adjusted to two positions: an upright sitting position (approximately 90°) and a reclined lounging position (approximately 155°).

1. To recline, gently push the backrest backward while applying slight pressure to the seat. The mechanism will allow it to shift to the reclined position.
2. To return to the upright position, lean forward slightly and pull the backrest forward until it locks into the upright position.
3. Always ensure the backrest is securely locked in your desired position before leaning back.



Image: Visual representation of the chair's adjustable backrest, allowing for both sitting and lounging.

Using the Cup Holder and Side Pocket:

- The integrated cup holder on the armrest is suitable for standard-sized cups, bottles, or drinks.
- The side mesh pocket can be used to store small personal items such as phones, magazines, or sunscreen.

Folding for Storage:

1. Ensure the backrest is in the upright position.
2. Gently push the sides of the chair inwards, allowing the frame to collapse.
3. Once folded, secure it with any integrated straps if present, and place it into the provided storage bag.

Maintenance

- **Cleaning:** Wipe the fabric and frame with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Allow to air dry completely before folding and storing.

- **Storage:** Store the chair in its carrying bag in a cool, dry place when not in use to protect it from dust, moisture, and prolonged sun exposure.
- **Inspection:** Periodically check all joints, screws, and fabric for any signs of wear, damage, or looseness. Tighten any loose screws and address any damage promptly to ensure safety and extend the product's life.

Troubleshooting

Problem	Possible Cause	Solution
Chair is difficult to unfold/fold.	Mechanism might be stiff or misaligned.	Apply gentle, even pressure. Ensure no fabric is caught in the joints. Lubricate joints if necessary with a silicone-based spray.
Chair feels unstable.	Not fully extended or on uneven ground.	Ensure all legs are fully extended and locked. Move the chair to a flat, firm surface. Check for any bent frame parts.
Backrest does not adjust smoothly.	Mechanism might be stiff or obstructed.	Ensure no fabric is caught. Apply slight pressure to the seat while adjusting.

Specifications



Image: Detailed specifications including dimensions, weight, and load capacity.

Attribute	Value
Brand	WOLTU
Model Number	CPS8147sz-2
Color	Black
Material	Metal frame, 600D Oxford Fabric
Unfolded Dimensions (Sitting)	64 x 83 x 89 cm (25.2 x 32.7 x 35.0 inches) (L x W x H)
Unfolded Dimensions (Reclined)	101 x 83 x 68 cm (39.8 x 32.7 x 26.8 inches) (L x W x H)
Folded Dimensions	90 x 17 x 17 cm (35.4 x 6.7 x 6.7 inches)
Item Weight	3.55 kg (7.8 lbs)

Attribute	Value
Load Capacity	Up to 150 kg (330 lbs)
Country of Origin	China

Warranty and Support

For warranty information and customer support, please contact WOLTU GmbH directly. Details regarding specific warranty periods and terms are typically provided at the point of purchase or on the official WOLTU website.
If you encounter any issues not covered in the troubleshooting section, or require replacement parts, please reach out to the seller or manufacturer's customer service for assistance.
You can visit the WOLTU brand store for more information:WOLTU Brand Store

© 2024 WOLTU. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question