DOMO DO537FR

DOMO DO537FR AIRFRYER User Manual

Model: DO537FR

Introduction

Thank you for purchasing the DOMO DO537FR Air Fryer. This appliance is designed to cook a variety of foods using rapid hot air circulation, offering a healthier alternative to traditional deep frying. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

Product Overview

The DOMO DO537FR Air Fryer features a dual-basket design, allowing you to cook two different foods simultaneously or larger quantities of a single item. Below are key components of your air fryer.



Figure 1: Front view of the DOMO DO537FR Air Fryer with both cooking baskets securely in place. The digital display and control icons are visible on the top front panel.



Figure 2: Components of the DOMO DO537FR Air Fryer, including the main appliance body, two removable cooking baskets, and two crisping racks designed to fit inside the baskets.



Figure 3: Detailed view of the digital control panel. It features temperature and time readouts, along with intuitive icons for various cooking presets such as fries, meat, fish, and baked goods.

Setup

1. **Unpacking:** Carefully remove the air fryer and all its components from the packaging. Retain the packaging for future storage or transport if needed.
2. **Initial Cleaning:** Before first use, wipe the exterior of the appliance with a damp cloth. Wash the cooking baskets and crisping racks with warm, soapy water. Rinse thoroughly and dry completely. Do not immerse the main unit in water.
3. **Placement:** Place the air fryer on a stable, flat, heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 10 cm (4 inches) of clear space around the back and sides of the unit.
4. **Power Connection:** Ensure the voltage of your power outlet matches the voltage specified on the appliance's rating label (230 Volts). Plug the power cord into a grounded wall outlet.

Operating Instructions

Preheating

For best results, preheating the air fryer is recommended for most recipes. This ensures even cooking and crispier results.

1. Plug in the air fryer. The display will illuminate.
2. Select the desired temperature using the temperature controls (up/down arrows).
3. Set the time for 3-5 minutes for preheating.
4. Press the start/pause button to begin preheating.

Cooking with the Air Fryer

1. **Prepare Food:** Place the crisping rack into the cooking basket. Place your ingredients into the cooking basket. Do not overfill the basket; ensure there is enough space for air to circulate. For optimal crispiness, lightly toss food with a small amount of oil if desired.
2. **Insert Basket:** Slide the cooking basket back into the main unit until it clicks into place.
3. **Set Time and Temperature:**
    - Manually set the desired cooking temperature and time using the respective up/down arrows on the control panel.
    - Alternatively, select one of the pre-set programs by pressing the menu icon and cycling through the options (e.g., fries, chicken, fish, steak, cake, vegetables). The air fryer will automatically set the recommended time and temperature for the selected program.
4. **Start Cooking:** Press the start/pause button to begin the cooking cycle.
5. **Shake/Flip Food (Optional):** For even cooking, especially with items like fries or chicken wings, you may need to shake or flip the food halfway through the cooking time. Carefully pull out the basket, shake or flip the contents, and reinsert the basket. The air fryer will automatically resume cooking.
6. **End of Cooking:** The air fryer will beep when the cooking cycle is complete. Carefully pull out the basket and transfer the cooked food to a serving plate.

Dual Zone Cooking (Sync Function)

The DOMO DO537FR features two independent cooking zones, allowing you to cook two different foods at different temperatures and times, or synchronize their finish times.



Figure 4: The dual-basket design in action, showing separate compartments for cooking different food items simultaneously.

1. **Independent Cooking:**
    - Load food into both baskets.
    - Select basket 'L' (Left) or 'R' (Right) on the control panel.
    - Set desired temperature and time for the selected basket.
    - Repeat for the other basket.
    - Press start/pause to begin cooking for both zones independently.

2. **Sync Finish Function:**
    - Load food into both baskets.
    - Select basket 'L' and set its cooking time and temperature.
    - Select basket 'R' and set its cooking time and temperature.
    - Press the 'SYNC' button on the control panel. The air fryer will automatically adjust the start times of each basket so they finish cooking simultaneously.
    - Press start/pause to begin the synchronized cooking.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your DOMO DO537FR Air Fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Cleaning Baskets and Racks:** Wash the cooking baskets and crisping racks with warm, soapy water using a non-abrasive sponge. Rinse thoroughly and dry completely. **Note:** These parts are NOT dishwasher safe.
3. **Cleaning the Interior:** Wipe the interior of the air fryer with a damp cloth. For stubborn residue, use a mild dish soap solution. Avoid abrasive cleaners or scouring pads.
4. **Cleaning the Exterior:** Wipe the exterior of the appliance with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Storage:** Ensure all parts are clean and dry before storing. Store the air fryer in a cool, dry place.

Troubleshooting

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; appliance malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Food is not crispy.	Basket overloaded; insufficient oil; temperature too low; cooking time too short.	Do not overload the basket. Lightly toss food with oil. Increase temperature or cooking time. Shake/flip food during cooking.
White smoke coming from the appliance.	Grease residue from previous use; high-fat food being cooked.	Clean the basket and interior thoroughly after each use. For high-fat foods, drain excess fat during cooking.
Food is unevenly cooked.	Food not shaken/flipped; basket overloaded.	Shake or flip food halfway through cooking. Reduce the amount of food in the basket.

Specifications

- **Model:** DO537FR
- **Brand:** DOMO
- **Capacity:** 2 x 4 Liters (Total 8 Liters)
- **Output Wattage:** 2850 Watts
- **Voltage:** 230 Volts

- **Item Weight:** 6.81 Kilograms (approx. 14.98 pounds)
- **Product Dimensions:** 16.14 x 16.14 x 14.96 inches (L x W x H)
- **Nonstick Coating:** Yes
- **Dishwasher Safe Parts:** No (Baskets and racks are not dishwasher safe)
- **First Available:** August 18, 2023

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official DOMO website. You may also contact customer service at the details provided on the product packaging or official website.
Website: www.domo-elektro.be

© 2024 DOMO. All rights reserved.
This manual is for informational purposes only and may be subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question