Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AEG AXP26U339CW

AEG AXP26U339CW Portable Air Conditioner User Manual

Model: AXP26U339CW (950011610)

1. Introduction

This user manual provides essential information for the safe and efficient operation of your AEG AXP26U339CW Portable Air Conditioner. Please read this manual thoroughly before installation, operation, or maintenance. Keep it for future reference.

The AEG Comfort 6000 AXP26U339CW is a connected mobile air conditioner designed to cool your home quietly and efficiently. It features excellent energy-efficient cooling and can be controlled via the AEG App for optimal settings.



The AEG AXP26U339CW Portable Air Conditioner, designed for efficient home cooling.

2. Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the appliance with a damaged cord or plug.
- Keep the appliance away from flammable materials.
- This appliance uses R290 refrigerant, which is flammable. Handle with care and ensure proper ventilation.
- Do not block air inlets or outlets.
- Supervise children and ensure they do not play with the appliance.
- Refer to the full safety guidelines in the printed manual for comprehensive details.



These symbols indicate important safety warnings. Always read and understand the instructions provided.

3. Setup and Installation

3.1 Unpacking

Carefully remove the air conditioner from its packaging. Check for any damage during transit. Retain the packaging for future storage or transport.

3.2 Placement

Place the unit on a flat, stable surface. Ensure there is sufficient space around the unit for proper airflow (at least 20 cm from walls and furniture).



The air conditioner should be placed near a window for exhaust hose installation.

3.3 Exhaust Hose Installation

Connect the exhaust hose to the air conditioner and extend it to a window. For optimal performance and energy efficiency, it is highly recommended to use the optional Premium Window Kit. This kit helps seal the window opening, preventing warm air from re-entering the room and improving cooling efficiency by up to 28%.



The exhaust hose should be securely fitted to the window kit to prevent air leakage.

3.4 Power Connection

Plug the power cord into a grounded electrical outlet. Ensure the outlet meets the power requirements of the unit.

4. Operating Instructions

4.1 Control Panel Overview

The control panel is located on the top of the unit. It features buttons for power, mode selection, temperature adjustment, fan speed, and timer settings. The digital display shows the current temperature or settings.



The control panel allows direct interaction with the unit's functions.

4.2 Modes of Operation

- **Cool Mode:** For cooling the room. Adjust temperature using the '+' and '-' buttons.
- **Fan Mode:** Circulates air without cooling. Select fan speed (Low, Medium, High).
- **Dry Mode (Dehumidify):** Reduces humidity in the room.
- **Auto Mode:** Automatically selects the operating mode based on the room temperature.

4.3 Using the AEG App

The AEG AXP26U339CW can be controlled remotely via the AEG App. Download the app from your smartphone's app store and follow the in-app instructions to connect your device. Through the app, you can:

- Select your desired temperature.
- Create custom schedules for operation.
- Choose your preferred operating mode.
- Monitor the unit's status.



The AEG App provides convenient remote control and scheduling features.

4.4 Energy Efficiency Tips

To maximize energy savings, ensure all windows and doors are closed when the unit is operating. The optional Premium Window Kit can significantly improve efficiency and shorten cooling times by up to 60%.



Proper sealing of windows and doors enhances cooling performance and energy efficiency.

4.5 Quiet Operation

The AEG AXP26U339CW is designed to deliver a continuous cool airflow at a low noise level of 64 dB(A), ensuring a comfortable environment without excessive disturbance.



Enjoy a cool and quiet environment with your AEG portable air conditioner.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner.

5.1 Cleaning the Air Filter

The air filter should be cleaned every two weeks or more frequently depending on usage and air quality. A dirty filter can reduce cooling efficiency and airflow.

1. Unplug the air conditioner from the power outlet.
2. Locate and remove the air filter (usually on the back or side of the unit).
3. Wash the filter with warm, soapy water. Rinse thoroughly.
4. Allow the filter to air dry completely before reinserting it.

5.2 Draining Water

The unit collects condensation during operation. Depending on humidity levels, you may need to drain the water periodically. Refer to the specific instructions in the full manual for continuous drainage options.

5.3 Storage

Before storing the unit for an extended period, ensure it is completely drained of water and the filter is clean and dry. Store in a cool, dry place, preferably in its original packaging.

6. Troubleshooting

If you encounter issues with your air conditioner, refer to the table below for common problems and solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Unit does not turn on.	No power; power cord unplugged; circuit breaker tripped.	Check power connection; reset circuit breaker.
Insufficient cooling.	Dirty air filter; blocked air intake/outlet; room too large; windows/doors open.	Clean filter; clear obstructions; ensure room size is within capacity; close windows/doors.
Unit is noisy.	Unit not on a level surface; fan speed too high.	Place on a level surface; reduce fan speed. (Note: Normal operating noise is 64 dB(A)).
Water leakage.	Water tank full; drainage hose blocked or improperly connected.	Drain water tank; check drainage hose for blockages or proper connection.

7. Specifications

Feature	Detail
Brand	AEG
Model Name	AXP26U339CW (950011610)
Item Weight	69.3 pounds
Product Dimensions	15.16 x 18.74 x 27.95 inches
Noise Level	64 dB
Installation Type	Portable
Special Features	WiFi Enabled
Voltage	220 Volts
Wattage	50 watts
Refrigerant	R290 (environmentally friendly)

Note: Specifications are subject to change without notice for product improvement.

8. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official AEG website. Keep your purchase receipt as proof of purchase.
For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact AEG customer service. Contact details can typically be found on the AEG website or in your product's packaging. You may also consider purchasing additional protection plans, such as the "Complete Protect" plan, which covers eligible past and future purchases.

© 2025 AEG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BXPLGX9W

More documents and user manuals: **https://manuals.plus/**