YOLOEMOT T10

YOLOEMOT T10 Bluetooth Speaker Instruction Manual

Introduction Package Contents Product Overview Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the YOLOEMOT T10 Bluetooth Speaker. This portable wireless speaker is designed to deliver clear audio with enhanced bass, featuring IPX5 water resistance, multiple playback modes, and True Wireless Stereo (TWS) pairing functionality. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and longevity of your device.

2. Package Contents

Please check the box for the following items:

- YOLOEMOT T10 Bluetooth Speaker
- Charging Cable
- Audio Cable
- Lanyard
- Instruction Manual

3. Product Overview

Familiarize yourself with the speaker's components and controls:



This image displays the front of the YOLOEMOT T10 speaker, highlighting the power/play/pause button, volume up/next track button, volume down/previous track button, and the LED indicator light. The charging port is covered by a waterproof flap at the bottom.



A detailed diagram illustrating the functions of each button and the location of the charging port, AUX input, and TF card slot, all protected by a waterproof silicone cover.

Button Functions:

Button	Function (Short Press)	Function (Long Press)
+ (Volume Up)	Increase Volume	Next Track
Power / **Play** / **Pause**	Play/Pause Music, Answer/End Call	Power On/Off
- (Volume Down)	Decrease Volume	Previous Track

4. Setup

4.1 Charging the Speaker

Before first use, fully charge the speaker. Open the waterproof silicone cover to access the charging port.

- Connect the provided charging cable to the speaker's charging port and a USB power adapter (not included).
- The LED indicator will show charging status (e.g., red for charging, off when fully charged).
- A full charge provides up to 12 hours of playback time.

4.2 Power On/Off

- **To Power On:** Long press the **Power** / **Play** / **Pause** button until the LED indicator lights up and you hear a power-on tone.
- **To Power Off:** Long press the **Power** / **Play** / **Pause** button until the LED indicator turns off and you hear a power-off tone.

4.3 Bluetooth Pairing (Single Speaker)

1. Ensure the speaker is powered on and in Bluetooth pairing mode (LED indicator will flash).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "YOLOEMOT T10" from the list of devices.
4. Once paired, the LED indicator will stop flashing and remain solid, and you will hear a confirmation tone.

4.4 True Wireless Stereo (TWS) Pairing (Two Speakers)

For an immersive stereo sound experience, you can pair two YOLOEMOT T10 speakers together:



This image features two YOLOEMOT T10 speakers wirelessly connected via True Wireless Stereo (TWS) function, providing an enhanced

audio experience for a group of people outdoors.

1. Ensure both YOLOEMOT T10 speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), double-press the **Power** / **Play** / **Pause** button. The speaker will enter TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. Once connected, you will hear a confirmation tone, and the LED indicator on the primary speaker will flash, while the secondary speaker's LED will be solid.
4. Now, connect your device to the primary speaker via Bluetooth as described in Section 4.3.

4.5 AUX and TF Card Playback

The YOLOEMOT T10 speaker supports playback via AUX input and TF (MicroSD) card.

- **AUX Mode:** Open the waterproof silicone cover and connect the provided audio cable to the speaker's AUX port and your audio device. The speaker will automatically switch to AUX mode.
- **TF Card Mode:** Open the waterproof silicone cover and insert a TF card (with music files) into the TF card slot. The speaker will automatically switch to TF card playback mode.

5. Operating Instructions

5.1 Music Playback

- **Play/Pause:** Short press the **Power** / **Play** / **Pause** button.
- **Volume Up:** Short press the **+** button.
- **Volume Down:** Short press the **-** button.
- **Next Track:** Long press the **+** button.
- **Previous Track:** Long press the **-** button.

5.2 Call Management

When connected to a smartphone via Bluetooth, the speaker can manage calls:

- **Answer Call:** Short press the **Power** / **Play** / **Pause** button.
- **End Call:** Short press the **Power** / **Play** / **Pause** button during a call.
- **Reject Call:** Long press the **Power** / **Play** / **Pause** button when an incoming call rings.

6. Maintenance

6.1 Water Resistance (IPX5)

The YOLOEMOT T10 speaker features an IPX5 water resistance rating, meaning it is protected against low-pressure water jets from any direction. This makes it suitable for use in environments with splashes, such as bathrooms or near a pool.



The YOLOEMOT T10 speaker is shown near a bathtub, emphasizing its IPX5 waterproof capability, making it suitable for use in wet environments like bathrooms or beaches.

Important:

- Ensure the silicone cover for the charging port, AUX input, and TF card slot is securely closed before exposing the speaker to water.
- Do not submerge the speaker in water.
- Avoid exposing the speaker to high-pressure water jets.

[redacted]

An official video demonstrating the IPX5 water resistance and high volume output of the YOLOEMOT T10 speaker, suitable for outdoor activities like hiking.

6.2 Cleaning and Storage

- Clean the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If not used for extended periods, charge the speaker at least once every three months to maintain battery health.

7. Troubleshooting

If you encounter issues with your YOLOEMOT T10 speaker, refer to the following common problems and solutions:

- **Speaker does not power on:**
  Ensure the speaker is fully charged. Connect it to a power source and try again.
- **Cannot pair with Bluetooth device:**
  Make sure the speaker is in pairing mode (LED flashing). Ensure Bluetooth is enabled on your device and it is within 12 meters of the speaker. Forget previous pairings on your device and try again.
- **No sound or low volume:**
  Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired. If using AUX or TF card, ensure the cable is fully inserted or the TF card has valid music files.
- **Sound distortion:**
  Reduce the volume on both the speaker and your device. Ensure the speaker is not too far from your Bluetooth device or obstructed.
- **TWS pairing fails:**
  Ensure both speakers are powered on and not connected to any other device. Try resetting both speakers by powering them off and on, then attempt TWS pairing again.

8. Specifications

Technical details of the YOLOEMOT T10 Bluetooth Speaker:



A technical diagram illustrating the dimensions of the YOLOEMOT T10 speaker, measuring 66mm in diameter and 96mm in height. It also shows the waterproof silicone cover for the ports.

Feature	Detail
Model Number	T10
Connectivity Technology	Bluetooth 5.3
Speaker Output Power	5 Watts
Audio Output Mode	Stereo
Water Resistance	IPX5
Bluetooth Range	Up to 12 meters (39 feet)
Battery Life	Up to 12 hours

Feature	Detail
Dimensions (D x W x H)	2.6" x 2.6" x 3.78" (66mm x 66mm x 96mm)
Item Weight	175 g
Input Voltage	5V DC
Impedance	4 ohm
Signal-to-Noise Ratio	75 dB
Compatible Devices	Smartphones, Tablets, Laptops
Power Source	Battery Powered (1 Lithium Polymer battery included)

9. Warranty and Support

The YOLOEMOT T10 Bluetooth Speaker comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.
For warranty claims, technical support, or any questions regarding your product, please contact YOLOEMOT customer service through the platform where you purchased the item.

10. Additional Resources

View official product videos for more information:

[redacted]

An official video demonstrating the powerful sound and bass capabilities of the YOLOEMOT T10 portable wireless speaker.

[redacted]

An official video showcasing the compact and portable design of the YOLOEMOT T10 speaker, ideal for outdoor use.

[redacted]

An official video providing a detailed visual tour of the YOLOEMOT T10 portable speaker's features and design elements.

[redacted]

An official video showing the YOLOEMOT T10 Bluetooth speaker in various outdoor settings, highlighting its versatility.

[redacted]

An official video emphasizing the small size and portability of the YOLOEMOT T10 speaker.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question