Tyche HCPR01

Tyche Turbo Pro Hair Clipper Kit

User Instruction Manual

Introduction

Thank you for choosing the Tyche Turbo Pro Hair Clipper Kit. This professional-grade clipper is designed for precision cutting and reliable performance. Featuring a high-speed magnetic motor, carbon steel blade, and zero-overlap capabilities, it provides an efficient and smooth grooming experience. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

Important Safety Information

To reduce the risk of electric shock, burns, fire, or injury:

- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- Always unplug this appliance from the electrical outlet immediately after using.
- Unplug this appliance before cleaning, putting on or taking off parts.
- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- Use this appliance only for its intended household use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

- Do not use this appliance with a damaged or broken comb, as facial injury may occur.
- Always attach plug to appliance first, then to outlet. To disconnect, turn all controls to "OFF" then remove plug from outlet.

Package Contents

Your Tyche Turbo Pro Hair Clipper Kit includes the following items:

- Tyche Turbo Pro Hair Clipper
- 4 Premium Attachment Combs (1/8" (3mm), 1/4" (6mm), 3/8" (10mm), 1/2" (13mm))
- Blade Guard
- Cleaning Brush
- Lubricating Oil
- Operating Instructions Manual



Figure 1: Contents of the Tyche Turbo Pro Hair Clipper Kit as packaged.

Product Overview

Familiarize yourself with the main components of your Tyche Turbo Pro Hair Clipper:

- **Self-Sharpening Blades:** Designed for long-lasting sharpness and precision.
- **Taper Lever:** Adjustable lever for varying cutting lengths without changing attachment combs, from 000 to 1.

- **Power Switch:** On/Off control for the clipper.
- **8 ft. Heavy Duty & Chemical Resistant Power Cord:** Provides flexibility and durability during use.
- **High-Speed Magnetic Motor:** Delivers 11,000 SPM (Strokes Per Minute) for efficient cutting.
- **Carbon Steel Blade:** Durable and precise cutting blade.
- **Zero-Overlap Blades:** For ultra-close cuts and detailed work.



Figure 2: Key features and components of the Tyche Turbo Pro Hair Clipper.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Inspect:** Check the clipper and accessories for any signs of damage. Do not use if damaged.
3. **Clean Blades:** Before first use, clean the blades with the provided cleaning brush to remove any manufacturing residue.
4. **Lubricate Blades:** Apply a few drops of the included lubricating oil to the blades. Turn the clipper on for a few seconds to distribute the oil evenly. Wipe off any excess oil.
5. **Select Attachment Comb:** Choose the desired cutting guide (comb) based on the hair length you wish to achieve. The combs are marked with their respective lengths (1/8", 1/4", 3/8", 1/2").
6. **Attach Comb:** Align the attachment comb with the clipper blade and firmly snap it into place. Ensure it is securely fastened before use.

Operating Instructions

1. **Prepare Hair:** Ensure hair is clean, dry, and free of tangles. For best results, comb the hair in the direction of growth.
2. **Plug In:** Insert the power cord into a suitable electrical outlet (120V, 60Hz).
3. **Turn On:** Flip the power switch to the "ON" position. The clipper will begin to operate.
4. **Adjust Taper Lever:** The taper lever allows for fine adjustments to cutting length without changing combs. Push the lever up for the shortest cut (000) and pull it down for a longer cut (1). Experiment to find the desired length.
5. **Begin Cutting:** Hold the clipper firmly with the blade flat against the head. Move the clipper slowly against the direction of hair growth. Use overlapping strokes to ensure an even cut.
6. **Remove Hair:** Periodically stop and brush away accumulated hair from the blades and comb to maintain cutting efficiency.
7. **Detailing:** For outlining and detailing, remove the attachment comb and use the clipper's bare blade. Use caution as the bare blade provides a very close cut.
8. **Turn Off:** Once finished, flip the power switch to the "OFF" position and unplug the clipper from the outlet.

Maintenance

Proper maintenance ensures the longevity and performance of your clipper.

- **Cleaning Blades:** After each use, brush away loose hair from the blades using the cleaning brush. For a more thorough cleaning, you can remove the blade set (refer to manufacturer's instructions if applicable for blade removal, otherwise just brush thoroughly).
- **Oiling Blades:** It is crucial to oil the blades regularly, ideally after every few uses or if the clipper starts to pull hair. Apply 2-3 drops of lubricating oil across the top of the blades and turn the clipper on for a few seconds to distribute. Wipe off any excess oil with a soft cloth. *Do not use hair oil, grease, or any oil mixed with kerosene or any solvent, as these will evaporate and slow down the blades.*
- **Storage:** Store the clipper in a dry, cool place, away from moisture and direct sunlight. Keep the blade guard on the blades when not in use to protect them.
- **Cord Care:** Do not wrap the cord around the clipper. Store the cord loosely to prevent damage.

Troubleshooting

Problem	Possible Cause	Solution
Clipper does not turn on.	Not plugged in; power outlet issue; damaged cord.	Ensure clipper is securely plugged into a working outlet. Check cord for damage. If damaged, do not use.

Problem	Possible Cause	Solution
Clipper pulls or snags hair.	Blades are dull; blades are dirty/clogged; insufficient oil; incorrect cutting technique.	Clean and oil blades. Ensure blades are sharp (if not, consider professional sharpening or replacement). Use slow, even strokes.
Clipper runs slowly or vibrates excessively.	Blades are dirty/clogged; insufficient oil; motor issue.	Clean and oil blades thoroughly. If problem persists, contact customer support.
Uneven cut.	Attachment comb not properly secured; incorrect angle; hair not prepped.	Ensure attachment comb is firmly snapped on. Maintain a consistent angle. Comb hair before cutting.

Specifications

Model: HCPR01

Motor: High-Speed Magnetic Motor (11,000 SPM)

Blade Material: Carbon Steel

Power: 120V, 60Hz

Cord Length: 8 ft.

Weight: Approximately 1.9 pounds (0.86 kg)

Dimensions (Package): 8.75 x 6.25 x 2.5 inches

Included Combs: 1/8" (3mm), 1/4" (6mm), 3/8" (10mm), 1/2" (13mm)

Warranty and Support

The Tyche Turbo Pro Hair Clipper Kit comes with a 1-year warranty from the date of purchase, covering defects in materials and workmanship. This warranty does not cover damage caused by misuse, abuse, alteration, or normal wear and tear.

For warranty claims, technical support, or replacement parts, please contact Tyche customer service through their official website or the retailer where the product was purchased. Please have your model number (HCPR01) and proof of purchase ready.

For additional information and resources, visit: www.tyche.com (*Note: This is a placeholder URL. Please refer to your product packaging for official support contact information.*)

© 2023 Tyche. All rights reserved. Tyche Turbo Pro Hair Clipper Kit User Manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question