Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garmin S70

Garmin Approach S70 47mm Premium GPS Golf Watch Instruction Manual

Model: S70 (010-02746-02)

Brand: Garmin

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Garmin Approach S70 47mm Premium GPS Golf Watch. Please read this manual thoroughly to ensure optimal performance and to familiarize yourself with all features.



Figure 1: Front view of the Garmin Approach S70 47mm GPS Golf Watch.

2. Setup

2.1 What's in the Box

- Garmin Approach S70 47mm GPS Golf Watch
- Charging/Data Cable
- Documentation (Quick Start Manual)

2.2 Initial Charging

Before first use, fully charge your Approach S70. Connect the charging/data cable to the watch and a USB power source. A full charge typically takes a few hours. The watch will display the charging status.

2.3 Pairing with the Garmin Golf App

1. Download the Garmin Golf app from your smartphone's app store.
2. Enable Bluetooth on your smartphone.
3. On your Approach S70, navigate to the settings menu and select 'Pair Phone'.
4. Follow the on-screen instructions on both your watch and the Garmin Golf app to complete the pairing process.

3. Operating Instructions

The Garmin Approach S70 features a stunning 1.4-inch AMOLED display, bringing over 43,000 preloaded full-color CourseView maps to life on your wrist. This premium smartwatch offers a suite of tools designed to enhance your golf game and support your lifestyle.

3.1 GPS Golf Features

The watch comes preloaded with more than 43,000 full-color CourseView maps of golf courses worldwide. Download updates for the courses you play most often via the Garmin Golf app.



Figure 2: Watch face showing a detailed golf course map with yardage to the green.

3.1.1 Virtual Caddie

The improved virtual caddie feature analyzes your shot dispersion data, elevation, wind speed, wind direction, and more to recommend the optimal club for your next shot. A new shot dispersion chart quickly shows potential hazards based on your club choice.

3.1.2 Enhanced PlaysLike Distance

This feature accounts for uphill shots, downhill shots, and trajectory, as well as wind, temperature, and air pressure using a built-in barometer. This provides more accurate

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BYFBRMWP

More documents and user manuals: **https://manuals.plus/**