Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vikye Vikye15dhi4br7e

Vikye X3 Wireless Game Controller User Manual

Model: Vikye15dhi4br7e

Introduction

Thank you for choosing the Vikye X3 Wireless Game Controller. This versatile gamepad is designed to enhance your gaming experience across multiple platforms, including Android, iOS, PC, TV, and VR devices. Featuring a comfortable grip, precise controls, and a rechargeable battery, it provides seamless connectivity and responsive gameplay. Please read this manual carefully before use to ensure proper operation and maintenance of your device.



Image: The Vikye X3 Wireless Game Controller, shown in black with red accents, alongside its USB charging cable and a detachable phone holder.

Setup

Package Contents

- Vikye X3 Wireless Game Controller
- USB Charging Cable
- Detachable Phone Holder
- User Manual (this document)

Charging the Controller

Before first use, fully charge the controller. Connect the supplied USB charging cable to the Micro USB port on the controller and the other end to a USB power source (e.g., computer USB port, USB wall adapter).



Image: A close-up view highlighting the Micro USB charging port located on the top edge of the controller.

- The LED indicator will show charging status.
- A full charge typically takes approximately 2 hours.
- Once fully charged, the controller provides 6-8 hours of continuous use.



Image: The controller displaying text overlays indicating "Battery Capacity: Lithium Battery 400mAh", "Charging Time: 2 Hours", and "Use Time: 6-8 Hours".

Connecting the Controller

The Vikye X3 controller supports multiple connection modes:

1. **Bluetooth Connection (Android/iOS/Smart TV):**
    - Ensure the controller is charged.
    - Press and hold the HOME button for 3 seconds to enter pairing mode (LED will flash rapidly).
    - On your device, enable Bluetooth and search for "X3 Gamepad" or similar.
    - Select the controller to pair. The LED will become solid once connected.
2. **Wired Connection (PC/Android TV Box):**
    - Connect the controller to your PC or Android TV Box using the supplied USB cable.
    - The controller should be automatically recognized as a gamepad. Drivers may be installed automatically.

Operating Instructions

Controller Layout and Functions



Image: A diagram of the controller highlighting the D-pad, left and right analog joysticks, action buttons (A, B, X, Y), HOME button, SELECT, and START buttons.

- **D-Pad:** Directional control for movement or menu navigation.
- **Left Analog Stick:** Primary movement control.
- **Right Analog Stick:** Camera control or secondary movement.
- **Action Buttons (A, B, X, Y):** Game-specific actions.
- **HOME Button:** Power on/off, pairing mode, return to home screen.

- **SELECT Button:** Game-specific function, often for menu or secondary actions.
- **START Button:** Game-specific function, often for pausing or starting.
- **L1/R1 (Shoulder Buttons):** Top trigger buttons.
- **L2/R2 (Trigger Buttons):** Bottom trigger buttons.

Supported Platforms and Game Compatibility

The Vikye X3 controller is designed to be compatible with a wide range of games and emulators that support gamepad functions. It offers different modes to simplify operation across various platforms.



Image: The controller with text stating "Support many games", "A variety of simulators and games that support handle functions can be compatible", "Smooth control lever, precise button and comfortable grip", "There are different modes for different games", and "While improving compatibility, it also simplifies the operation steps".

For optimal performance, ensure your device's operating system is up-to-date and that the game or application you are using supports external game controllers.

Using the Detachable Phone Holder

The included phone holder allows you to securely mount your smartphone directly onto the controller for a portable gaming setup.



Image: The controller shown with a smartphone attached to the holder, and the holder shown separately, demonstrating its attachment mechanism.

- Attach the holder to the designated slot on the top of the controller.
- Gently extend the clamps of the holder and place your smartphone securely within them.
- Ensure the phone is balanced and does not obstruct any buttons or ports.



Image: A person comfortably seated, actively playing a game using the Vikye X3 wireless controller, demonstrating typical usage.

Maintenance

Cleaning

- Wipe the controller with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals or abrasive cleaners.
- Avoid getting moisture into ports or openings.

Storage

- Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to about 50% to prolong its lifespan.

Battery Care

- Do not expose the battery to fire or high temperatures.
- Do not disassemble, crush, or puncture the battery.
- If the battery appears damaged or leaks, discontinue use immediately and dispose of it properly according to

local regulations.

Troubleshooting

Problem	Possible Cause	Solution
Controller does not power on.	Battery is depleted.	Charge the controller for at least 30 minutes.
Cannot connect via Bluetooth.	Controller not in pairing mode; Bluetooth interference; previously paired device.	Ensure controller is in pairing mode (flashing LED). Turn off Bluetooth on other devices. Forget the controller from your device's Bluetooth list and try pairing again.
Buttons or joysticks are unresponsive.	Connection issue; software glitch; low battery.	Reconnect the controller. Restart the game/device. Ensure battery is charged. Try resetting the controller (if applicable, usually a small pinhole button).
Phone holder is unstable.	Phone not properly seated; holder not securely attached.	Ensure phone is centered and firmly gripped by the holder. Verify the holder is fully clicked into place on the controller.

If you encounter issues not listed here, please refer to the support section or contact customer service.

Specifications

Feature	Detail
Model Number	Vikye15dhi4br7e
Connectivity	Bluetooth, Wired (USB)
Battery Capacity	400mAh Lithium Battery
Charging Time	Approx. 2 hours
Use Time	6-8 hours (approx.)
Dimensions (Package)	17.1 x 11.4 x 6.8 cm (6.73 x 4.49 x 2.68 inches)
Weight (Package)	210 grams (0.46 lbs)
Compatibility	Android, iOS, PC, Smart TV, VR (with compatible apps/games)
Origin	China

Warranty and Support

This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact your retailer.

For technical support, troubleshooting assistance, or inquiries regarding your Vikye X3 Wireless Game Controller, please contact the seller or manufacturer's customer service through the platform where you purchased the product. Please have your model number (Vikye15dhi4br7e) and purchase details ready when contacting support.

© 2024 Vikye. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I connect the Vikye X3 Wireless Game Controller to a PC?

To connect your Vikye X3 Wireless Game Controller to a PC, the manual recommends using a wired connection for the best results: Wired Connection: Connect the controller to your PC using the supplied USB...

Read full answer

Open the live page

https://manuals.plus/asin/B0BYFG26WL

More documents and user manuals: **https://manuals.plus/**