Vieta Pro 250438

Vieta Pro #Dance Bluetooth Speaker User Manual

Model: 250438

Introduction

Thank you for choosing the Vieta Pro #Dance Bluetooth Speaker. This portable speaker is designed to deliver powerful sound with the convenience of Bluetooth 5.0 connectivity, IPX7 waterproofing, and True Wireless Stereo (TWS) functionality. It also features a USB Type-C port for charging and a dedicated button for direct access to your virtual assistant. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.

Safety Information

- Do not expose the speaker to extreme temperatures or direct sunlight for prolonged periods.
- Keep the speaker away from sharp objects and corrosive materials.
- Ensure the USB Type-C port cover is securely closed when near water to maintain IPX7 waterproofing.
- Do not attempt to disassemble or repair the speaker yourself. This will void the warranty.
- Use only the provided charging cable or a certified USB Type-C cable for charging.
- Avoid listening at excessively high volumes for extended periods to prevent hearing damage.

Package Contents

- Vieta Pro #Dance Bluetooth Speaker
- USB Type-C Charging Cable
- User Manual

Product Overview




VIETA PRO
VIETA PRO
RoHS

Figure 1: Side view of the speaker highlighting the power button, volume controls, mode button, and LED indicators.



Figure 2: Top view of the speaker, featuring the central button with the Vieta Pro logo and an illuminated ring.

The Vieta Pro #Dance speaker features an intuitive control panel on its side, including power, volume up/down, mode selection, and a dedicated button for the virtual assistant. LED indicators provide feedback on battery status and connectivity. The top of the speaker houses the main control button, often illuminated, which can be used for various functions depending on the mode.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Locate the USB Type-C charging port, usually protected by a rubber flap to ensure waterproofing. Connect the provided USB Type-C cable to the speaker and the other end to a compatible USB power adapter (not included) or a computer's USB port. The LED indicators will show charging status and turn off or

change color when fully charged.

2. Powering On/Off

Press and hold the **Power button** (usually marked with a power symbol) for a few seconds until you hear an audible prompt or see the LED indicators light up. To power off, press and hold the same button again until the speaker shuts down.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode. It will typically enter pairing mode automatically on first power-on, indicated by a blinking blue LED.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices. You should see "Vieta Pro #Dance" or a similar name appear in the list.
4. Select the speaker name to connect. Once connected, the LED indicator will typically turn solid blue, and you may hear a confirmation tone.

4. True Wireless Stereo (TWS) Pairing

The TWS function allows you to pair two Vieta Pro #Dance speakers together for a stereo sound experience. You will need two speakers for this feature.

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one of the speakers (this will be the primary speaker), press the **Mode button** (often marked 'M' or a similar symbol) or a dedicated TWS button. The speaker will enter TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. Once connected, you will hear a confirmation sound, and their LED indicators will synchronize.
4. Now, connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section. Both speakers will play audio in stereo.

Operating

1. Music Playback

- **Play/Pause:** Press the main control button (on top) once to play or pause music.
- **Volume Up:** Press the **Volume + button**.
- **Volume Down:** Press the **Volume - button**.
- **Next Track:** Press and hold the **Volume + button** (or double-press the main control button, depending on model variation).
- **Previous Track:** Press and hold the **Volume - button** (or triple-press the main control button, depending on model variation).

2. Virtual Assistant Access

The speaker features a dedicated button for direct access to your smartphone's virtual assistant (Siri, Google Assistant, etc.). Press the **Virtual Assistant button** (often marked with a microphone icon or a specific symbol) once to activate the assistant. You can then speak your commands through the speaker's built-in microphone.

3. Handling Calls

- **Answer Call:** Press the main control button once when an incoming call rings.

- **End Call:** Press the main control button once during a call.
- **Reject Call:** Press and hold the main control button for 2 seconds when an incoming call rings.

4. IPX7 Waterproofing

The Vieta Pro #Dance speaker is IPX7 waterproof, meaning it can be submerged in water up to 1 meter (3 feet) for up to 30 minutes. This makes it ideal for use by the pool, at the beach, or in the shower. Ensure the USB Type-C port cover is fully sealed before exposing the speaker to water.



Figure 3: The speaker is designed to withstand water splashes and submersion, perfect for outdoor and wet environments.



Figure 4: Water resistance allows for worry-free use near pools or in rainy conditions.

Maintenance

- **Cleaning:** Use a soft, damp cloth to clean the speaker's surface. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is low or depleted.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker is not in pairing mode; device's Bluetooth is off; speaker is connected to another device.	Ensure speaker is in pairing mode (blinking blue LED). Turn on Bluetooth on your device. Disconnect from other devices.
No sound or low volume.	Volume on speaker or device is too low; speaker is not connected.	Increase volume on both speaker and connected device. Ensure successful Bluetooth connection.
TWS pairing fails.	Speakers are too far apart; one speaker is already connected to a device.	Place speakers closer together. Ensure both speakers are disconnected from other devices before TWS pairing.

Specifications

Brand: Vieta Pro

Model Number: 250438

Special Features: Bluetooth, IPX7 Waterproof, TWS (True Wireless Stereo), Virtual Assistant Access

Max Speaker Output Power: 25 Watts

Connectivity Technology: Bluetooth 5.0, USB Type-C

Audio Output Mode: Stereo

Compatible Devices: Laptop, Smartphone, Tablet

Controller Type: Button

Product Dimensions (L x W x H): 17.9 x 5.84 x 6.81 cm

Item Weight: 350 Grams

Manufacturer: FRAMASON AUDIO SA

Warranty and Support

Vieta Pro products are manufactured to the highest quality standards. For warranty information and technical support, please refer to the warranty card included with your product or visit the official Vieta Pro website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 Vieta Pro. All rights reserved.