Casio AP265

Casio AP265 Celviano Digital Piano User Manual

Model: AP265

Introduction

Thank you for choosing the Casio AP265 Celviano Digital Piano. This instrument combines advanced sound technology with a traditional piano feel, offering a rich musical experience. This manual provides essential information for the proper setup, operation, and maintenance of your digital piano. Please read it thoroughly before using the instrument to ensure safe and optimal performance.

Important Safety Information

To prevent electric shock, fire, or other damage, always observe the following precautions:

- **Power Supply:** Use only the specified AC adapter. Do not use the adapter if the cord is damaged.
- **Moisture:** Do not expose the instrument to rain or moisture. Do not place containers with liquids on the instrument.
- **Ventilation:** Ensure adequate ventilation. Do not block ventilation openings.
- **Placement:** Place the instrument on a stable, level surface. Avoid direct sunlight, extreme temperatures, or excessive dust.
- **Cleaning:** Use a soft, dry cloth for cleaning. Do not use abrasive cleaners or solvents.
- **Disassembly:** Do not attempt to disassemble or modify the instrument. Refer all servicing to qualified personnel.

Package Contents

Verify that all items are present in the package:

- Casio AP265 Celviano Digital Piano Unit
- Piano Bench
- AC Adapter

- Music Stand
- Pedal Unit (pre-attached or separate, depending on model revision)
- User Manual (this document)

Setup

1. Assembly

The Casio AP265 typically requires minimal assembly. Follow the detailed instructions provided in the separate assembly guide (if included) or the quick start guide. Key steps generally involve attaching the main piano unit to the stand and connecting the pedal unit.



Image: Angled view of the Casio AP265 Celviano Digital Piano, illustrating its assembled form with the music stand and pedal unit.

2. Power Connection

1. Ensure the piano's power switch is in the "OFF" position.
2. Connect the AC adapter to the DC IN terminal on the rear of the piano.
3. Plug the AC adapter into a standard wall outlet.

3. Pedal Unit

The AP265 features a three-pedal unit (Damper, Soft, Sostenuto) for expressive playing. Ensure the pedal unit cable is securely connected to the designated jack on the piano's underside or rear panel.

Operating Instructions

1. Power On/Off

- To turn on: Press the **POWER** button.
- To turn off: Press and hold the **POWER** button until the display turns off.

2. Volume Adjustment

Use the **VOLUME** knob or buttons to adjust the overall sound level. Rotate clockwise to increase volume, counter-clockwise to decrease.

3. Sound Selection

The AP265 offers a variety of instrument tones. Refer to the instrument panel for dedicated buttons or use the **FUNCTION** button combined with specific keys to select different tones (e.g., Grand Piano, Electric Piano, Strings).



Image: Front view of the Casio AP265 Celviano Digital Piano, highlighting the keyboard and control panel for sound selection and other functions.

4. Metronome

To activate the metronome, press the **METRONOME** button. Use the tempo controls to adjust the beat per minute (BPM). Press the button again to turn off the metronome.

5. Recording Function

The AP265 includes a built-in recorder. To record, press the **REC** button, then begin playing. Press **STOP** to end recording. Playback can be initiated by pressing the **PLAY** button.

6. Headphone Use

Connect standard 3.5mm stereo headphones to the headphone jacks located on the front or side of the piano. This will mute the internal speakers, allowing for private practice.

7. Connectivity (Auxiliary)

The auxiliary input (3.5mm jack) allows you to connect external audio devices (e.g., MP3 player, smartphone) and play along with your favorite music through the piano's speakers.

Maintenance

Cleaning

- Wipe the piano's surface with a soft, dry, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water and a mild, neutral detergent, then wipe dry immediately.

- Do not use benzene, alcohol, paint thinner, or other chemical agents, as they may discolor or damage the finish.
- Avoid spraying cleaning agents directly onto the instrument.

Storage

When not in use for extended periods, cover the piano with a dust cover to protect it from dust and dirt. Store in a location free from extreme temperatures, humidity, and direct sunlight.

Troubleshooting

Problem	Possible Cause	Solution
No sound	• Power not on • Volume too low • Headphones connected	• Press POWER button • Increase VOLUME • Disconnect headphones
Distorted sound	• Volume too high • External device issue	• Decrease VOLUME • Check external device connection/volume
Keys not responding	• Instrument mode issue • Internal malfunction	• Restart the piano • Contact customer support if problem persists

If the problem persists after attempting these solutions, please contact Casio customer support.

Specifications

Feature	Detail
Model	AP265
Number of Keys	88 (Scaled Hammer Action Keyboard II)
Instrument Type	Digital Piano
Connectivity	3.5mm Jack (Headphones), Auxiliary (3.5mm Jack)
Power Source	AC adapter
Skill Level	Beginner
UPC	079767362744

Warranty and Support

Casio products are manufactured to high-quality standards. For information regarding your product's warranty coverage, please refer to the warranty card included with your purchase or visit the official Casio website. For technical support, service, or parts, please contact Casio customer service through their official channels.
Official Casio Website: www.casio.com

© 2024 Casio Computer Co., Ltd. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question