Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zunate Zunatez3op72bxng

Zunate Air Conditioner Remote Control Instruction Manual

Model: Zunatez3op72bxng
Compatible with: R06/BGE, R09B/BGE, R09B/BGCE, R06/BG, R09C/BGE, Komeco, Comfee

1. Product Overview

This manual provides detailed instructions for the Zunate replacement air conditioner remote control. Designed for ease of use and broad compatibility, this remote allows you to control various functions of your air conditioning unit.

Key Features:

- Easy setup, simple operation, comfortable and convenient design.
- Simple programming and easy-to-read buttons.
- Multiple modes, including: fan, sleep, etc.
- Powerful enough for long-distance operation.



Figure 1.1: Front view of the Zunate Air Conditioner Remote Control, showing the display screen and all control buttons.

2. Setup and Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries correctly:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Note: *To prevent damage, remove the batteries when the remote control is not in use for an extended period.*



Figure 2.1: Open battery compartment showing slots for two AAA batteries.



Figure 2.2: Rear view of the remote control, indicating the location of the battery cover.

3. Operating Instructions

This section details the primary functions and how to use the buttons on your remote control.



Figure 3.1: The remote control held in hand, demonstrating its comfortable grip.

Button Functions:

- **Power Button (U):** Turns the air conditioner ON or OFF.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **FAN:** Adjusts fan speed (e.g., Auto, Low, Medium, High).
- **SWING:** Controls the vertical swing of the air deflector.
- **DIRECTION:** Adjusts the horizontal direction of the air deflector.
- **TIMER:** Sets a timer for the unit to turn ON or OFF.
- **CANCEL:** Cancels the currently set timer.
- **TURBO:** Activates rapid cooling or heating for a short period.
- **RESET LOCK:** Resets settings or locks the remote to prevent accidental changes.
- **CLOCK:** Sets the current time on the remote's display.

- **SLEEP:** Activates sleep mode, which adjusts temperature and fan speed for comfortable sleep.
- **LED:** Turns the display backlight ON or OFF.
- **Temperature Up/Down Arrows (▲ / ▼):**Adjusts the desired temperature setting.



Figure 3.2: Detailed view of the remote control's buttons for easy identification.



Figure 3.3: Close-up of the remote's display screen and the infrared (IR) emitter at the top.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

Battery Replacement:

Replace batteries when the display becomes dim or the remote's range decreases significantly. Always replace both batteries at the same time with new AAA batteries.

Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the surface or internal components.

5. Troubleshooting

If you encounter issues with your remote control, refer to the following common problems and solutions:

- **Remote not responding:**
    - Check if batteries are installed correctly with correct polarity.
    - Replace old batteries with new ones.
    - Ensure there are no obstructions between the remote and the air conditioner's receiver.

- Make sure you are within the maximum operating range (up to 10 meters).

- **Display is dim or blank:**
  - Batteries are low; replace them.
- **Remote range is short:**
  - Batteries may be weak; replace them.
  - Ensure the remote's infrared emitter is clean and unobstructed.

6. Specifications

Specification	Detail
Brand	Zunate
Model Name	Zunatez3op72bxng
Color	White
Compatible Devices	Air Conditioner
Controller Type	Remote Control
Rated Voltage	3V DC
Power Supply	2 x AAA Batteries (not included)
Maximum Range	10 Meters
Item Dimensions (L x W x H)	11 x 5.5 x 2.2 cm / 4.3 x 2.16 x 0.87 inches
Package Weight	55g
Country of Origin	China



Figure 6.1: Dimensions of the remote control.

7. Compatibility

This remote control is designed to be a replacement for various air conditioner models, including but not limited to:

- Komeco
- Comfee
- R06/BGCE
- R06/BGE
- R09B/BGE
- R09B/BGCE
- R06/BG
- R09C/BGE

8. Warranty and Support

For information regarding warranty coverage or technical support, please refer to the seller's policy or contact the manufacturer directly. Details are typically provided with your purchase documentation or on the product listing page.

© 2023 Zunate. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BYXSXWTV

More documents and user manuals: **https://manuals.plus/**