chefhandy BBW-9302

Chefhandy BBW-9302 Baby Bottle Warmer Instruction Manual

Model: BBW-9302

1. Introduction

Thank you for choosing the Chefhandy BBW-9302 Baby Bottle Warmer. This device is designed to safely and efficiently warm breast milk, formula, and baby food to an optimal temperature, ensuring your baby's nutrition is always ready. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the cord, plug, or the appliance itself in water or other liquids to protect against electrical hazards.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Always ensure water is added before switching on the appliance.
- Hot water and steam can cause severe burns. Exercise caution when the warmer contains hot water.

3. Product Overview

Components

Familiarize yourself with the parts of your Chefhandy BBW-9302 Baby Bottle Warmer:



Image: Labeled diagram of the Chefhandy BBW-9302 Baby Bottle Warmer showing its various parts.

1. Transparent Upper Cover
2. Baby Bottle Basket
3. Temperature Display
4. Time Display
5. Function Indicator (Fast, Keep, Food, Steam)
6. Function Mode Button (M)
7. Reduce Temperature/Time Button (-)
8. Add Temperature/Time Button (+)
9. Power Button

Key Features

The Chefhandy BBW-9302 offers 10-in-1 multifunctionality for comprehensive baby feeding solutions:



Image: Visual representation of the 10-in-1 multifunction features of the bottle warmer.

- Fast Warming
- Gentle Thaw
- Fast Thaw
- Keep Warm
- Steam Sterilization
- Food Heating
- Timer Function
- Adjustable Temperature
- Anti-scald Basket
- Smart Touch Controls

The warmer is designed to accommodate most baby bottle sizes, with an internal diameter of approximately 3.8 inches.



Image: The bottle warmer shown with various bottle types, highlighting its compatibility and 3.8-inch opening.

4. Setup

1. Unpack all components and remove any packaging materials.
2. Wipe the main unit with a damp cloth. Wash the transparent upper cover and baby bottle basket with warm soapy water, then rinse thoroughly and dry.
3. Place the warmer on a stable, flat, heat-resistant surface, away from children.
4. Ensure the power cord is easily accessible and not obstructed.

5. Operating Instructions

Before operating, ensure the warmer is plugged into a suitable power outlet.



Image: The bottle warmer's control panel displaying various functions and their default settings.

General Operation Steps:

1. Place the bottle or food jar into the baby bottle basket.
2. Add an appropriate amount of purified water into the warming chamber. The water level should be slightly below the bottle's neck or the food level.
3. Place the transparent upper cover over the basket.
4. Press the Power Button (**9**) to turn on the device.
5. Press the Function Mode Button (**M**) repeatedly to cycle through the desired warming modes (Fast, Keep, Food, Steam, Thaw). The selected mode will be indicated by the Function Indicator (**5**).

6. Use the Add Temperature/Time Button (+) and Reduce Temperature/Time Button (-) to adjust the temperature or time as needed.
7. The device will start heating automatically after a few seconds of inactivity or by pressing the Power button again to confirm.
8. Once the warming cycle is complete, carefully remove the bottle or food using the basket handle to avoid burns. Always check the temperature of the contents before feeding.

Specific Warming Modes:

- **Fast Warming:** Ideal for quickly heating milk. Adjustable time from 1-8 minutes, with a temperature range of 95°F-140°F (35°C-60°C).
- **Keep Warm:** Maintains milk at a desired temperature for up to 24 hours. Temperature range: 95°F-140°F (35°C-60°C).
- **Food Heating:** Suitable for warming baby food jars. Keeps warm for up to 2 hours. Temperature range: 86°F-176°F (30°C-80°C).
- **Steam Sterilization:** For sterilizing bottles and accessories. Adjustable time from 5-15 minutes, with a temperature range of 100°F-212°F (38°C-100°C).
- **Gentle Thaw / Fast Thaw:** Use these modes to safely defrost frozen breast milk or baby food. Follow recommended thawing guidelines for specific food types.

6. Maintenance

Cleaning:

- Always unplug the appliance and allow it to cool completely before cleaning.
- Do not immerse the main unit in water. Wipe the exterior with a damp cloth.
- The transparent upper cover and baby bottle basket can be washed with warm soapy water and rinsed thoroughly.
- To remove mineral deposits (limescale) from the heating plate, mix 50ml of white vinegar with 100ml of cold water. Pour the solution into the warming chamber and let it stand for 30 minutes. Do not turn on the appliance. Empty the solution and rinse the chamber thoroughly with clean water.
- Dry all parts completely before storing or next use.

7. Troubleshooting

- **Appliance does not turn on:** Ensure the power cord is securely plugged into a working outlet. Check if the power button has been pressed.
- **Milk not warming sufficiently:** Ensure enough water has been added to the warming chamber. Check if the correct warming mode and temperature setting have been selected. The initial temperature of the milk will affect warming time.
- **Display shows an error code:** Refer to the specific error code in the full manual (if available) or contact customer support. Often, this indicates insufficient water or an overheating issue.
- **Limescale buildup:** Follow the descaling instructions in the Maintenance section. Regular descaling is crucial for optimal performance.

8. Specifications

Specification	Detail
Model Number	BBW-9302
Dimensions (L x W x H)	25.91 x 13.79 x 13.11 cm
Item Weight	771 g
Batteries Required	No

9. Warranty and Support

For warranty information and customer support, please refer to the product packaging or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

© 2024 Chefhandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question