Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC042SR

ALLIMITY RC042SR Replacement Remote Control User Manual

Model: RC042SR

1. Introduction

Thank you for choosing the ALLIMITY RC042SR replacement remote control. This remote is designed to function as a direct replacement for your original Marantz AV Receiver remote, covering all essential functions. It is compatible with Marantz AV Receiver models NR1711, SR5015, and SR6015.

2. Setup

2.1. Battery Installation

The RC042SR remote control requires two (2) AAA batteries for operation. No programming is required; simply insert the batteries, and the remote will be ready to use with compatible models.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Figure 2.1: Back view of the remote control, highlighting the battery compartment. Ensure correct battery polarity when inserting.

3. Operating Instructions

The ALLIMITY RC042SR remote control is designed to replicate the functionality of your original Marantz AV Receiver remote. Once batteries are installed, it should operate immediately with compatible models.

3.1. Compatible Models

- Marantz AV Receiver NR1711
- Marantz AV Receiver SR5015
- Marantz AV Receiver SR6015

3.2. Basic Functions

The remote covers all functions of your original remote. Point the remote directly at your Marantz AV Receiver for optimal performance. Common functions include:

- **Power:** Turns the receiver on or off.
- **Input Selection:** Buttons for CBL/SAT, DVD, Blu-ray, GAME, AUX, MEDIA PLAYER, TV AUDIO, 8K, TUNER, USB, CD, Bluetooth, PHONO, INTERNET RADIO allow selection of various audio/video sources.
- **Volume Control:** Adjusts the master volume level.
- **Mute:** Silences the audio output.
- **Navigation:** Directional arrows (Up, Down, Left, Right) and ENTER button for menu navigation.
- **Menu/Setup:** Accesses the receiver's setup menu.
- **Smart Select:** Dedicated buttons (1-4) for quick access to pre-configured sound modes (Movie, Music, Game, Pure).





Figure 3.1: Front view of the ALLIMITY RC042SR remote control, displaying the layout of all buttons for various functions.



Figure 3.2: Angled view of the remote control, providing a perspective of its ergonomic design.

4. Maintenance

4.1. Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in water.

4.2. Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the AV Receiver's infrared sensor.

- Make sure you are within the effective operating range (approximately 33 feet).

- **Certain buttons not working:**
  - Verify that the remote is compatible with your specific Marantz AV Receiver model (NR1711, SR5015, SR6015).
  - Clean the remote's surface and buttons to ensure no debris is interfering with button presses.

- **Intermittent operation:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure consistent line of sight to the receiver.

6. Specifications

Brand	ALLIMITY
Model Number	RC042SR
Connectivity Technology	Infrared
Special Feature	Ergonomic
Compatible Devices	Marantz AV Receiver NR1711, SR5015, SR6015
Maximum Supported Devices	1
Number of Buttons	45
Controller Type	Remote Control
Maximum Range	33 Feet (approx. 10 meters)
Batteries Required	2 x AAA (not included)
Item Weight	87 Grams
Country of Origin	China

7. Warranty and Support

Specific warranty information for this product is not available in the provided documentation. For support or warranty inquiries, please refer to the seller's return policy or contact the seller directly through the platform where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BYYV8S8S

More documents and user manuals: **https://manuals.plus/**