Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EWA A117

EWA A117 Mini Portable Wireless Bluetooth Speaker User Manual

Model: A117

Introduction

This manual provides comprehensive instructions for the EWA A117 Mini Portable Wireless Bluetooth Speaker. It covers product features, setup, operation, maintenance, and troubleshooting to ensure optimal performance and user experience. The EWA A117 is a compact, powerful, and versatile Bluetooth speaker designed for portability and ease of use, featuring a magnetic base for attachment to metal surfaces and compatibility with MagSafe-enabled devices.



Image: The EWA A117 speaker in yellow, demonstrating its compact size and magnetic attachment feature with a smartphone.

What's Included

Upon unboxing your EWA A117 speaker, please verify that all the following components are present:

- 1 x EWA A117 magnetic mini Bluetooth speaker
- 1 x Micro USB charging cable
- 1 x Charger (Power adapter)
- 1 x User manual (This document)
- Warranty information (12-month warranty and 30-day risk-free guarantee)

Setup Guide

1. Charging the Speaker

Before initial use, fully charge the EWA A117 speaker. A full charge takes approximately 1.5 hours and provides up to 10 hours of playtime.

1. Connect the micro USB cable to the charging port on the speaker.
2. Connect the other end of the micro USB cable to the provided charger or a compatible USB power source.
3. The charging indicator light will illuminate. It will change or turn off once charging is complete.



Image: Visual representation of the EWA A117 speaker's charging duration (1.5 hours) and playback time (up to 10 hours).

2. Powering On/Off

- **To Power On:** Press and hold the power button (usually located on the side or bottom) for a few seconds until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the power button again for a few seconds until you hear an audible prompt or the indicator light turns off.

3. Bluetooth Pairing

The EWA A117 uses Bluetooth 5.0 for fast and reliable connectivity.

1. Ensure the speaker is powered on and in pairing mode (indicated by a blinking LED light, if applicable).
2. On your smartphone, tablet, or other Bluetooth-enabled device, navigate to the Bluetooth settings.
3. Search for available devices. You should see "EWA A117" or a similar name appear in the list.
4. Select "EWA A117" to connect. Once paired, you will hear a confirmation sound, and the indicator light will become solid.
5. Your device should automatically reconnect to the speaker in the future when both are powered on and within range.

Operating Instructions

Audio Playback

Once paired, audio from your connected device will play through the EWA A117 speaker. Control volume and playback (play/pause, skip tracks) directly from your connected device.



Image: An exploded diagram illustrating the internal components of the EWA A117 speaker, emphasizing its advanced 3W driver and passive subwoofer for powerful sound.

Magnetic Base Functionality

The EWA A117 features a powerful built-in magnet, allowing it to securely attach to various metal surfaces. This provides versatile placement options for your speaker.

- Simply place the speaker against any ferrous metal surface (e.g., refrigerator, gym equipment, golf cart frame, metal

shelving).

- Ensure the surface is clean and dry for optimal magnetic adhesion.



Image: The EWA A117 speaker demonstrating its magnetic attachment capability on a refrigerator, a golf cart, and a bathroom fixture.

Magnetic Phone Stand and Grip

Leverage the speaker's magnetic properties to use it as a convenient phone stand or grip, especially with MagSafe-compatible iPhones (iPhone 12, 13, 14, 15 Pro/Max series).

- Align the speaker's magnetic base with the MagSafe area on the back of your compatible iPhone or MagSafe-enabled phone case.
- The speaker will securely attach, allowing you to hold your phone more comfortably or prop it up for hands-free viewing.



Image: A series of images showing the EWA A117 speaker magnetically attached to an iPhone, functioning as both a grip and a stand for various viewing angles.



Image: A person holding an iPhone with the EWA A117 speaker magnetically attached to the back, illustrating its use as a comfortable grip.

Maintenance and Care

Waterproof Design

The EWA A117 speaker features a waterproof design, making it suitable for use in various environments such as the beach, poolside, camping, or picnics. While it is waterproof, avoid submerging it for extended periods or exposing it to high-pressure water jets.



Image: The EWA A117 speaker positioned on a white surface next to a swimming pool, with water splashing, demonstrating its waterproof capability.

Cleaning

- Wipe the speaker with a soft, damp cloth to remove dust or dirt.
- Do not use harsh chemicals, solvents, or abrasive cleaners, as these may damage the speaker's finish or internal components.
- Ensure the charging port cover is securely closed when not charging to maintain water resistance.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

Troubleshooting

If you encounter any issues with your EWA A117 speaker, please refer to the following common problems and solutions:

Speaker Does Not Power On

- **Check Battery:** Ensure the speaker is fully charged. Connect it to a power source and allow it to charge for at least 30 minutes before attempting to power on again.
- **Power Button:** Confirm you are pressing and holding the power button for the required duration (typically a few seconds).

Cannot Pair with Bluetooth Device

- **Speaker in Pairing Mode:** Make sure the speaker is powered on and in Bluetooth pairing mode (indicator light blinking).
- **Device Bluetooth On:** Ensure Bluetooth is enabled on your smartphone or tablet.
- **Distance:** Keep the speaker and your device within close proximity (within 1 meter) during pairing.
- **Forget Device:** If previously paired, try "forgetting" or "unpairing" the speaker from your device's Bluetooth list and then attempt to pair again.
- **Interference:** Move away from other wireless devices that might cause interference.

No Sound or Low Volume

- **Volume Levels:** Check the volume level on both the speaker and your connected device. Increase both.
- **Connection:** Ensure the speaker is successfully paired and connected to your device.
- **Audio Source:** Verify that the audio is playing from the correct source on your device.

Magnetic Attachment is Weak

- **Surface Material:** Ensure the surface is made of a ferrous metal (e.g., steel, iron). The magnet will not work on aluminum, plastic, or wood.
- **Surface Cleanliness:** A clean, flat surface provides the best magnetic adhesion. Remove any dust, dirt, or moisture.
- **Thickness:** Very thick or non-flat metal surfaces might reduce magnetic strength.

Product Specifications

Feature	Detail
Model Name	A117
Speaker Type	Subwoofer
Special Feature	Magnetic Back Snap
Recommended Uses	For Smartphones or Tablets
Compatible Devices	Smartphone, Tablet
Surround Sound Channel Configuration	1.0
Color	Yellow
Product Dimensions	2.25"D x 2.25"W x 2"H
Item Weight	0.12 Grams (0.004 ounces)
Waterproof	Yes
Control Method	Touch
Wireless Communication Technology	Bluetooth 5.0
Power Source	Battery Powered
Battery Type	1 Lithium Polymer battery (included)
Audio Driver Type	Dynamic Driver
Speaker Maximum Output Power	3 Watts
Audio Output Mode	Stereo
Mounting Type	Tabletop Mount (Magnetic)

Warranty and Support

The EWA A117 Mini Portable Wireless Bluetooth Speaker comes with a**12-month warranty** and a **30-day risk-free guarantee**.
If you experience any issues or are not completely satisfied with your product, please contact EWA customer support. Refer to the product packaging or the seller's information for specific contact details. It is recommended to contact support within 24 hours of identifying an issue for prompt assistance.
For further assistance, please visit the official EWA store or contact the seller directly through your purchase platform.

© 2023 EWA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZ4BL9Q1

More documents and user manuals: **https://manuals.plus/**