TESSAN TS-1021-C

TESSAN Ultra Thin Flat Extension Cord (Model TS-1021-C) Instruction Manual

Model: TS-1021-C | Brand: TESSAN

Introduction

Thank you for choosing the TESSAN Ultra Thin Flat Extension Cord. This manual provides essential information for the safe and efficient use of your new power strip. Designed for convenience and space-saving, this extension cord features a slim flat plug, a 10-foot thin cord, 3 AC outlets, 2 USB-A ports, and 1 USB-C port, making it ideal for various settings including homes, offices, dorm rooms, and travel.

Product Overview

The TESSAN Ultra Thin Flat Extension Cord is a versatile charging solution. Its compact design and multi-port functionality allow you to power and charge up to 6 devices simultaneously. The ultra-thin flat plug and cord are designed to minimize obstruction and fit in tight spaces.

Key Features:

- **Space-Saving Flat Plug:** Only 0.31 inches thick, designed to sit flush against the wall, allowing furniture to be placed closer to the outlet. The 45-degree right-angle plug prevents blocking adjacent receptacles.
- **10-Foot Thin Power Cord:** Provides extended reach and flexibility. The 0.12-inch flat cord can be discreetly routed under carpets, rugs, or doors to prevent tripping hazards.
- **6-in-1 Charging Station:** Equipped with 3 standard AC outlets, 2 USB-A ports, and 1 USB-C port for simultaneous charging of multiple devices.
- **USB Charging Capability:** The USB-C port delivers up to 3A, while the dual USB-A ports provide up to 2.4A, suitable for smartphones, tablets, earbuds, and laptops.
- **Mountable Design:** Features an extra mounting hole for secure installation on walls, floors, or under counters. Four rubber feet on the base prevent slipping on flat surfaces.



Image: Comparison of the TESSAN flat plug (left) and a standard plug (right), illustrating the significant space-saving benefit when placed behind furniture. The flat plug is only 0.31 inches thick, allowing furniture to sit flush against the wall.



Image: The 10-foot flat extension cord is shown running under a rug, demonstrating its ability to be hidden and prevent tripping hazards. The power strip is connected to a laptop and smartphone.

Setup Instructions

1. **Unpack the Device:** Carefully remove the TESSAN Ultra Thin Flat Extension Cord from its packaging. Ensure all components are present and undamaged.
2. **Choose an Outlet:** Select a standard 3-prong wall outlet. The flat plug design is particularly useful for outlets located behind furniture or in tight spaces.
3. **Plug In the Extension Cord:** Insert the flat plug into the wall outlet. The 45-degree angle ensures it does not obstruct the second receptacle.
4. **Position the Cord:** Route the 10-foot flat cord as needed. Its thin profile allows it to be placed under carpets, rugs, or along baseboards for a neat and safe setup.
5. **Secure the Power Strip (Optional):** If desired, use the mounting hole on the back of the power strip to secure it to a wall, desk, or other surface. Ensure the surface is stable and the mounting hardware (not included) is appropriate for

the weight of the power strip and connected devices. The non-slip rubber feet will help keep it stable on flat surfaces.



Image: The power strip is shown with its mounting hole and non-slip rubber feet, highlighting its versatile placement options on a nightstand or mounted to a wall.

Operating Instructions

1. **Connecting AC Devices:** Plug your devices into any of the 3 standard AC outlets on the power strip. Ensure the devices do not exceed the maximum wattage rating of the power strip.
2. **Connecting USB Devices:** Use the 2 USB-A ports or the 1 USB-C port to charge your compatible devices. Connect your device's USB charging cable to the appropriate port.
3. **Simultaneous Charging:** The power strip is designed to charge multiple devices efficiently at the same time. The USB-C port provides faster charging for compatible devices.



Image: A close-up view of the TESSAN power strip with multiple devices plugged into its 3 AC outlets, 2 USB-A ports, and 1 USB-C port, demonstrating its 6-in-1 functionality.



Image: The USB charging capabilities are highlighted, showing a tablet charging via USB-A and a smartphone via USB-C, with indicated maximum output currents.

Safety Information

- Do not exceed the maximum electrical rating of 125V.
- Avoid using in wet or damp conditions. This product is for indoor use only.
- Do not disassemble or modify the power strip.
- Keep out of reach of children and pets.
- Ensure plugs are fully inserted into the outlets.
- Do not use with appliances that require continuous supervision, such as coffee makers or heaters.

Maintenance

- Keep the power strip clean and free from dust.
- Wipe with a dry cloth only. Do not use liquid cleaners.

- Inspect the cord and plug periodically for any signs of damage. If damaged, discontinue use immediately and replace the unit.

Troubleshooting

- **No Power to Devices:**
  - Ensure the flat plug is securely inserted into the wall outlet.
  - Check if the wall outlet itself is functioning by plugging in another device.
  - Verify that the total wattage of connected devices does not exceed the power strip's maximum rating.
- **Slow Charging via USB Ports:**
  - Ensure your device's charging cable is not damaged and is compatible with the power strip's USB output.
  - Some devices may charge slower if multiple high-power devices are connected simultaneously.

Specifications

Feature	Detail
Model Number	TS-1021-C
Product Dimensions	2.04 x 1.46 x 3.07 inches
Item Weight	9.3 ounces
Total Power Outlets	3 AC Outlets
USB Ports	2 USB-A, 1 USB-C
Voltage	125 Volts
Special Features	Mountable, Wide Spaced Outlet, Flat Plug, Thin Cord
Cord Length	10 feet

Warranty and Support

For warranty information or technical support, please refer to the product packaging or visit the official TESSAN website. If you encounter any issues not covered in this manual, please contact TESSAN customer service for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question