Ariete 8210

Ariete 8210 Convector Heater User Manual

Model: 8210

1. Important Safety Instructions

Please read all instructions carefully before using this appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before cleaning or performing any maintenance.
- Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.
- Do not cover the heater. Overheating may occur if the heater is covered.
- Keep flammable materials such as furniture, curtains, and bedding at least 1 meter (3 feet) from the front and sides of the heater.
- This appliance is equipped with an **overheat protection system**. If the heater overheats, it will automatically shut off. Unplug the heater, allow it to cool down, and then plug it back in. If the issue persists, contact customer support.
- The heater also features an **anti-tilt switch** that automatically turns off the unit if it is accidentally knocked over. Ensure the heater is placed on a stable, flat surface.
- Do not insert any objects into the heater's openings.
- This appliance is for indoor use only.

2. Product Overview

The Ariete 8210 Convector Heater is designed to provide efficient and quiet heating for your indoor spaces. It features multiple power settings, an adjustable thermostat, and a turbo fan for enhanced heat distribution.



Figure 2.1: Front view of the Ariete 8210 Convector Heater, showing the main body, control panel, and feet.



Figure 2.2: The Ariete 8210 Convector Heater highlighting its turbo fan, eco-friendly design, and three power levels.



Figure 2.3: Detail of the Ariete 8210 Convector Heater emphasizing its silent operation, suitable for relaxation.

Key Features:

- **3 Power Levels:** 800W, 1200W, and 2000W for flexible heating.
- **Adjustable Thermostat:** Allows precise temperature control.
- **Turbo Fan:** For rapid and efficient heat distribution.
- **Overheat Protection:** Automatic safety shut-off.
- **Anti-tilt Switch:** Enhances safety by turning off if tipped.
- **Silent Operation:** Designed for minimal noise during use.

3. Setup

3.1 Unpacking

Carefully remove the heater from its packaging. Retain the packaging for storage or in case of return. Check for any

signs of damage. If the appliance appears damaged, do not use it and contact customer support.

3.2 Placement

- Place the heater on a firm, level, and stable surface to prevent tipping.
- Ensure there is at least 1 meter (3 feet) of clear space around the heater from walls, furniture, curtains, and other flammable objects.
- Do not place the heater directly below a power outlet.
- Avoid placing the heater in areas where it could be easily knocked over or where children or pets could come into contact with it.



Figure 3.1: The Ariete 8210 Convector Heater positioned safely in a bedroom, demonstrating appropriate clearance from bedding.



Figure 3.2: The Ariete 8210 Convector Heater placed in a living room, illustrating safe distance from furniture and decor.

3.3 Power Connection

Plug the power cord into a suitable 220V AC electrical outlet. Ensure the outlet is in good condition and not overloaded with other appliances.

4. Operating Instructions

4.1 Power On/Off

Locate the main power switch on the control panel. Press the switch to the 'ON' position to power on the heater. Press it to the 'OFF' position to turn off the heater.

4.2 Adjusting Power Levels

The Ariete 8210 offers three power settings: 800W, 1200W, and 2000W. Use the power selection switches on the control panel to choose your desired heating output:

- **800W:** For low heat or maintaining warmth.
- **1200W:** For medium heat.
- **2000W:** For maximum heat output and faster room warming.

4.3 Using the Adjustable Thermostat

The adjustable thermostat allows you to set the desired room temperature. Turn the thermostat dial clockwise to increase the temperature setting and counter-clockwise to decrease it. The heater will cycle on and off to maintain the set temperature.



Figure 4.1: Close-up of the control panel, indicating the adjustable thermostat dial for precise temperature regulation.

4.4 Turbo Fan Operation

Engage the turbo fan function to quickly circulate warm air throughout the room. This feature can be used in conjunction with any of the power settings for enhanced heating performance.

5. Maintenance

5.1 Cleaning

Always unplug the heater and allow it to cool completely before cleaning.

- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Do not immerse the heater in water or any other liquid.
- Periodically clean the air intake and outlet grilles with a vacuum cleaner brush attachment to remove dust and debris.

5.2 Storage

When not in use, store the heater in a cool, dry place, preferably in its original packaging, away from direct sunlight and moisture.

6. Troubleshooting

- **Heater does not turn on:**
  - Check if the power cord is securely plugged into a working outlet.
  - Ensure the main power switch is in the 'ON' position.
  - Verify if the overheat protection or anti-tilt switch has been activated. Unplug, wait for cooling, and reset.
- **Heater produces no heat:**
  - Check the power level settings.
  - Ensure the thermostat is set to a temperature higher than the current room temperature.
- **Unusual noise or smell:**
  - A slight odor or noise may occur during initial use; this is normal and should dissipate.
  - If persistent or strong, unplug the heater immediately and contact customer support.

If you experience any issues not covered here, or if troubleshooting steps do not resolve the problem, please contact customer support.

7. Specifications

Brand	Ariete
Model Number	8210
Power Levels	800W, 1200W, 2000W
Voltage	220 Volts (AC)
Dimensions (L x W x H)	58 x 17 x 42 cm (approximately)
Item Weight	4.66 Kilograms
Special Features	Adjustable Thermostat, Overheat Protection, Anti-tilt Switch, Turbo Fan
Heating Method	Convection
Indoor/Outdoor Use	Indoor Use Only

8. Warranty and Support

8.1 Warranty Information

This product comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase or contact your retailer for specific details regarding warranty coverage and duration.

8.2 Customer Support

For technical assistance, spare parts, or any questions regarding your Ariete 8210 Convector Heater, please contact

Ariete customer service or your authorized dealer. Contact information can typically be found on the product packaging or the official Ariete website.

© 2025 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question