Psisuvry HC

Psisuvry HC 3.2 Cubic Feet Home Safe Instruction Manual

Model: HC

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Psisuvry HC 3.2 Cubic Feet Home Safe. Please read this manual thoroughly before using the safe to ensure proper function and security. Keep this manual for future reference.

2. Safety Information

- **Emergency Keys:** Always store the emergency keys in a secure location away from the safe. Do not store them inside the safe.
- **Battery Replacement:** Replace batteries promptly when the low battery indicator appears to avoid being locked out.
- **Mounting:** For enhanced security, it is recommended to securely mount the safe to a wall or floor using the provided hardware. Be aware that drilling holes for mounting may affect the safe's water and fire resistance properties if not properly sealed.
- **Children:** Keep the safe locked and out of reach of children to prevent unauthorized access.

3. Package Contents

Verify that all items are present in the package:

- 1 x Psisuvry HC 3.2 Cubic Feet Home Safe
- 2 x Emergency Keys
- 4 x Mounting Screws
- 4 x Expansion Bolts
- 1 x External Battery Box
- 1 x User Manual (this document)
- 1 x Removable Shelf



Figure 3.1: Product Dimensions and Included Components

4. Product Overview

The Psisuvry HC Home Safe is designed to protect your valuables with a robust construction and advanced locking mechanisms.

4.1 Key Features

- **Dual Anti-Theft Locking System:** Features an electronic digital keypad for quick access and a physical key for emergency override.
- **Solid Steel Construction:** Enhanced anti-burglar performance with anti-pry, anti-drilling, and anti-collision design.
- **Removable Shelf:** Allows for flexible storage options to accommodate various item sizes.
- **Built-in Interior Light:** Automatically illuminates when the safe is opened for visibility in dark environments.
- **Anti-Theft Alarm System:** Activates after 3 incorrect code entries.
- **External Battery Compartment:** Provides a way to power the keypad if internal batteries are depleted.



Figure 4.1: Interior View and Dimensions of the Safe



Figure 4.2: Removable Shelf for Flexible Storage



Figure 4.3: Security Features of the Safe



Figure 4.4: Locking Mechanism and Emergency Access

5. Setup

5.1 Battery Installation

1. Open the safe using the emergency key (refer to Section 6.3).
2. Locate the battery compartment on the inside of the door.
3. Insert 4 AA batteries (not included) according to the polarity indicators (+/-).
4. Close the battery compartment cover.

5.2 Initial Code Setting

1. With the safe door open, press the red reset button located on the inside of the door. You will hear a beep.
2. On the keypad, enter a new 3-8 digit code.
3. Press the '#' button to confirm. The safe will beep again, indicating the new code is set.
4. Test the new code with the door open before closing it.

5.3 Mounting the Safe

For optimal security, it is highly recommended to mount the safe to a solid surface such as a wall or floor.

1. Choose a suitable location for mounting.
2. Mark the drilling points through the pre-drilled holes at the back or bottom of the safe.
3. Drill pilot holes in the marked locations using an appropriate drill bit for your wall or floor material.
4. Align the safe with the drilled holes.
5. Secure the safe using the provided mounting screws and expansion bolts. Ensure all fasteners are tightened securely.



Figure 5.1: Example of Wall or Floor Mounted Installation



Figure 5.2: Wall Mounting Installation Steps

6. Operating Instructions

6.1 Opening the Safe with Digital Keypad

1. Enter your programmed 3-8 digit code.
2. Press the '#' button. The green light will illuminate.
3. Within 5 seconds, turn the knob clockwise to open the door.

6.2 Changing the User Code

1. Open the safe door.
2. Press the red reset button on the inside of the door. You will hear a beep.
3. Enter your new 3-8 digit code on the keypad.
4. Press the '#' button to confirm. The safe will beep again.
5. Test the new code with the door open before closing it.

6.3 Using the Emergency Key

The emergency key provides access if you forget your code or if the batteries are depleted.

1. Locate the emergency keyhole, usually hidden behind a cover on the keypad panel.
2. Insert the emergency key and turn it counter-clockwise.
3. While holding the key turned, turn the knob clockwise to open the door.

6.4 Anti-Theft Alarm System

The safe is equipped with an alarm system that activates if 3 incorrect codes are entered consecutively. The alarm will sound for a period and the keypad will be temporarily locked.



Figure 6.1: Anti-Theft Alarm System

7. Maintenance

- **Cleaning:** Clean the safe's exterior with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** Replace the batteries annually or when the low battery indicator lights up to ensure

reliable operation of the electronic lock.

- **Keypad Care:** Keep the keypad dry and free from dust or debris.

8. Troubleshooting

Problem	Possible Cause	Solution
Safe does not open with code.	Incorrect code entered, dead batteries, keypad malfunction.	Re-enter code carefully. Replace batteries. Use emergency key.
Keypad is unresponsive.	Dead batteries, temporary keypad lock (after incorrect entries).	Replace batteries. Wait for the alarm to stop and keypad to reset. Use external battery box if needed.
Alarm sounds unexpectedly.	3 incorrect code entries, physical tampering.	Enter correct code to disarm. Check for signs of tampering.
Door does not close properly.	Obstruction, misalignment.	Check for items blocking the door. Ensure the safe is on a level surface.

9. Specifications

Feature	Detail
Brand	Psisuvry
Model Number	HC
Capacity	3.2 Cubic Feet
Product Dimensions (D x W x H)	12.2"D x 14.5"W x 19.7"H
Item Weight	28.6 Pounds
Lock Type	Electronic Combination Lock, Key
Material	Alloy Steel
Color	Black
Special Features	Alarm System, Anti-Theft, Combination Lock, Removable Shelf, Scratch Resistant
Mounting Type	Wall & Floor Mount
Batteries Required	Yes (4 x AA, not included)

10. Warranty and Support

Your Psisuvry HC Home Safe comes with the following:

- **Warranty:** 3-Year Warranty.
- **Return/Exchange Policy:** 6-year return/exchange policy.
- **Technical Support:** Lifetime technical support.

For any questions, technical assistance, or warranty claims, please contact Psisuvry customer support. Refer to the product packaging or the retailer's website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question