Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY RC45157

ALLIMITY RC45157 Replacement Remote Control User Manual

Model: RC45157 | Brand: ALLIMITY

Introduction

This manual provides comprehensive instructions for the ALLIMITY RC45157 replacement remote control. It is designed to function as a direct replacement for original remote controls of various JVC and Continental Edison television models. No programming is required; simply insert batteries to begin operation.

Setup

Inserting Batteries

To power your remote control, follow these steps to correctly insert the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Image: Back view of the remote control, highlighting the battery compartment cover. This is where two AAA batteries are inserted.

Once batteries are inserted, the remote control is ready for immediate use with compatible TV models. No additional programming or pairing is required.

Operating Instructions

Remote Control Layout





Image: Front view of the ALLIMITY RC45157 remote control, displaying all buttons and their labels.

The ALLIMITY RC45157 remote control features a standard layout for easy navigation and control of your television. Key functions are grouped logically.

Basic Functions

- **Power Button ( ):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **LANG. Button:** Changes audio language or subtitle options.
- **Volume Up/Down (V+/V-):** Adjusts the sound volume.
- **Mute Button ( ):** Mutes or unmutes the TV sound.
- **Channel Up/Down (P+/P-):** Changes the TV channel.
- **Home Button ( ):** Accesses the TV's home screen or smart TV interface.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **EXIT Button:** Exits the current menu or application.
- **NETFLIX, YouTube, Google Play, Prime Video Buttons:** Direct access to streaming applications.
- **MENU Button:** Opens the TV's main menu.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop):** Controls media playback.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within certain menus or applications.
- **TEXT Button:** Accesses teletext services if available.

Compatible TV Models

The ALLIMITY RC45157 remote control is compatible with a wide range of JVC and Continental Edison television models. This remote functions immediately upon battery insertion for the following models:

- **JVC Models:** LT-43VA3205I, LT-24VAH325I, LT-32VAH325I, LT-65VA3205I, LT-32VAH32IW, LT-40VAF325I, LT-50VA3215I, LT-65VA3215I, LT-43VA3000, LT-55VA3035, LT-65VA3000, LT-40VAF3100, LT-55VAQ6235, LT-65VA3055, LT-55VA3200, LT-50VA3000, LT-24VAH3000, LT-32VAF3035, LT-55VAQ8235, LT-43VAQ7235, LT-55VA3055, LT-65VA3200, LT-32VAH3000, LT-43VAF3000, LT-32VAF5035, LT-65VAQ8235, LT-50VAQ7235, LT-43VAF3055, LT-65VAQ6235, LT-32VAF3000, LT-24VAH3055, LT-32VAH305D, LT-43VAQ6235, LT-55VAQ7235, LT-24VAH3035, LT-24VAH32IW, LT-55VA3205I, LT-43VA3035, LT-39VAH3000, LT-58VA3035, LT-50VAQ6235, LT-43VA3200, LT-50VA3200.
- **Continental Edison Models:** CELED43SA22B3, CELED32SAHD23B3, CELED55SA222B3, CELED65UHDSA22B3, CEQLED65SA22B3, CELED40SA22B3.

This list includes models mentioned in the product description and feature bullets. If your TV model is not listed but uses a similar original remote, this replacement may still be compatible.

Troubleshooting

If you experience issues with your ALLIMITY RC45157 remote control, please refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Check the batteries. Ensure they are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones. Weak batteries are a common cause of remote control malfunction.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Point the remote directly at the TV's IR sensor.
- **Buttons Not Working:**
  - Test all buttons. If only some buttons are unresponsive, there might be a physical issue with those specific buttons.
  - Clean the remote control. Dust or debris under the buttons can sometimes prevent them from registering presses. Use a soft, dry cloth.
- **Limited Functionality:**
  - While this remote is a direct replacement, some advanced or very specific functions of your original TV remote might not be replicated if they are unique to your TV model and not standard IR commands.
  - Ensure your TV model is listed in the compatible models section.

If problems persist after following these steps, consider contacting the seller for further assistance.

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	RC45157
Color	Black
Connectivity Technology	Infrared (IR)
Special Features	Ergonomic design
Maximum Range	10 Meters
Controller Type	Button Control

Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials, which can damage the surface or internal components.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

- **Handling:** Avoid dropping the remote control or subjecting it to strong impacts, as this can damage internal circuitry.

Warranty and Support

This product is typically covered by a standard manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the documentation provided at the time of purchase or contact the seller directly.
For technical support or further assistance with your ALLIMITY RC45157 remote control, please reach out to the retailer or manufacturer through their official support channels. When contacting support, please have your product model number (RC45157) and details of your issue readily available.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZNQM9FN

More documents and user manuals: **https://manuals.plus/**