Sherilyn 22SE

Sherilyn Kids Play Tent with Padded Mat User Manual

Model: 22SE | Brand: Sherilyn

Introduction

Thank you for choosing the Sherilyn Kids Play Tent with Padded Mat. This play tent is designed to provide a comfortable and engaging space for children, fostering imaginative play and relaxation. This manual contains important information regarding the assembly, safe operation, and maintenance of your new play tent. Please read it thoroughly before assembly and retain it for future reference.

Important Safety Information

To ensure the safety of children and prevent damage to the product, please adhere to the following guidelines:

- **Adult Supervision:** Always ensure children are supervised by an adult while playing in or around the tent.
- **Assembly:** Assembly must be performed by an adult. Keep small parts away from children during assembly.
- **Placement:** Place the tent on a flat, stable surface indoors. Avoid placing near open flames, heaters, or other heat sources.
- **Ventilation:** Ensure adequate ventilation. Do not cover the tent completely with non-breathable materials.
- **Choking Hazard:** Regularly inspect the tent for any loose parts, strings, or small components that could pose a choking hazard.
- **Structural Integrity:** Do not allow children to climb on the tent frame or hang from its structure, as this may cause instability or damage.
- **Cleaning:** Follow the cleaning instructions carefully to maintain hygiene and product longevity.

What's Included

Please verify that all components are present before beginning assembly:

- Tent Fabric (Main cover with integrated curtains and window details)
- Support Poles (Various lengths for frame construction)
- Connectors (For joining poles)

- Padded Mat (One piece, machine washable)
- Assembly Instructions (Printed manual)



Figure 1: The included padded mat, designed to fit the base of the tent, offering a comfortable surface for play and rest. It is machine washable for easy cleaning.

Setup and Assembly

Assembly of the Sherilyn Kids Play Tent is designed to be straightforward and can typically be completed by one adult within 10 minutes without additional tools. Follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all listed components are present.
2. **Assemble Base Frame:** Connect the appropriate support poles using the connectors to form the rectangular base of the tent. Ensure all connections are secure.

3. **Construct Vertical Supports:** Attach the vertical support poles to the corners of the base frame.
4. **Form Roof Structure:** Connect the roof poles to the top of the vertical supports and join them at the peak to create the tent's roof frame.
5. **Drape Tent Fabric:** Carefully drape the tent fabric over the assembled frame. Ensure the fabric is aligned correctly, with the window and door openings positioned as desired.
6. **Secure Fabric:** Fasten the tent fabric to the frame using any integrated ties or loops provided. Ensure the fabric is taut and evenly distributed.
7. **Place Padded Mat:** Lay the padded mat inside the tent on the base.
8. **Final Adjustments:** Adjust the curtains and any decorative elements as desired.



Figure 2: An illustration of the tent's structure, showing the frame and fabric in place. This image provides a visual guide for the assembly process.



Figure 3: Detailed view of the tent's cream fabric, breathable window, and elegant gauze curtains with cute pompoms. The window features ties for opening and closing, and the curtains can be tied back for an open feel.

Operating Instructions

The Sherilyn Kids Play Tent is designed for indoor use as a personal play space or a cozy retreat. Its simple design allows for versatile use:

- **Play Area:** Children can use the tent for imaginative play, reading, or quiet activities. The spacious interior can accommodate multiple children or even an adult.
- **Resting Nook:** The included padded mat provides a comfortable surface for napping or relaxing.
- **Curtain Management:** The tent features both sheer and cloth curtains. These can be tied back for an open, airy feel or closed for privacy and a cozy atmosphere. The window also has ties for adjustment.



Figure 4: A child enjoying the spacious interior of the play tent, which includes the padded mat and decorative elements. The tent offers ample room for various activities.

Maintenance and Care

Proper care will extend the life and appearance of your play tent:

- **Tent Fabric:** The tent fabric can be spot cleaned with a damp cloth and mild soap. For deeper cleaning, it may be hand washed or machine washed on a delicate cycle with cold water. Air dry thoroughly. Do not bleach or tumble dry.
- **Padded Mat:** The padded mat is machine washable. Wash on a gentle cycle with cold water and mild detergent. Tumble dry on low heat or air dry flat.
- **Frame:** Wipe the support poles and connectors with a damp cloth as needed. Ensure they are dry before storage.
- **Storage:** When not in use, disassemble the tent and store all components in a clean, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter any issues with your play tent, please refer to the following common solutions:

Problem	Possible Cause	Solution
Tent is unstable or wobbly.	Poles not fully connected; uneven surface.	Ensure all poles are securely inserted into connectors. Place the tent on a flat, level surface.
Fabric does not fit correctly.	Incorrect orientation of fabric; frame not fully assembled.	Review assembly steps to ensure the frame is correctly built. Re-drape the fabric, ensuring proper alignment with openings.
Missing parts.	Packaging error.	Contact Sherilyn customer support with your purchase details for assistance.

Specifications

- **Product Dimensions:** 35.5 x 57 x 53 inches (Width x Length x Height)
- **Item Weight:** 9.01 pounds
- **Model Number:** 22SE
- **Manufacturer:** Sherilyn
- **Recommended Age:** 18 months - 5 years



Figure 5: A visual representation of the play tent's dimensions, indicating its length, width, and height for reference.

Warranty and Support

For any questions, concerns, or to report missing or damaged parts, please contact Sherilyn customer support. While specific warranty details are not provided in this manual, most products come with a standard manufacturer's warranty against defects. Please refer to your purchase documentation or contact the seller for detailed warranty information.
Contact Information: Please refer to the contact details provided with your purchase or visit the official Sherilyn brand store on Amazon for support options.

Visit the Sherilyn Store on Amazon

© 2025 Sherilyn. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I find the PDF setup instructions for the Sherilyn 22SE Kids Play Tent, and can they be emailed to me?

While we cannot email files directly to you, you can access the full setup instructions for your Sherilyn 22SE Kids Play Tent right here on this page. The manual is available in a web-friendly...

Read full answer