Razee USRP-22

Razee Kids Play Tent Instruction Manual

Model: USRP-22

Introduction

The Razee Kids Play Tent is a large, hand-made playhouse designed for indoor and outdoor use, providing a comfortable and safe environment for children. Its sturdy construction ensures durability for years of imaginative play. This manual provides essential information for assembly, operation, and maintenance of your play tent.

What's in the Box

Upon unpacking, please ensure all components listed below are present:

- Play Tent Fabric Cover
- Support Poles (various sizes)
- Connectors
- Play Mat
- Decorative Pennant Banners
- String Lights (battery-operated)

Setup Instructions

Assembly of the Razee Kids Play Tent is designed to be straightforward and typically takes only a few minutes. Follow these steps for proper setup:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Identify the different lengths of support poles and the various connectors.
2. **Assemble Base Frame:** Connect the shortest poles using the appropriate connectors to form the rectangular base of the tent. Ensure all connections are secure and fully inserted.
3. **Install Vertical Poles:** Insert the longer vertical poles into the corner connectors of the base frame.
4. **Construct Roof Frame:** Use the remaining poles and connectors to form the triangular roof structure. Connect these to the tops of the vertical poles.
5. **Drape Fabric Cover:** Carefully drape the tent fabric cover over the assembled pole structure. The cover is a single

piece designed to fit snugly over the frame. Ensure the window cutouts and door openings align correctly with the frame.

6. **Secure Fabric:** The fabric cover has sleeves or ties that secure it to the poles. Ensure all attachment points are properly fastened to keep the tent stable.
7. **Place Play Mat:** Lay the included play mat on the floor inside the tent. The mat is sized to fit the tent's base.
8. **Add Decorations:** Attach the pennant banners to the front or top of the tent as desired. Install the string lights along the interior roof poles for a cozy ambiance. Ensure batteries are inserted correctly into the light unit.

Visual Aid: While no official seller video is available for assembly, the process involves connecting plastic poles to form a house-like frame and then fitting the fabric cover over it. The base is a rectangle, with vertical poles at the corners and a triangular roof structure. The fabric slides over this frame, securing it in place.



Image: The fully assembled Razee Kids Play Tent, demonstrating its spacious interior and functional windows.

Operating the Play Tent

The Razee Kids Play Tent is designed for versatile play and relaxation. Here are some operational features:

- **Door Openings:** The front opening of the tent can be tied back to remain open, allowing easy access and an open play area. To create a more secluded space, untie the fabric and let it hang down, covering the entrance.
- **Windows:** The tent features breathable windows on the sides. These can be left open or tied back with integrated ties for ventilation or to allow light in.
- **String Lights:** The included string lights are battery-operated and can be turned on or off using the switch on the battery pack. Position them along the interior roof poles to create a warm and inviting atmosphere, especially during evening play or quiet time.



Image: Detailed view of the tent's features, highlighting the breathable window, tie-back options for the entrance, and the texture of the fabric and mat.

Maintenance

To ensure the longevity and cleanliness of your Razee Kids Play Tent, follow these maintenance guidelines:

- **Fabric Cleaning:** The tent fabric is made from durable material. For general cleaning, spot clean with a damp cloth and mild soap. For a more thorough cleaning, the fabric cover can be removed from the frame and is machine

washable. Use cold water on a gentle cycle and air dry to prevent shrinking or damage.

- **Play Mat Cleaning:** The included play mat is machine washable. Wash with cold water on a gentle cycle and air dry.
- **Pole Care:** Wipe down the support poles with a damp cloth as needed. Ensure they are dry before reassembling or storing to prevent mildew.
- **Storage:** When not in use, the tent can be easily de-constructed and stored in its original packaging or a suitable storage bag to protect it from dust and damage.

Troubleshooting

If you encounter any issues with your play tent, consider the following common solutions:

Problem	Possible Cause	Solution
Tent feels unstable or wobbly.	Poles not fully inserted into connectors.	Ensure all poles are pushed firmly into their respective connectors until they click or are fully seated.
Fabric cover does not fit correctly.	Incorrect pole assembly or fabric misalignment.	Double-check the pole lengths against the assembly guide to ensure they are in the correct positions. Re-drape the fabric, ensuring it is evenly distributed over the frame.
String lights not working.	Dead batteries or incorrect battery insertion.	Replace batteries with fresh ones. Ensure batteries are inserted with correct polarity (+/-). Check the on/off switch.

Specifications

Feature	Detail
Brand	Razee
Model Number	USRP-22
Product Dimensions	57" L x 35.5" W x 53" H (35.5 x 57 x 53 inches)
Item Weight	9.1 pounds
Material	Fabric (no smell, safe for kids)
Recommended Age	36 months - 12 years
Included Accessories	Play Mat, Pennant Banners, String Lights

Warranty and Support

For information regarding product warranty, returns, or additional support, please refer to the purchase documentation or contact Razee customer service directly. Contact details can typically be found on the product packaging or the official Razee website.

© 2025 Razee. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can you provide the assembly instructions and a diagram for the Razee USRP-22 Kids Play Tent, specifically detailing which poles and lettered connectors to use for each side?

While the provided manual for the Razee USRP-22 Kids Play Tent describes the assembly steps, it does not include a letter-coded diagram. However, you can follow these structural steps to identify which poles go...

Read full answer

Where can I find the assembly manual for the Razee USRP-22 Kids Play Tent?

You can follow these assembly steps for the Razee Kids Play Tent (Model: USRP-22) to rebuild the frame and attach the cover:Unpack and Identify: Lay out all components. You should have support poles of...

Read full answer