Razee USRP-22

Razee Kids Play Tent Instruction Manual

Model: USRP-22 | Brand: Razee

1. Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Recommended Age:** This play tent is suitable for children aged 36 months to 12 years. Adult supervision is recommended at all times.
- **Material Safety:** The tent is made from fabric that is free from strong odors and safe for children.
- **Assembly:** Ensure all parts are securely connected during assembly to prevent collapse.
- **Usage:** Do not allow children to climb on the tent structure or hang from its frame. This product is designed for play and relaxation, not for rough play or jumping.
- **Lighting:** The included string lights require 2 AA batteries. Ensure batteries are inserted correctly and the battery pack is secured away from small children.

2. Package Contents

Verify that all components are present before beginning assembly:

- Play Tent Fabric Cover
- Assembly Poles (PVC piping)
- Connectors
- Quilted Play Mat
- Decorative String Lights (battery-operated)
- Colorful Pennant Banners

3. Setup and Assembly

The Razee Kids Play Tent is designed for easy and quick assembly, typically taking only a few minutes. No special tools are required.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out.
2. **Assemble Frame:** Connect the PVC piping poles using the provided connectors. Ensure that both ends of each

pole are fully inserted into the connectors. You can shine a light behind the connection point to verify full insertion.

3. **Drape Tent Fabric:** Carefully drape the tent fabric cover over the assembled frame. Ensure the fabric is aligned correctly with the frame's structure.
4. **Secure Fabric:** Use the ties on the tent fabric to secure it to the frame at designated points.
5. **Insert Play Mat:** Place the quilted play mat inside the tent. The mat is sized to fit the base of the tent.
6. **Install Lights:** String the decorative lights along the inside top edges of the tent. The battery pack for the lights has a simple on/off switch. For best results, create small loops with the wire and hook them onto the tent's roof loops or frame. Insert 2 AA batteries (not included) into the battery pack.
7. **Add Banners:** Attach the colorful pennant banners to the tent as desired for decoration.



Figure 3.1: Tent dimensions (57" L x 35.5" W x 53" H) and overall structure.



Figure 3.2: Details of the tent's features, including the breathable window and fabric ties.

4. Operating Instructions (Usage)

The Razee Kids Play Tent provides a comfortable and engaging space for children.

- **Creating a Play Space:** The tent is ideal for creating a magical reading nook, a quiet retreat, or a fun play area.
- **Indoor & Outdoor Use:** Suitable for use in bedrooms, family rooms, kids' playrooms, and even outdoors in a backyard or park (ensure it is placed on a flat, stable surface and protected from harsh weather).
- **Privacy:** The front flaps of the tent can be closed and secured with ties to provide a private space for your child.
- **Lighting:** Activate the string lights using the on/off switch on the battery pack to create a warm and inviting ambiance, especially useful for bedtime stories or quiet play.



Figure 4.1: The Razee Kids Play Tent set up for play.



Figure 4.2: The tent offers ample space for children to play comfortably.

5. Maintenance

- **Tent Fabric:** If the tent fabric becomes wrinkled from packaging or storage, it can be steamed or ironed on a low setting to smooth it out.
- **Play Mat:** The quilted play mat is machine washable for easy cleaning. Follow care instructions on the mat's label.
- **General Cleaning:** For minor spills or dirt on the tent fabric, spot clean with a damp cloth and mild soap. Allow to air dry completely before storage.
- **Storage:** When not in use, the tent can be easily de-constructed and stored in its original packaging or a suitable storage bag to protect it from dust and damage.



Figure 5.1: The included play mat is machine washable for convenience.

6. Troubleshooting

Problem	Possible Cause / Solution
Tent frame feels unstable or collapses easily.	Ensure all PVC piping poles are fully inserted into their connectors. Apply firm pressure until they are snug.
Tent fabric appears wrinkled.	This is normal due to packaging. Use a garment steamer or iron on a low setting to smooth out wrinkles.
String lights are not working.	Check if 2 AA batteries are correctly installed in the battery pack. Ensure the on/off switch is in the "on" position. Replace batteries if needed.
Tent corners or edges do not stay tucked under.	Minor adjustments may be needed. Ensure the fabric is evenly distributed over the frame. Small sewing adjustments can be made if persistent.

Problem	Possible Cause / Solution
Missing parts upon arrival.	Contact Razee customer support immediately for assistance.

7. Specifications

Feature	Detail
Product Dimensions	57" L x 35.5" W x 53" H (144.78 x 90.17 x 134.62 cm)
Item Weight	8.69 pounds (3.94 kg)
Model Number	USRP-22
Manufacturer Recommended Age	36 months - 12 years
Material	Fabric (no smell, safe for kids)
Lighting Power	2 x AA Batteries (not included)

8. Warranty and Support

For specific warranty information and customer support, please refer to the documentation included with your purchase or contact Razee directly through their official channels. You can visit the Razee Store on Amazon for more information.

Manufacturer: Razee

© 2025 Razee. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question