Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy Osmos Mini Bluetooth Speaker Set

iJoy Osmos Mini Bluetooth Speaker Set - User Manual

Model: Osmos Mini Bluetooth Speaker Set

1. Introduction

Thank you for purchasing the iJoy Osmos Mini Bluetooth Speaker Set. This manual provides essential information for the safe and efficient operation of your new portable wireless stereo speakers. Please read this manual thoroughly before use and retain it for future reference.

2. Package Contents

Please check the package for the following items:

- 2 x Osmos Mini Bluetooth Speakers
- 1 x Dual Charging Dock
- 1 x Micro USB Charging Cable (for individual speaker charging)
- 2 x Lanyards
- 1 x User Manual (this document)

3. Product Overview

The iJoy Osmos Mini Bluetooth Speaker Set consists of two compact, metal-cased speakers designed for portable stereo audio. Each speaker features a power/multifunction button, a micro USB charging port, and an LED indicator.



Figure 3.1: iJoy Osmos Mini Bluetooth Speakers illustrating wireless dual stereo capability.

The speakers are designed for easy portability and can be carried individually or as a pair. Their compact size makes them suitable for various environments.



Figure 3.2: Dimensions of a single iJoy Osmos Mini Bluetooth Speaker.

4. Setup

4.1 Charging the Speakers

Before first use, fully charge both speakers. You have two charging options:

1. **Using the Dual Charging Dock:** Place both speakers onto the charging dock. Ensure they are correctly seated. The LED indicator on each speaker will illuminate to show charging status.
2. **Individual Charging:** Connect the micro USB charging cable to the micro USB port on each speaker and then to a USB power source (e.g., computer, USB wall adapter).

A full charge provides approximately 8 hours of playtime. The LED indicator will change color (e.g., red for charging, off or blue for fully charged) depending on the speaker's status.



Figure 4.1: Charging the Osmos Mini Bluetooth Speakers using the dock or individually.

4.2 Powering On/Off

- **To Power On:** Press and hold the power/multifunction button on each speaker for a few seconds until you hear an audible prompt and the LED indicator lights up.
- **To Power Off:** Press and hold the power/multifunction button on each speaker again for a few seconds until you hear an audible prompt and the LED indicator turns off.

4.3 Bluetooth Pairing

The speakers can be used individually or paired together for stereo sound.

4.3.1 Single Speaker Pairing

1. Ensure the speaker is powered on and in pairing mode (LED will typically flash).
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices and select "OSMOS Speaker" (or similar name).
4. Once connected, the speaker will provide an audible confirmation, and the LED will stop flashing.

4.3.2 Stereo Pairing (Two Speakers)

1. Power on both Osmos Mini Bluetooth Speakers. Do not connect them to any device yet.
2. The speakers will automatically attempt to pair with each other. You will hear an audible confirmation when they are successfully paired for stereo sound. One speaker will act as the master (left channel) and the other as the slave (right channel).
3. Once the two speakers are paired with each other, connect your Bluetooth-enabled device to the master speaker (usually indicated by a specific LED pattern or audible prompt) as described in Section 4.3.1.

The speakers maintain a stable connection up to 33 feet (10 meters) from the connected device.



Figure 4.2: Osmos Mini Bluetooth Speaker maintaining connection over distance.

5. Operating Instructions

5.1 Playing Audio

Once connected via Bluetooth, audio played from your device will be streamed to the speaker(s). Use your device to

control playback (play/pause, skip tracks) and volume.



Figure 5.1: Osmos Mini Bluetooth Speakers connected to a television for audio output.

5.2 Hands-Free Calling

When connected to a smartphone, the Osmos Mini Bluetooth Speaker supports hands-free calling.

- **Answer Call:** Press the power/multifunction button once when a call comes in.
- **End Call:** Press the power/multifunction button once during a call.
- **Reject Call:** Press and hold the power/multifunction button for approximately 2 seconds when a call comes in.

6. Maintenance and Care

- **Cleaning:** Wipe the speakers with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speakers in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** These speakers are not waterproof. Avoid exposure to water or excessive moisture.

- **Battery Care:** To prolong battery life, fully charge the speakers at least once every three months if not in regular use.



Figure 6.1: Osmos Mini Bluetooth Speakers designed for outdoor use, emphasizing durability.

7. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on	Low battery	Charge the speaker fully.
No sound	Volume too low; Not connected; Device issue	Increase volume on speaker and device; Ensure Bluetooth is connected; Check device audio output.
Cannot pair with device	Speaker not in pairing mode; Device Bluetooth off; Interference	Ensure speaker is flashing LED; Turn device Bluetooth off/on; Move closer to speaker; Disconnect from other devices.

Problem	Possible Cause	Solution
Stereo pairing fails	Speakers already connected to a device	Ensure both speakers are not connected to any device before attempting stereo pairing. Power cycle both speakers.

8. Specifications

Feature	Specification
Brand	iJoy
Model	Osmos Mini Bluetooth Speaker Set
Connectivity Technology	Bluetooth, USB
Speaker Maximum Output Power	6 watts (2 x 3W)
Audio Output Mode	Stereo, Surround
Enclosure Material	Metal
Bluetooth Range	10 meters (33 feet)
Power Source	Battery Powered
Battery Life	Up to 8 hours
Compatible Devices	Laptop, Smartphone, Tablet, Television
Control Method	App (via connected device)
Number of Audio Channels	2
Unit Count	2 Count

9. Safety Information

- Do not expose the speakers to extreme temperatures, direct sunlight, or open flames.
- Do not disassemble, repair, or modify the device. This may cause damage, electric shock, or fire.
- Keep the device away from water and other liquids.
- Do not use the device near strong magnetic fields.
- Dispose of the device and its battery responsibly according to local regulations.

10. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact iJoy customer service through their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZTK35LM

More documents and user manuals: **https://manuals.plus/**