Mueller MLR010560N

MuellerLiving Electric Coffee Grinder Instruction Manual

Model: MLR010560N

1. Important Safety Instructions

Please read all instructions carefully before using your MuellerLiving Electric Coffee Grinder. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before cleaning, assembling, or disassembling parts.
- Do not immerse the motor base, cord, or plug in water or other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Close supervision is necessary when any appliance is used by or near children. Children should be supervised to ensure that they do not play with the appliance.
- Avoid contact with moving parts. The blades are sharp. Handle with care.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner. Contact customer service for assistance.
- Use the appliance only for its intended household purpose, which is grinding coffee beans, spices, or herbs.
- Do not use outdoors.
- Ensure the lid is securely in place before operating the grinder. The safety mechanism prevents operation without the lid.
- Do not overfill the grinding chamber. Refer to the 'Operating Instructions' for maximum capacity.

2. Product Overview

The MuellerLiving Electric Coffee Grinder is designed for efficient and consistent grinding of coffee beans, spices, and herbs. Its compact design and powerful motor make it a versatile addition to your kitchen.



Image 1: MuellerLiving Electric Coffee Grinder, showcasing its sleek black design and compact form factor.

Components:

- **Transparent Lid:** Allows you to monitor the grinding process. Features a safety interlock.
- **Stainless Steel Grinding Bowl:** Durable chamber for holding ingredients.
- **Stainless Steel Blades:** Sharp, high-speed blades for efficient grinding.
- **One-Touch Power Button:** Simple press-and-hold operation.

- **Motor Base:** Contains the motor and power cord.
- **Cord Storage:** Integrated cord wrap underneath the base for neat storage.



Image 2: Close-up view of the grinder's top, showing the transparent lid and the stainless steel blades within the grinding bowl.

3. Setup

Before first use, follow these steps:

1. Unpack the grinder and all its components. Remove any packaging materials.
2. Wipe the exterior of the motor base with a damp cloth.
3. Clean the grinding bowl and lid with a damp cloth and mild detergent. Rinse thoroughly and dry completely before use. Do not immerse the motor base in water.
4. Place the grinder on a stable, flat, and dry surface.
5. Unwind the power cord from the cord storage area at the bottom of the unit.



Image 3: Underside of the grinder, illustrating the integrated cord storage for convenient organization.

4. Operating Instructions

This grinder is designed for simple, one-touch operation.

Grinding Coffee Beans or Spices:

1. Ensure the grinder is unplugged.
2. Remove the transparent lid.
3. Add your desired amount of whole coffee beans, spices, or herbs to the grinding bowl. Do not exceed the maximum capacity of 9 tablespoons (approximately 1.8 oz / 50g). Overfilling can lead to inefficient grinding and potential damage.



Image 4: Top-down view of the grinding bowl, showing coffee beans inside and indicating the maximum capacity.

4. Place the transparent lid securely onto the grinder. Ensure it clicks into place. The grinder will not operate if the lid is not properly seated due to its safety mechanism.



Image 5: Illustrates the proper placement of the transparent lid onto the grinder, highlighting the safety feature.

5. Plug the grinder into a standard 120V AC electrical outlet.
6. Press and hold the power button to begin grinding. The blades will spin as long as the button is held down. Release the button to stop grinding.



Image 6: Hands operating the grinder by pressing the one-touch power button.

Achieving Desired Grind Consistency:

The grinding time determines the fineness of your grind. Monitor the consistency through the transparent lid.

- **Coarse Grind (French Press):** Grind for approximately 6-8 seconds.
- **Medium Grind (Drip Coffee Maker):** Grind for approximately 10-12 seconds.
- **Fine Grind (Espresso Machine, Pour Over):** Grind for approximately 14-16 seconds.



Image 7: Visual guide demonstrating coarse, medium, and fine grind consistencies with recommended grinding times.

After grinding, unplug the unit, remove the lid, and carefully pour out the ground contents. For best results, grind only the amount needed for immediate use.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your grinder.

1. **Always unplug the grinder before cleaning.**
2. **Grinding Bowl and Blades:** The grinding bowl is not detachable. To clean, use a small brush (not included) to remove any residual grounds. Then, wipe the interior of the bowl and the blades with a damp cloth. For stubborn residue, a cloth dampened with mild detergent can be used, followed by a clean, damp cloth to remove soap residue. Ensure the bowl and blades are completely dry before next use.
3. **Lid:** The transparent lid can be washed with warm, soapy water. Rinse thoroughly and dry completely.
4. **Exterior:** Wipe the exterior of the motor base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
5. **Storage:** Store the grinder in a dry place with the power cord neatly wrapped in its storage compartment.

Important: Never immerse the motor base in water or any other liquid.

6. Troubleshooting

If you encounter issues with your grinder, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Grinder does not start.	1. Power cord not plugged in. 2. Lid not securely in place. 3. Overheating.	1. Ensure the grinder is properly plugged into a working outlet. 2. Remove and re-seat the lid, ensuring it clicks into place. 3. Unplug the grinder and allow it to cool down for 30 minutes before attempting to use it again.
Inconsistent grind.	1. Insufficient grinding time. 2. Overfilling the grinding bowl. 3. Grinder not level.	1. Increase grinding time slightly. Pulse the button for better control. 2. Reduce the amount of ingredients. Do not exceed 9 tablespoons. 3. Ensure the grinder is on a flat, stable surface during operation.
Grinder stops during operation.	1. Lid dislodged. 2. Overheating.	1. Check if the lid is still securely in place. Re-seat if necessary. 2. Unplug the grinder and allow it to cool down for 30 minutes.

If the problem persists after attempting these solutions, please contact MuellerLiving customer support.

7. Specifications

Feature	Detail
Model Number	MLR010560N
Brand	Mueller
Color	Black
Style	One Touch
Product Dimensions	3.62"L x 7.8"W x 3.62"H
Item Weight	1.82 pounds
Voltage	120 Volts (DC)
Grinding Capacity	Up to 9 tablespoons (approx. 1.8 oz / 50g)
Manufacturer	Mueller Austria
UPC	810022373729

8. Warranty and Support

MuellerLiving products are manufactured with quality and durability in mind. For information regarding warranty coverage, product registration, or customer support, please visit the official MuellerLiving website or contact their customer service department. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question