Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PINDOWS PDS-607-N3

PINDOWS Kids Digital Sport Watch PDS-607-N3 User Manual

Model: PDS-607-N3

1. Introduction

Thank you for choosing the PINDOWS Kids Digital Sport Watch PDS-607-N3. This watch is designed for children aged 5-15, offering a range of useful functions including accurate timekeeping, an alarm, stopwatch, calendar, and LED backlight. It is built with durable materials and features a waterproof design suitable for daily activities. This manual provides detailed instructions to help you set up and operate your watch effectively.



Image 1.1: PINDOWS Kids Digital Sport Watch PDS-607-N3. This image shows the front view of the watch with its digital display and various buttons.

2. Product Features and Button Functions

The PINDOWS PDS-607-N3 watch is equipped with several features and clearly labeled buttons for easy operation.

- **Accurate Timekeeping:** Digital display with 12/24-hour format.
- **Alarm Function:** Set daily alarms.
- **Stopwatch:** 1/100 second precision for timing activities.
- **LED Backlight:** For clear visibility in low light conditions.
- **Calendar:** Displays date and day of the week.
- **Water Resistance:** 30 meters (3ATM) for daily use.
- **Durable Construction:** Resin mirror, ABS case, PU band, Stainless Steel buckle.



Image 2.1: Product Features and Button Layout. This image highlights the watch's dimensions, materials, and functions, along with the positions of the LIGHT, MODE, START, and RESET buttons.

Button Functions:

- **LIGHT Button:** Activates the LED backlight.
- **MODE Button:** Cycles through different modes (Time, Alarm, Stopwatch, Date).
- **START Button:** Starts/stops the stopwatch, adjusts values during setting.
- **RESET Button:** Resets the stopwatch, selects digits/items during setting.



Image 2.2: Functional Overview. This image visually represents the key functions: Alarm, EL Backlight, Calendar Week, 30m Waterproof, and Stopwatch Timing.

3. Setup and Time Setting

3.1 Initial Setup

Your PINDOWS watch comes with a pre-installed Lithium Metal battery. It should be ready for use upon arrival. If the display is blank, ensure the battery insulator tab (if present) has been removed. If the display remains blank, the battery may need replacement (refer to Section 5.3).

3.2 Setting Time and Date

1. From the normal time display, press the **MODE** button three times to enter the time setting mode. The seconds digits will start flashing.
2. Press the **RESET** button to cycle through the setting items: Seconds → Hours → Minutes → Month → Date → Day of the Week.

3. While an item is flashing, press the **START** button to adjust its value. Hold **START** to change values more quickly.
4. For the 12/24-hour format, when the hour digits are flashing, press **START** to toggle between 12-hour (with 'PM' indicator) and 24-hour formats.
5. Once all settings are correct, press the **MODE** button once to return to the normal time display.

4. Operating Instructions

4.1 LED Backlight

To illuminate the display in dark conditions, press the **LIGHT** button. The backlight will activate for a few seconds.



Image 4.1: LED Backlight. This image demonstrates pressing the 'LIGHT' button to activate the super bright backlight display for clear viewing at night.

4.2 Alarm Function

1. From the normal time display, press the **MODE** button once to enter the Alarm mode.

2. Press the **RESET** button to select the hour or minute digits.
3. Press the **START** button to adjust the flashing hour or minute.
4. To turn the alarm ON/OFF, press the **START** and **RESET** buttons simultaneously while in Alarm mode. An alarm icon will appear/disappear on the display.
5. Press the **MODE** button to return to the normal time display.
6. When the alarm sounds, press any button to stop it.



Image 4.2: Alarm Clock. This image illustrates the alarm function, which can help in establishing regular habits.

4.3 Stopwatch Function

1. From the normal time display, press the **MODE** button twice to enter the Stopwatch mode. The display will show "00:00:00".
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **START** button to resume timing.
5. While the stopwatch is paused, press the **RESET** button to reset the stopwatch to "00:00:00".

6. Press the **MODE** button to return to the normal time display.

4.4 Date and Day of Week Display

The watch automatically displays the current date and day of the week in the normal time mode, once correctly set (refer to Section 3.2).

5. Maintenance

5.1 Water Resistance (3ATM / 30 Meters)

The PINDOWS PDS-607-N3 watch is rated for 3ATM (30 meters) water resistance. This means it is resistant to splashes, rain, and brief immersion in water, such as hand washing or accidental spills. It is suitable for showering and swimming in shallow water. However, it is **not** recommended for hot water activities (e.g., hot showers, saunas) or diving, as steam and rapid temperature changes can compromise the seals. Do not press buttons underwater.



Image 5.1: 3ATM Water Resistance. This image illustrates the watch's resistance to water from washing, swimming, and rain.

5.2 Cleaning Your Watch

To clean your watch, wipe it gently with a soft, damp cloth. Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and seals.

5.3 Battery Replacement

The watch uses 1 Lithium Metal battery. When the display becomes dim or stops functioning, the battery may need replacement. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and water resistance. Attempting to replace the battery yourself may void any warranty and could damage the watch.



Image 5.2: Reliable Quality Components. This image shows the highly transparent resin glass, particle non-slip buttons, comfortable strap, and anti-corrosion backcover, indicating the watch's construction.

6. Troubleshooting

- **Display is blank:** Check if the battery is depleted. If recently purchased, ensure any protective tab has been removed.

Consider professional battery replacement.

- **Time is incorrect:** Re-set the time and date following instructions in Section 3.2. Ensure the 12/24-hour format is set as desired.
- **Alarm not sounding:** Ensure the alarm function is activated (alarm icon visible on display). Check alarm time settings.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though this model does not feature a lock). If buttons are stuck, gently clean around them. If the issue persists, contact support.

7. Specifications

Feature	Specification
Brand	PINDOWS
Model Number	PDS-607-N3
Display Type	Digital
Movement Type	Quartz (Japan Original)
Case Material	ABS (Acrylonitrile Butadiene Styrene)
Mirror Material	Resin (Acrylic Crystal)
Band Material	Polyurethane
Buckle Material	Stainless Steel
Case Diameter	42 mm (1.62 Inches)
Case Thickness	17 mm (0.6 Inches)
Band Width	18 mm (0.64 Inches)
Water Resistance	30 Meters (3ATM)
Battery Type	1 Lithium Metal battery (included)
Functions	Time (12/24H), Date, Day, Alarm, Stopwatch (Chrono), LED Backlight
Item Weight	109 g

8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact PINDOWS customer service directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZYH71SJ

More documents and user manuals: **https://manuals.plus/**