Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PINDOWS PDS-608-N3

PINDOWS Kids Multifunctional Digital Sport Watch

User Manual

Brand: PINDOWS | **Model:** PDS-608-N3

Introduction

Thank you for choosing the PINDOWS Kids Multifunctional Digital Sport Watch. This watch is designed for active children aged 5-15, offering accurate timekeeping with a Japanese quartz movement and a range of useful features including an LED backlight, alarm, calendar, and stopwatch. Its durable and waterproof design makes it suitable for various outdoor activities.



Figure 1: Front view of the PINDOWS Kids Digital Sport Watch. This image shows the watch face with digital display, analog-style indicators, and the four control buttons.

Product Features Overview



Figure 2: Functional Overview. This image highlights key features such as LED Backlight, Alarm Function, 30m Waterproof, Calendar Week, Stopwatch Timing, and Hourly Chime.

- **Accurate Timekeeping:** Equipped with an imported Japanese quartz movement and battery.
- **Multi-Functional:** Digital display, Date, Week, Alarm, Stopwatch, Hourly Chime, 12/24h format, LED backlight, 30m Waterproof.
- **Durable Materials:** High-quality PU strap, high-hardness mineral tempered glass mirror, 304 stainless steel face ring and back cover.

Setup and Initial Use

Your PINDOWS watch comes with a pre-installed lithium metal battery. Before first use, you may need to set the current time and date.

Button Functions:

The watch features four main buttons:

- **LIGHT:** Activates the LED backlight.
- **MODE:** Cycles through different modes (Time, Alarm, Stopwatch).
- **START:** Used for starting/stopping functions in Stopwatch mode, and adjusting values in setting modes.
- **RESET:** Used for resetting functions in Stopwatch mode, and adjusting values in setting modes.



Figure 3: LED Backlight and Button Identification. This image clearly labels the 'LIGHT' button and demonstrates the watch's super bright backlight display.

Operating Instructions

1. Setting Time and Date:

1. From the normal time display, press the**MODE** button three times to enter time setting mode. The seconds will start flashing.
2. Press the **RESET** button to cycle through the setting items: Seconds → Hours → Minutes → Month → Date → Day of Week.
3. Use the **START** button to adjust the flashing value.

4. Once all settings are complete, press the **MODE** button to return to normal time display.
5. To switch between 12-hour and 24-hour format, press the **START** button while the hour is flashing in time setting mode.

2. Using the Alarm Function:



Figure 4: Alarm Clock Feature. This image illustrates the alarm function, which can help children develop regular sleep habits.

1. From the normal time display, press the **MODE** button once to enter Alarm mode.
2. Press the **RESET** button to select the hour or minute to set.
3. Use the **START** button to adjust the flashing value.
4. Press the **MODE** button to confirm and exit Alarm setting mode.
5. To turn the alarm ON/OFF, press the **START** button while in Alarm mode. An alarm icon will appear/disappear.

3. Using the Stopwatch:

1. From the normal time display, press the **MODE** button twice to enter Stopwatch mode.

2. Press the **START** button to begin timing. Press **START** again to pause.
3. Press the **RESET** button to reset the stopwatch to zero.
4. Press the **MODE** button to return to normal time display.

4. LED Backlight:

Press the **LIGHT** button at any time to illuminate the watch face for clear viewing in low-light conditions.

5. Hourly Chime:

To activate or deactivate the hourly chime, press and hold the **RESET** button while in normal time display. A chime icon will appear/disappear when activated/deactivated.

Maintenance and Care

Water Resistance:



Figure 5: 3ATM Waterproof. This image demonstrates the watch's resistance to sweat and rain, and its suitability for swimming and

showering.

This watch is 30m (3ATM) waterproof, meaning it is resistant to sweat, rain, and can support swimming and showering. However, it is **not recommended** for diving or prolonged submersion in hot water. Do not press any buttons while the watch is wet or submerged to prevent water ingress.

Cleaning:

Wipe the watch clean with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by drying. Avoid using chemical cleaners or abrasive materials.

Battery:

The watch uses a Lithium Metal battery (included). When the display becomes dim or functions are erratic, it may be time for a battery replacement. It is recommended to have battery replacement performed by a qualified technician to ensure water resistance is maintained.

Troubleshooting

- **Display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Buttons are unresponsive:** Ensure the watch is not wet. If the issue persists, a reset may be needed (consult customer service if no reset button is apparent).
- **Time is inaccurate:** Re-set the time following the instructions in the 'Operating Instructions' section. If inaccuracy persists, the battery may be low or the movement may require service.
- **Water inside the watch:** Immediately stop using the watch and seek professional service. Do not attempt to dry it yourself.

Specifications



Figure 6: Product Features and Dimensions. This image provides a visual summary of the watch's key specifications.

Feature	Detail
Model Number	PDS-608-N3
Movement Type	Automatic (Quartz)
Case Diameter	1.64 Inches (approx. 42mm)
Case Thickness	0.6 Inches (approx. 15mm)
Band Material Type	Polyurethane (PU)
Band Width	0.62 Inches (approx. 16mm)
Band Color	Blue (as per product image)

Water Resistance	30m (3ATM)
Battery	1 Lithium Metal battery (included)
Item Weight	91 g
Manufacturer	PINDOWS



Figure 7: Detailed Components. This image shows the highly transparent resin glass, particle non-slip buttons, stainless steel clasp, and anti-corrosion backcover.

Warranty and Support

PINDOWS provides a **12-month warranty service** for this product. If you encounter any issues or have questions regarding your watch, please do not hesitate to contact our customer service. We are committed to providing the best products and services.

For support, please refer to the contact information provided with your purchase or visit the official PINDOWS website.

© 2023 PINDOWS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BZYJ687C

More documents and user manuals: **https://manuals.plus/**