Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ODK XSD-B010116

ODK Computer Desk User Manual

Model: XSD-B010116

Introduction

Thank you for choosing the ODK Computer Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Warnings

Attention: Please follow the assembly instructions carefully. Do not exceed the recommended maximum load of 25 kg (55 lbs) to ensure the stability and safety of the desk. Ensure all screws are tightened securely before use.

Package Contents

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desk Top Panel (1)
- Metal Frame Legs (2)
- Crossbars/Support Beams (2-3, depending on design)
- Storage Bag (1)
- Headphone Hook (1)
- Assembly Hardware (Screws, Allen Wrench, etc.)
- Instruction Manual (This document)



Figure 1: Exploded view of desk components, showing the tabletop, metal frame, and accessories.

Setup and Assembly

Assembly is straightforward and typically takes about 30 minutes. It is recommended to assemble the desk on a soft, clean surface to prevent scratches. All necessary tools are included in the package.

1. **Step 1: Attach Crossbars to Legs.** Lay one metal leg frame on the floor. Attach the crossbars to the designated holes using the provided screws. Do not fully tighten yet.
2. **Step 2: Attach Second Leg Frame.** Connect the second metal leg frame to the other end of the crossbars. Ensure all connections are aligned.
3. **Step 3: Secure the Frame.** Once the frame is assembled, gently tighten all screws using the Allen wrench. Ensure the frame is stable and level.
4. **Step 4: Attach Desk Top.** Carefully place the desk top panel onto the assembled metal frame. Align the pre-drilled holes on the underside of the desk top with the holes on the frame. Secure the desk top to the frame using the

remaining screws. Fully tighten all screws.

5. **Step 5: Install Storage Bag and Headphone Hook.**Attach the storage bag to the side of the desk frame as shown in the diagrams. The headphone hook can be attached to either side of the desk. Ensure you choose the correct parts and screws during assembly.



Figure 2: The ODK Computer Desk fully assembled, showcasing its modern design and functional features.

Operating Instructions

The ODK Computer Desk is designed for versatile use in various settings, including home offices, study rooms, and bedrooms.

- **Work Surface:** Utilize the spacious tabletop for your computer, laptop, monitor, keyboard, and other work essentials. The 100cm (39.4 inch) surface provides ample space.
- **Storage Bag:** The additional storage bag helps organize your workspace more efficiently. It is ideal for storing documents, notebooks, pens, and small electronic devices.

- **Headphone Hook:** Use the versatile hook to hang headphones, bags, or other useful gadgets, keeping your desk tidy and items easily accessible.



Figure 3: The integrated storage bag provides convenient organization for office supplies and personal items.



Figure 4: The headphone hook offers a practical solution for keeping headphones off the desk surface.

Maintenance

Proper care will extend the life and appearance of your ODK Computer Desk.

- **Cleaning:** The melamine veneer tabletop is waterproof, heat-resistant, and dust-proof. Simply wipe with a damp cloth to clean. Avoid abrasive cleaners.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- **Load Capacity:** Do not exceed the maximum load capacity of 25 kg (55 lbs) to prevent damage and ensure safety.

Troubleshooting

Problem	Possible Cause	Solution
Desk is wobbly.	Screws are loose; uneven floor.	Tighten all assembly screws. Ensure the desk is on a flat, level surface.
Parts missing from package.	Packaging error.	Contact ODK customer support with your purchase details.
Difficulty assembling.	Incorrect part orientation; screws not aligning.	Review the assembly instructions carefully. Ensure you are using the correct parts and screws for each step. Do not overtighten screws until all parts are aligned.

Specifications

Brand: ODK

Model Number: XSD-B010116

Color: 3 x black

Product Dimensions (L x W x H): 100 x 48 x 73.5 cm (approximately 39.4 x 18.9 x 28.9 inches)

Item Weight: 7.9 kg (approximately 17.4 lbs)

Material: Metal (frame), Engineered Wood (top)

Special Features: Lightweight, Scratch Resistant, Storage Bag, Headphone Hook

Maximum Load Capacity: 25 kg (55 lbs)



Figure 5: Detailed dimensions of the ODK Computer Desk.

Warranty and Support

ODK is committed to customer satisfaction. If you encounter any issues with your product, or have questions regarding assembly, operation, or maintenance, please do not hesitate to contact our customer support team. We are here to assist you before and after your purchase.
For support, please refer to the contact information provided with your purchase or visit the official ODK website.

© 2025 ODK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C1BPXHSN

More documents and user manuals: **https://manuals.plus/**