Hiswelle Hiswelle[Unknown]

Hiswelle 17L/4.5Gal Ultra Large Humidifier Instruction Manual

Model: Hiswelle[Unknown]

1. Product Overview

The Hiswelle 17L/4.5Gal Ultra Large Humidifier is designed to effectively humidify dry air in large spaces up to 2000 square feet. It features a large water capacity, multiple mist modes, intelligent humidity control, and convenient mobility features.



Image: The Hiswelle 17L/4.5Gal Ultra Large Humidifier, showcasing its tall design and mist output.

2. Safety Precautions

- Always place the humidifier on a firm, flat, and waterproof surface.
- Do not immerse the unit in water or other liquids.
- Ensure the power cord is not damaged and is properly plugged into a suitable outlet.
- Keep out of reach of children and pets.
- Do not add water directly into the mist nozzle. Always fill the water tank as instructed.
- The unit features an automatic shut-off and waterless alarm when the tank is low on water.

3. Setup and Assembly

1. **Unpack the Humidifier:** Carefully remove all components from the packaging.
2. **Attach Wheels:** The humidifier comes with 4 flexible wheels for easy movement. Attach them to the base of the unit.

3. **Assemble Mist Tubes:** Connect the sprayer tube components to the top of the humidifier. The extension tube helps deliver mist to higher places. Ensure they are securely fitted.
4. **Fill Water Tank:** The humidifier features a 17L (4.5 Gallon) ultra-large capacity. Fill the water tank from the top, ensuring water is added to the sides and not directly into the central mist nozzle. Do not exceed the 'Max' fill line.
5. **Power On:** Plug the power cord into a standard electrical outlet.

Image: Illustration of the top-fill water tank, highlighting the ease of refilling without bending.



Image: The humidifier with its caster wheels, demonstrating its portability.

4. Operating Instructions

The humidifier can be operated via the touch control panel or the included remote control.

Control Panel Functions:

- **Power On/Off:** Press the power button to turn the unit on or off.
- **Mist Volume:** Select from 4 mist volume modes (low, medium, high, highest) to adjust the output.
- **Customize Humidity:** Use the humidistat feature to set your desired humidity level between 45% and 95%. The unit will automatically adjust mist levels to maintain this setting.
- **Timer:** Set the operating time from 1 to 16 hours. The humidifier will automatically shut off after the set time.
- **Sleep Mode:** Activates whisper-quiet operation and dims the display for undisturbed rest.
- **Intermittent Mist:** Choose between constant mist or intermittent mist modes (e.g., 1, 3, or 5-minute intervals).
- **UV Lamp:** Activate the UV lamp for water purification, helping to ensure clean mist output.



Image: The easy-to-operate control panel and portable remote control for convenient adjustments.



Image: Visual representation of the smart sensor automatically adjusting mist levels based on desired humidity.

Essential Oil Diffuser:

An aroma box is located on the back of the unit. Press to open, add **ONLY 2 drops** of essential oil to the pad, and then close. The humidifier will then diffuse the aroma with the mist.

Video: An official product video demonstrating the features and operation of the Hiswelle 17L Cool Mist Humidifier, including mist output and control panel functions.

5. Maintenance

- **Regular Cleaning:** The humidifier is designed without traditional filters, reducing the risk of mildew and simplifying maintenance. Regularly wipe down the unit and clean the water tank to prevent mineral buildup.
- **Top Nozzle:** Pay attention to cleaning the top nozzle area, as water can sometimes get trapped.
- **Water Quality:** Using distilled or demineralized water can help prevent white residue, especially in areas with hard water.

6. Troubleshooting

- **No Mist/Low Mist:** Check if the water tank is empty. The unit will automatically shut down and emit a waterless alarm. Refill the tank. Ensure the mist volume setting is appropriate.
- **Noisy Operation:** If the mist fan/blower becomes noisy or slows intermittently, it may require inspection or replacement.
- **Water Leakage:** Ensure the water tank is not overfilled. The 'Max' line indicates the maximum water level. If using the wheels to move the unit, remove the mist tubes and exercise caution to prevent the tank from tipping.
- **Difficulty Monitoring Water Level:** The water level indicator is a small glass window. It may be difficult to see the water level clearly. Exercise caution when refilling to avoid overfilling.

7. Specifications

Feature	Detail

Brand	Hiswelle
Model Number	Hiswelle[Unknown]
Color	WHITE
Capacity	17 Liters (4.5 Gallons)
Floor Area Coverage	Up to 2000 Square Feet
Operation Mode	Ultrasonic
Product Dimensions	11"D x 11"W x 28"H
Item Weight	11.1 pounds
Special Features	Sleep Mode & Whisper-Quiet, 4 Mist Level Options, Top Filling, 1-16 Hour Timer, Touch Control Panel, Waterless Auto Shut Off, Humidistat, Remote Control, Essential Oil Diffuser, UV Lamp
Room Type	Bedroom, Living Room, Office, Commercial, Greenhouse

8. Warranty and Support

Specific warranty details are not provided in the product information. For any support inquiries, troubleshooting assistance, or warranty claims, please contact Hiswelle customer service directly through their official channels or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question