Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Restokki Restokkiymnu6ih1k3

Restokki 61-Key Portable Electronic Keyboard Piano User Manual

Model: Restokkiymnu6ih1k3

1. Introduction

Thank you for purchasing the Restokki 61-Key Portable Electronic Keyboard Piano. This manual provides essential information for the safe and efficient operation of your new instrument. Please read it thoroughly before use and retain it for future reference.



Figure 1.1: Top view of the Restokki 61-Key Portable Electronic Keyboard Piano.

This image displays the Restokki 61-Key Portable Electronic Keyboard Piano from a top-down perspective, showcasing its 61 keys, control panel, and integrated speakers. The design emphasizes its compact and portable nature.

2. Package Contents

Verify that all items listed below are included in your package:

- 1 x Restokki 61-Key Keyboard Piano
- 1 x Microphone
- 1 x Power Supply (US standard flat plug)
- 1 x User Manual (this document)

3. Setup

3.1 Power Connection

1. Locate the DC power input port on the back of the keyboard.
2. Connect the provided power supply adapter to the DC input port.
3. Plug the power supply into a standard US electrical outlet.
4. Alternatively, the keyboard can be powered by batteries (not included). Refer to the battery compartment on the underside for correct battery type and insertion.

3.2 Microphone Connection

Connect the included microphone to the microphone input jack, typically located on the control panel or side of the keyboard.



Figure 3.1: Keyboard with music stand attached.

This image shows the keyboard with its detachable music stand in place, ready for sheet music. The overall view highlights the instrument's readiness for use.

4. Operating Instructions

4.1 Power On/Off

Press the **POWER** button located on the control panel to turn the keyboard on or off. The display will illuminate when powered on.

4.2 Basic Functions

- **Tone Selection:** Use the **TONE** buttons or number pad to select from 200 available tones.
- **Rhythm Selection:** Use the **RHYTHM** buttons or number pad to select from 200 available rhythms.
- **Demonstration Songs:** Press the **DEMO** button to cycle through 60 demonstration songs.

- **Volume Control:** Adjust the master volume using the dedicated**VOLUME** buttons or knob.

4.3 Advanced Functions

- **Sustain:** Press the **SUSTAIN** button to prolong the sound of notes.
- **Tremor (Vibrato):** Activate the **TREMOR** function to add a vibrato effect to the sound.
- **Recording:** Use the **RECORD** button to record your performances. Press**PLAY** to listen to recorded tracks.
- **Chord Function:** Engage the **CHORD** function for automatic chord accompaniment.
- **Keyboard Drum:** Access percussion sounds directly from the keyboard keys using the**KEYBOARD DRUM** mode.
- **Double Keyboard:** This feature allows splitting the keyboard into two sections, each with independent tone settings.



Figure 4.1: Detailed view of the control panel.

This close-up image focuses on the control panel of the keyboard, showing the various buttons and the digital display. Key functions such as power, volume, tone, rhythm, and recording controls are visible.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the keyboard. Do not use liquid cleaners or abrasive

materials.

- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** If using batteries, remove them if the keyboard will not be used for an extended period to prevent leakage.
- **Avoid Moisture:** Keep the keyboard away from water and high humidity to prevent damage to electronic components.

6. Troubleshooting

Problem	Possible Cause	Solution
No sound	Power not connected or low batteries. Volume set to minimum. Headphones connected.	Ensure power supply is connected or replace batteries. Increase volume. Disconnect headphones.
Keys not responding	Keyboard in an incorrect mode. Internal malfunction.	Restart the keyboard. Contact customer support if problem persists.
Distorted sound	Volume too high. Faulty microphone connection.	Reduce volume. Check microphone connection or try a different microphone.

7. Specifications

Model Number	Restokkiymnu6ih1k3
Number of Keys	61
Dimensions (Approx.)	74.3 x 17.2 x 4.8 cm (29.3 x 6.8 x 1.9 inches)
Material	ABS
Tones	200
Rhythms	200
Demonstration Songs	60
Functions	Rhythm control, keyboard drum, double keyboard, chord function, sustain, tremor, transfer control, recording function
Power Source	DC Power Adapter (US standard flat plug) or Batteries (not included)
Item Weight	1.3 kg (2.86 pounds)

8. Warranty and Support

8.1 Warranty Information

This product is covered by a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. Keep your purchase receipt as proof of purchase.

8.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact Restokki customer support. Contact details can typically be found on the product packaging or the official Restokki website.
You may also visit the Restokki Store on Amazon for additional product information and support resources.

© 2023 Restokki. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0C1KMX381

More documents and user manuals: **https://manuals.plus/**